

Amazon Basics B08FV5PLFW

AmazonBasics Shelving Storage Units User Manual

Models: 4-Shelf Shelving Unit with Casters & 3-Shelf Adjustable Shelving Unit

1. INTRODUCTION

Thank you for choosing AmazonBasics Shelving Storage Units. These versatile and durable units are designed to provide efficient storage solutions for various environments, including kitchens, offices, garages, and more. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and optimal use of your shelving units.

This manual covers both the 4-shelf unit with casters and the 3-shelf adjustable unit.

2. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Weight Capacity:** Do not exceed the maximum weight capacity per shelf or total unit capacity. Refer to the 'Specifications' section for details.
- **Even Distribution:** Distribute weight evenly across shelves to prevent tipping or collapse.
- **Stability:** Ensure the unit is placed on a flat, stable surface. For units with leveling feet, adjust them to ensure stability.
- **Casters:** If using casters, lock them when the unit is stationary to prevent unintended movement. Exercise caution when moving a loaded unit.
- **Children:** Keep children away from the unit during assembly. Do not allow children to climb on or play with the shelving unit.
- **Assembly:** Assemble the unit according to the instructions. Ensure all parts are securely fastened before use.
- **Maintenance:** Regularly inspect the unit for loose parts or damage. Tighten fasteners as needed.

3. PARTS LIST

Verify that all components are present before beginning assembly. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

3.1. 4-Shelf Shelving Unit Components




Image: All components for the 4-shelf shelving unit, including wire shelves, vertical poles, casters, and plastic sleeve clips.

- Wire Shelves (4)
- Vertical Poles (4, multi-part)
- Plastic Sleeve Clips (numerous)
- Wheel Casters (4)
- Leveling Feet (4, optional alternative to casters)

3.2. 3-Shelf Adjustable Shelving Unit Components




Image: All components for the 3-shelf shelving unit, including wire shelves, vertical poles, plastic sleeve clips, and leveling feet.

- Wire Shelves (3)
- Vertical Poles (4, multi-part)
- Plastic Sleeve Clips (numerous)
- Leveling Feet (4)

4. SETUP AND ASSEMBLY

No tools are required for assembly. It is recommended to assemble the unit with two people for easier

handling, though one person can manage.

4.1. General Assembly Steps (Applicable to both units)

1. **Attach Leveling Feet/Casters:** Screw the leveling feet or casters into the bottom of the lower pole sections. For the 4-shelf unit, choose between casters for mobility or leveling feet for stationary use.
2. **Assemble Poles:** Screw the upper pole sections into the lower pole sections. Ensure they are tightly connected.
3. **Install Plastic Sleeve Clips:** On each pole, locate the desired height for your first shelf. Snap two plastic sleeve clips around each pole at the same height, ensuring the arrows on the clips point upwards. These clips will create a groove for the shelf to rest on.
4. **Place First Shelf:** Slide a wire shelf down over the poles until it rests securely on the plastic sleeve clips. Gently press down on each corner of the shelf to ensure it is fully seated and level.
5. **Repeat for Remaining Shelves:** Determine the desired height for subsequent shelves. Install plastic sleeve clips at the chosen height on all four poles, then slide the next wire shelf into place. Repeat until all shelves are installed.
6. **Final Check:** Once all shelves are in place, gently push down on each shelf to ensure it is firmly seated and stable. If using leveling feet, adjust them to eliminate any wobble.



Image: An assembled 4-shelf shelving unit with casters, ready for use.



Image: An assembled 3-shelf shelving unit with leveling feet, ready for use.

5. OPERATING INSTRUCTIONS

These shelving units are designed for static storage and, for the 4-shelf unit, occasional mobility.

- **Loading:** Place items on the shelves, ensuring weight is distributed evenly. Avoid concentrating heavy items in one small area.
- **Adjusting Shelf Height:** To adjust a shelf's height, first remove all items from that shelf. Then, lift the shelf off the plastic clips. Remove the clips, reposition them at the desired height (in 1-inch increments), and then place the shelf back onto the clips.
- **Moving (4-Shelf Unit with Casters):** Before moving the unit, ensure all items are stable and secure.

Unlock all casters. Push the unit slowly and carefully. Avoid sudden movements or pushing over uneven surfaces. Lock casters once the unit is in its new desired position.

6. MAINTENANCE

Regular maintenance will help prolong the life of your shelving unit.

- **Cleaning:** Wipe the unit with a dry cloth to remove dust and debris. For more stubborn marks, use a slightly damp cloth and mild soap, then dry thoroughly. Avoid abrasive cleaners or harsh chemicals.
- **Inspection:** Periodically check all connections and fasteners to ensure they are tight. If any parts appear loose, tighten them.
- **Damage:** If any part of the unit becomes bent, broken, or significantly damaged, discontinue use and replace the affected components or the entire unit.

7. TROUBLESHOOTING

If you encounter issues with your shelving unit, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit is wobbly/unstable	Uneven floor; loose connections; shelves not fully seated.	Adjust leveling feet; check all pole connections; ensure shelves are pressed down firmly onto clips.
Shelf slides down	Plastic sleeve clips not properly installed or damaged.	Ensure clips are snapped together securely and at the same height on all poles. Replace damaged clips.
Casters not rolling smoothly	Debris in casters; casters locked.	Clean casters; unlock casters before moving.

8. SPECIFICATIONS

Feature	4-Shelf Unit (with Casters)	3-Shelf Unit
Material	Steel (Chrome Finish)	Steel (Chrome Finish)
Dimensions (L x W x H)	36" x 14" x 57.75"	23.3" x 13.4" x 30"
Number of Shelves	4	3
Shelf Weight Capacity (Leveling Feet)	Up to 350 lbs (evenly distributed)	Up to 250 lbs (evenly distributed)
Shelf Weight Capacity (Casters, stationary)	Up to 110 lbs (evenly distributed)	N/A
Shelf Weight Capacity (Casters, in motion)	Up to 88 lbs (evenly distributed)	N/A
Total Max Load (Leveling Feet)	1400 lbs	750 lbs

Feature	4-Shelf Unit (with Casters)	3-Shelf Unit
Total Max Load (Casters, stationary)	440 lbs	N/A
Total Max Load (Casters, in motion)	353 lbs	N/A
Adjustable Shelves	Yes (1-inch increments)	Yes (1-inch increments)
Assembly Required	Yes	Yes

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or visit the official AmazonBasics website. You can also find additional support and contact options through your Amazon purchase history.

For a digital copy of the user manual, you may refer to the PDF document available at [User Manual \(PDF\)](#)