

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Aromar](#) /

› [Aromar Metal Ultrasonic Diffuser Cubes White \(100ml\) Instruction Manual](#)

Aromar Cubes White (100ml)

aromar

Aromar Metal Ultrasonic Diffuser Cubes White (100ml)

Instruction Manual

PRODUCT OVERVIEW

This manual provides detailed instructions for the safe and efficient use of your Aromar Metal Ultrasonic Diffuser Cubes White (100ml). Please read all instructions carefully before operating the device and retain this manual for future reference.



Image: The Aromar Metal Ultrasonic Diffuser operating, emitting a fine mist, placed next to a small potted plant.

1. SETUP INSTRUCTIONS

1. **Unpack the Diffuser:** Carefully remove all components from the packaging. Ensure all parts are present:

diffuser unit, power adapter, and instruction manual.

2. **Choose a Location:** Place the diffuser on a flat, stable, and water-resistant surface. Ensure it is away from direct sunlight, heat sources, and out of reach of children and pets.
3. **Remove the Cover:** Gently lift the metal outer cover and the inner plastic lid from the diffuser base.
4. **Fill the Water Tank:** Using a clean measuring cup, fill the water tank with clean tap water or distilled water up to the maximum water level line (100ml capacity). Do not overfill.
5. **Add Essential Oils:** Add 3-5 drops of your preferred essential oil directly into the water tank. Adjust the quantity based on personal preference and room size.
6. **Replace Covers:** Carefully place the inner plastic lid back onto the water tank, ensuring it is properly seated. Then, replace the metal outer cover.
7. **Connect Power:** Plug the power adapter into the DC jack located at the bottom or side of the diffuser. Then, plug the adapter into a standard electrical outlet.



Image: An Aromar diffuser with a wooden base and white top, emitting mist, positioned in a modern living space.

2. OPERATING INSTRUCTIONS

Once the diffuser is set up and powered, you can begin operation using the control buttons.

- **Power On/Off:** Press the "Mist" button once to turn on the continuous mist. Press again to turn off the mist.
- **Light Function:** Press the "Light" button once to turn on the LED light, which will cycle through various colors. Press again to fix the light to a specific color. Press a third time to turn off the light.

3. MAINTENANCE AND CARE

Regular cleaning ensures optimal performance and extends the lifespan of your diffuser.

Daily Maintenance:

- After each use, unplug the diffuser and empty any remaining water from the tank.
- Wipe the inside of the water tank with a clean, soft cloth.

Weekly Cleaning:

- Unplug the diffuser.
- Add about 10ml of white vinegar to the water tank.

- Let it sit for 5-10 minutes to loosen mineral buildup.
- Drain the vinegar and wipe the tank thoroughly with a soft cloth.
- Use a cotton swab dipped in vinegar to gently clean the ultrasonic disc (the small ceramic disc at the bottom of the tank). Do not scrub or apply excessive pressure.
- Rinse the tank with clean water, ensuring no vinegar residue remains.
- Allow the diffuser to air dry completely before storing or next use.

Important: Do not immerse the diffuser base in water. Do not use harsh detergents, abrasive cleaners, or metal objects to clean the ultrasonic disc.

4. TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
No mist or weak mist	<ul style="list-style-type: none"> • Insufficient water in tank. • Water level too high. • Ultrasonic disc dirty. • Diffuser not plugged in correctly. 	<ul style="list-style-type: none"> • Add water to the MAX line. • Pour out excess water. • Clean the ultrasonic disc as per maintenance instructions. • Ensure power adapter is securely connected.
Water leaking from base	<ul style="list-style-type: none"> • Overfilled water tank. • Covers not properly seated. • Diffuser placed on an uneven surface. 	<ul style="list-style-type: none"> • Do not exceed the MAX water line. • Ensure inner and outer covers are securely in place. • Place diffuser on a flat, stable surface.
No power	<ul style="list-style-type: none"> • Power adapter not connected. • No power from outlet. 	<ul style="list-style-type: none"> • Check power adapter connection to diffuser and outlet. • Test outlet with another device.

5. PRODUCT SPECIFICATIONS

- **Brand:** Aromar
- **Model:** Cubes White (100ml)
- **Material:** Metal
- **Water Capacity:** 100 Milliliters
- **Auto Shutoff:** No
- **ASIN:** B08FVG5T6Z
- **UPC:** 810148034825
- **Manufacturer:** Mar Company Group

Important Safety Note: This diffuser model does not feature an automatic shutoff function. Users must manually turn off the device when the water tank is empty or when not in use to prevent damage to the unit.

6. WARRANTY INFORMATION

Specific warranty details for the Aromar Metal Ultrasonic Diffuser Cubes White (100ml) are typically provided with your purchase documentation or can be found on the official Aromar website. Please refer to these resources for

information regarding warranty coverage, terms, and conditions.

7. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Aromar diffuser, please contact the retailer where the product was purchased or visit the official Aromar website for customer service contact information. You can visit the Aromar Store online: [Aromar Official Store](#)