FELICON X3

FELICON Wireless Lightweight Gaming Mouse X3 User Manual

Model: X3 (TD-MICEWHITE)

Introduction

This manual provides detailed instructions for the FELICON Wireless Lightweight Gaming Mouse, model X3. This mouse features advanced 2.4GHz wireless transmission technology, a lightweight honeycomb shell, and multi-color RGB backlighting. It is designed for comfortable and efficient use across various operating systems.

Package Contents

- 1 x Wireless Mouse
- 1 x USB Receiver
- 1 x Charging Cable

Product Features

- **Lightweight Honeycomb Shell:** Constructed from high-quality ABS material with an ergonomic hollow perforated design to reduce weight and enhance heat dissipation, ensuring comfort during extended use.
- **2.4GHz Wireless Connection:** Utilizes advanced 2.4GHz wireless transmission technology for a stable and flexible connection.
- **Multi-Color RGB Backlight:** Equipped with 16 RGB LED lamps offering 4 chroma backlight modes, controllable via a dedicated switch.
- **Adjustable DPI:** Three adjustable DPI levels (1200/1800/2400) for precise cursor control, switchable via the DPI button.
- **Rechargeable Battery:** Features an in-built 800mAh rechargeable battery, eliminating the need for disposable batteries.

- **Power Saving Design:** Automatically enters sleep mode after 5 minutes of inactivity to conserve battery life.
- **Wide Compatibility:** Compatible with Windows 98/2000/ME/NT/XP/VISTA/7/8/10/11 and MAC OS.
- **Durable Switches:** High-quality Omron switches rated for up to 5,000,000 clicks.



Image 1: The FELICON Wireless Lightweight Gaming Mouse X3, showcasing its honeycomb design and RGB lighting.



Image 2: Illustration of the mouse's 2.4G wireless technology and rechargeable capability, shown with a laptop.



Image 3: Multiple views of the mouse highlighting its vibrant rainbow RGB backlight feature.



Image 4: Visual representation of the three adjustable DPI settings: 1200, 1800, and 2400 DPI.

Setup Instructions

1. Charging the Mouse

Before first use, or when the mouse response becomes slow, connect the charging cable to the mouse's charging port and a USB power source. The mouse can be used while charging.

2. Connecting the Mouse

1. Locate the Nano USB receiver in the bottom slot of the mouse.
2. Turn on the mouse using the power switch located on the bottom.
3. Plug the USB receiver into an available USB port on your computer.
4. The mouse should automatically connect. Ensure the connection distance does not exceed 10 meters for optimal performance.



Image 5: Diagram showing the location of the USB receiver in the bottom slot of the mouse.

Operating Instructions

1. Button Functions



Image 6: Labeled diagram of the mouse buttons and switches, including Left Button, Right Button, Scroll Wheel, DPI Button, Forward Button, Backward Button, Power ON/OFF switch, and Backlight Control Button.

- **Left Button:** Standard left-click function.
- **Right Button:** Standard right-click function.
- **Scroll Wheel:** For scrolling up and down.
- **DPI Button:** Press to cycle through DPI settings (1200/1800/2400).
- **Forward Button:** Navigates forward in web browsers or file explorers.
- **Backward Button:** Navigates backward in web browsers or file explorers.

2. DPI Adjustment

Press the **DPI button** (located behind the scroll wheel) to switch between the three available DPI settings: 1200, 1800, and 2400. Each press will cycle to the next setting.

3. RGB Backlight Control

The mouse features a backlight control switch on its bottom. This switch has three positions:

- **OFF:** Mouse power off.
- **ON (middle position):** Mouse power on, backlight off.

- **ON (right position):** Mouse power on, backlight on.

When the backlight is on, you can cycle through 4 different chroma backlight modes by pressing the **right button** on the bottom of the mouse.

4. Power Saving Mode

The mouse will automatically enter sleep mode if there is no operation for 5 minutes. To wake it up, simply press any key on the mouse.

Care and Maintenance

- Clean the mouse regularly with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- Keep the mouse away from liquids and extreme temperatures.
- Store the USB receiver safely when not in use to prevent loss.

Troubleshooting

- **Mouse response is slow or working improperly:** This may be due to a low battery. Charge the mouse using the provided charging cable.
- **Mouse not connecting:** Ensure the mouse is turned on and the USB receiver is securely plugged into your computer's USB port. Try a different USB port if necessary.
- **Intermittent connection:** Ensure the mouse is within 10 meters of the USB receiver and there are no significant obstructions.
- **Backlight not working:** Check the backlight control switch on the bottom of the mouse to ensure it is in the 'ON' position for backlighting.

Technical Specifications

Model	X3 (TD-MICEWHITE)
Connection	2.4G Wireless Transmission
Number of Buttons	6 buttons + 1 power switch + 1 RGB backlight control switch
DPI Settings	1200 / 1800 / 2400
Battery Capacity	800 mAh (Rechargeable)
Operating Systems	Windows 98/2000/ME/NT/XP/VISTA/7/8/10/11, MAC OS
Product Dimensions	4.72 x 1.97 x 1.57 inches (123 x 72 x 46 mm)
Item Weight	5.9 ounces
Movement Detection	Optical

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your

purchase or contact FELICON customer service through their official channels. Keep your purchase receipt for warranty claims.

© 2024 FELICON. All rights reserved.