

## LEGO 41444

# LEGO 41444 Friends Heartlake City Organic Coffee Classic Instruction Manual

Model: 41444

## INTRODUCTION

Welcome to the instruction manual for your LEGO 41444 Friends Heartlake City Organic Coffee Classic building set. This manual provides important information regarding the assembly, operation, maintenance, and safety of your new LEGO set. Please read through these instructions carefully to ensure a proper and enjoyable building and play experience.

The LEGO Heartlake City Organic Coffee set allows builders to create a vibrant coffee shop scene, complete with detailed accessories and mini-doll figures.

## SAFETY INFORMATION

**Attention! Choking hazard. Small elements.** This product contains small parts and is not suitable for children under 36 months (3 years) due to potential choking hazards. Adult supervision is recommended during assembly and play for younger children within the recommended age range.

LEGO building sets are manufactured to high safety standards. Bricks and parts undergo rigorous testing to ensure they meet the highest child safety requirements.

## WHAT'S INCLUDED

The LEGO 41444 Friends Heartlake City Organic Coffee Classic set contains all the necessary LEGO bricks and elements to construct the coffee shop, a smoothie bike, and various accessories, totaling 314 pieces.

- **314 LEGO pieces:** A comprehensive collection of bricks, plates, tiles, and specialized elements for building the detailed coffee shop and its features.
- **3 LEGO mini-dolls:** Includes Mia, Grandpa Marcel, and Granddaughter Ava, enabling diverse role-play scenarios.
- **Cafe Accessories:** Features an oven, blender, coffee machine, sandwich rack, and a variety of food elements to enhance the coffee shop's realism and playability.
- **Smoothie Bike:** A separate, buildable bicycle equipped with a smoothie dispenser, adding an element of mobile service to the play.
- **Building Instructions:** A physical, step-by-step guide is included in the product box to facilitate assembly.



Image: The complete LEGO 41444 Heartlake City Organic Coffee Classic set, showcasing the cafe building, smoothie bike, and the three included mini-doll figures.

## SETUP (ASSEMBLY)

---

Assembly of the LEGO 41444 Heartlake City Organic Coffee Classic set is a straightforward process designed for builders aged 6 and up. Follow the included physical building instructions for the best experience.

1. **Unpack Components:** Carefully open the box and empty all LEGO bags onto a clean, flat surface. It is recommended to sort pieces by color or type to facilitate the building process.
2. **Follow Instructions:** Refer to the step-by-step pictorial instructions provided in the manual. Each step illustrates which pieces are needed and where they should be placed.
3. **Connect Bricks Firmly:** Ensure all LEGO bricks are pressed together firmly to create a stable and durable model.
4. **Build Mini-dolls and Accessories:** Assemble the Mia, Grandpa Marcel, and Ava mini-dolls, as well as the smoothie bike and various cafe accessories, as directed by the instructions.
5. **Verify Completion:** Once all steps are completed, compare your assembled model with the images in the instruction manual to confirm all parts are correctly placed.



Image: An interior view of the assembled LEGO cafe, demonstrating the interaction between mini-dolls and the cafe's features.

## OPERATING (PLAY FEATURES)

---

The LEGO 41444 Heartlake City Organic Coffee Classic set offers several interactive play features once assembled:

- **Cafe Interior:** Arrange the mini-dolls and accessories like the oven, blender, coffee machine, and sandwich rack to simulate a bustling coffee shop environment.
- **Outdoor Seating:** Utilize the outdoor seating area for mini-dolls to enjoy their organic treats.
- **Smoothie Bike:** The smoothie bike can be detached and rolled around Heartlake City, allowing Mia to deliver fresh beverages.
- **Role-Playing:** Encourage imaginative role-playing scenarios, such as taking orders, preparing food and drinks, and serving customers.



Image: The Mia mini-doll operating the smoothie bike, ready to deliver organic drinks.

## MAINTENANCE

---

Proper care and maintenance will help preserve your LEGO set for years of enjoyment.

- **Cleaning:** To clean LEGO bricks, wipe them with a soft, damp cloth. For deeper cleaning, wash them by hand in water no warmer than 104°F (40°C) using a mild detergent. Rinse thoroughly and air dry. Do not use hot water, washing machines, or dryers, as high temperatures can damage the bricks.
- **Storage:** Store your LEGO set in a cool, dry place away from direct sunlight to prevent discoloration and material degradation. Keep small pieces in a container to avoid loss.
- **Disassembly:** If disassembling the set for storage, follow the building instructions in reverse order or carefully separate bricks using a brick separator (not included in this set, but available separately).

## TROUBLESHOOTING

---

If you encounter any issues during the assembly or use of your LEGO set, consider the following:

- **Missing Pieces:** In the rare event of a missing piece, please visit the official LEGO Customer Service website ([www.lego.com/service](http://www.lego.com/service)) to request replacement parts. You will typically need the set number (41444) and the part number (found in the back of the instruction manual).



- **Assembly Difficulties:** Double-check the building instructions for the specific step you are on. Ensure you are using the correct pieces and that they are oriented correctly. Sometimes, a small error in an earlier step can affect later assembly.
- **Loose Connections:** If parts feel loose, ensure they are fully pressed together. LEGO bricks are designed to connect firmly.

## SPECIFICATIONS

---

Attribute	Detail
Model Number	41444
Brand	LEGO
Product Name	Friends Heartlake City Organic Coffee Classic
Number of Pieces	314
Recommended Age	6 years and up
Product Dimensions	2.76 x 13.94 x 7.52 inches (packaging)
Item Weight	1.17 pounds
Release Date	January 1, 2020
Manufacturer	LEGO

## WARRANTY AND SUPPORT

---

LEGO products are known for their quality and durability. While LEGO sets do not typically come with a traditional warranty in the same way electronics do, LEGO Group stands behind its products.

- **Missing or Damaged Parts:** If you find any missing or damaged parts in a new, unopened set, LEGO Customer Service will typically provide replacements free of charge. Visit [www.lego.com/service/replacementparts](http://www.lego.com/service/replacementparts) to request these.
- **General Inquiries:** For any other questions, comments, or concerns regarding your LEGO set, please contact LEGO Customer Service directly. You can find contact information and frequently asked questions on their official website: [www.lego.com/service](http://www.lego.com/service).

Please have your set number (41444) ready when contacting customer service for efficient assistance.