

Razer RZ02-03331500-R3M1

Razer Pro Glide Soft Mouse Mat

Model: RZ02-03331500-R3M1

INTRODUCTION

The Razer Pro Glide is a soft mouse mat designed for enhanced office productivity. It features a thick, high-density rubber foam construction for comfort and durability, a textured micro-weave cloth surface for precise mouse movements, and an anti-slip base to ensure stability during use. This manual provides instructions for setting up, operating, and maintaining your Razer Pro Glide mouse mat.

SETUP

1. **Unpack the Mouse Mat:** Carefully remove the Razer Pro Glide mouse mat from its packaging.
2. **Flatten the Mat:** If the mat is rolled, gently unroll it and allow it to lie flat on your desk surface. It may take a short period for the mat to completely flatten.
3. **Positioning:** Place the mouse mat on a clean, dry, and flat surface where you intend to use your mouse. The anti-slip rubber base will help secure the mat in place.

TEXTURED MICRO-WEAVE CLOTH SURFACE

For quick, accurate mouse movements



Image: The anti-slip base ensures the mat remains stable on your desk.

OPERATING

The Razer Pro Glide is designed for immediate use. Simply place your mouse on the mat and begin your work or gaming activities. The textured micro-weave cloth surface is optimized for all mouse sensors, providing precise tracking and smooth gliding for accurate and efficient movements.

- **Enhanced Control:** The surface texture allows for quick and accurate mouse movements, crucial for productivity tasks.
- **Comfort:** The 3mm thick, high-density rubber foam provides a comfortable cushioning effect for your hand and wrist during extended use.
- **Stability:** The anti-slip rubber base prevents the mat from shifting, ensuring consistent performance.

ANTI-SLIP BASE

To keep the mat in place



Image: The textured micro-weave cloth surface provides optimal tracking for your mouse.

MAINTENANCE

To ensure the longevity and optimal performance of your Razer Pro Glide mouse mat, follow these cleaning guidelines:

- **Spot Cleaning:** For minor spills or dirt, use a soft, damp cloth with a small amount of mild soap. Gently wipe the affected area.
- **Avoid Harsh Chemicals:** Do not use harsh detergents, bleach, or abrasive cleaners, as these can damage the mat's surface and materials.
- **Air Dry:** After cleaning, allow the mat to air dry completely before reuse. Do not machine wash or tumble dry.
- **Regular Dusting:** Periodically dust the surface with a dry, soft cloth to prevent dust buildup.

TROUBLESHOOTING

- **Mat Not Lying Flat:** If the mat does not immediately lie flat after unrolling, place heavy, flat objects (like

books) on the edges for a few hours to help it flatten.

- **Mouse Tracking Issues:** Ensure the mouse mat surface is clean and free of debris. If issues persist, try cleaning your mouse sensor.
- **Mat Slipping:** Verify that the desk surface beneath the mat is clean and dry. The anti-slip base requires a clean surface for optimal grip.

SPECIFICATIONS

Feature	Detail
Model Number	RZ02-03331500-R3M1
Dimensions (L x W)	14.17" x 10.83" (360 mm x 275 mm)
Thickness	3 mm
Material	High-density rubber foam (base), Textured micro-weave cloth (surface)
Color	Grey
Special Features	Durability, Non-slip base
Weight	290 Grams

THICK, HIGH-DENSITY RUBBER FOAM

For greater comfort, durability and consistent control



Image: The thick, high-density rubber foam provides comfort and durability.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Razer website or contact Razer customer service directly. Keep your purchase receipt for warranty claims.

Razer Official Website: www.razer.com