



Manuals.plus /

› GLPE /

› GLPE LED Rope Lights Indoor/Outdoor with USB Power, 66Ft (2x33Ft) 200 LED String Lights with Remote, 16 Color Changing (Model: PR-01) - Instruction Manual

GLPE PR-01

GLPE LED Rope Lights Instruction Manual

Model: PR-01 | Brand: GLPE

1. SAFETY INFORMATION

Please read all instructions carefully before using the GLPE LED Rope Lights. Retain this manual for future reference.

- Keep the product out of reach of children.
- The rope lights are IP65 waterproof, suitable for outdoor use. However, the USB connector is **not waterproof** and must be protected from moisture and rain.
- Do not cut, modify, or attempt to repair the lights. This may damage the product and void the warranty.
- Use only with a compatible 5V DC USB power source.
- Unplug the lights from the power source when not in use, during cleaning, or before performing any maintenance.
- Avoid exposing the lights to extreme temperatures or direct flame.

2. PACKAGE CONTENTS

Verify that all items are included in your package:

- 2 x 33ft (Total 66ft) LED Rope Lights with USB Connector
- 2 x Remote Controls
- User Manual (this document)

Note: A USB power adapter (plug) is not included.

3. SPECIFICATIONS

Brand	GLPE
Model Number	PR-01
Length	66 Feet (2 x 33 Feet)
Number of LEDs	200 (100 per 33ft string)
Color Options	16 Color Changing (RGB)
Lighting Modes	8 Modes (e.g., Waves, Strobe, Twinkle, Fade, Jump)
Power Source	USB Powered (5V DC)
Waterproof Rating	IP65 (Rope lights only, USB connector is NOT waterproof)
Control Method	Remote Control, USB Button
Timer Function	4H, 6H, 8H, Timer Off
Material	Polyvinyl Chloride (PVC)
Average Life	50,000 Hours

4. SETUP

- 1. Unpack the Lights:** Carefully remove the LED rope lights and remote controls from the packaging. Gently uncoil the lights to avoid tangling.
- 2. Connect to Power:** Insert the USB connector of the rope lights into a compatible 5V USB power source. This can be a phone charger (not included), a power bank, a computer's USB port, or any other 5V USB outlet.
- 3. Position the Lights:** Place or hang the lights in your desired indoor or outdoor location. Ensure the USB connector is in a dry area or protected from water if used outdoors. The 10ft lead wire provides flexibility for placement.



Image: GLPE LED Rope Lights, 66ft (2x33ft) USB Powered, coiled and ready for setup.

This advertisement features a background image of a wooden pergola at night, illuminated with the LED rope lights. In the top left corner, there is an orange square icon with a white umbrella and raindrops. The text 'IP68 waterproof' is written in large, bold, orange letters, with 'Perfect For Outdoor Use' below it in white. At the bottom, there are four white rounded square icons with teal text: a color wheel for '18 Color Changing', a 2x2 grid for '8 Lighting Modes', a speedometer for '4 Flash Speeds', and a clock for 'Timer Function'.

Image: Close-up of the USB connector for the GLPE LED Rope Lights, highlighting its power input.

5. OPERATING INSTRUCTIONS

5.1 Using the Remote Control

The included remote control allows for full customization of your GLPE LED Rope Lights. Ensure the remote has a clear line of sight to the USB receiver for optimal performance.



Image: Detailed layout of the remote control with buttons for power, color selection, modes, speed, and timer functions.

- **ON/OFF:** Press to turn the lights on or off.
- **Color Selection:** Choose from 16 static colors using the dedicated color buttons.
- **Mode Selection:** Cycle through 8 dynamic lighting modes (e.g., Waves, Strobe, Twinkle, Fade, Jump, Asyn Fade, Asyn Jump, Auto) using the mode buttons.
- **Speed Adjustment:** Adjust the speed of dynamic modes using the 'SPEED' buttons.
- **Timer Function:** Set the lights to automatically turn off after 4 hours (4H), 6 hours (6H), or 8 hours (8H). Select 'TIMER OFF' to disable the timer.

5.2 Manual Control

A button on the USB connector allows for basic control if the remote is unavailable:

- Press the button to cycle through different colors and lighting modes.
- Hold the button to turn the lights off.

Video: Official GLPE-US demonstration of the LED rope lights, showcasing various colors and modes, and highlighting their indoor/outdoor versatility.

6. MAINTENANCE

- **Cleaning:** Gently wipe the rope lights with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, coil the lights neatly and store them in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the lights and cables for any signs of damage. Discontinue use if any damage is found.

7. TROUBLESHOOTING

- **Lights not turning on:**
 - Ensure the USB connector is securely plugged into a functional 5V power source.
 - Check if the power source itself is working correctly.
 - Verify the remote control battery is not depleted.
- **Remote control not responding:**
 - Ensure there is a clear line of sight between the remote and the USB receiver.
 - Replace the remote control battery if it is old or depleted.
 - Try controlling the lights using the button on the USB connector to confirm the lights are functional.
- **Inconsistent colors or modes:**
 - Unplug the lights from the power source, wait a few seconds, and then plug them back in to reset.

8. WARRANTY AND SUPPORT

For warranty information, technical support, or any product-related inquiries, please refer to the contact information provided with your purchase or visit the official GLPE website.