Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Soundcore A3908

Soundcore Life Note True Wireless Earbuds User Manual

Model: A3908

Brand: Soundcore

Introduction

Welcome to the user manual for your Soundcore Life Note True Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with advanced features for calls, music, and convenience. Please read this manual thoroughly to ensure proper use and maintenance of your device.

Key Features

- **Crystal-Clear Calls:** Equipped with 4 microphones and cVc noise reduction technology to enhance voice clarity and reduce background sounds during calls.
- **Extended Playtime:** Enjoy up to 7 hours of playback on a single charge, with a total of 40 hours of playtime using the included charging case.
- **Superior Sound Quality:** Graphene drivers deliver a wider soundstage with exceptional accuracy and clarity. Features aptX technology for low-latency, high-quality audio streaming and BassUp Technology for enhanced bass frequencies.
- **Water-Resistant Design:** IPX5-rated protection defends your earbuds against liquid damage, making them suitable for active use.
- **Seamless Connectivity:** Bluetooth 5.0 ensures an ultra-stable connection for skip-free streaming.
- **USB-C Charging:** Convenient and fast charging for the case using the included USB-C cable.
- **Comfortable Fit:** Multiple sizes of EarTips are included to help you find the perfect secure and comfortable fit.
- **Mono or Stereo Mode:** Effortlessly switch between using a single earbud or both.

Package Contents

- Soundcore Life Note True Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Multiple Sizes of EarTips (S, M, L, XL, XS)
- Quick Start Guide
- Safety Card

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case.
2. Connect the USB-C cable to the charging port on the case and to a power source.
3. The LED indicators on the case will show charging status. Once fully charged, the indicators will turn solid.
4. A full charge for the case provides multiple recharges for the earbuds, extending total playtime to 40 hours.



Image: Soundcore Life Note Earbuds in their charging case.

2. Pairing with Your Device

The earbuds use PUSH AND GO technology for automatic connection.

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "Soundcore Life Note" in the list of available Bluetooth devices and select it to connect.

4. Once connected, the earbuds will automatically reconnect to the last paired device when removed from the case.



Image: Individual Soundcore Life Note Earbuds.

3. Choosing the Right EarTips

For optimal sound quality and comfort, select the EarTips that best fit your ears.

- Try different sizes to find the ones that create a secure seal in your ear canal.
- A good seal will improve bass response and noise isolation.

Operating Your Earbuds

Controls

The Soundcore Life Note earbuds feature touch controls for easy management of audio and calls.

Function	Action	Earbud
Play/Pause	Tap 2 times	Right
Next Track	Tap 2 times	Left
Answer/End Call	Tap 2 times	Left/Right
Reject Call	Press and hold for 2 seconds	Left/Right
Activate Voice Assistant	Press and hold for 2 seconds	Right

Mono and Stereo Mode

You can use either earbud independently (Mono Mode) or both together (Stereo Mode).

- To use a single earbud, simply take one out of the charging case. It will automatically connect to your device.
- To switch to stereo mode, take the other earbud out of the case. They will automatically pair with each other.

Official Product Video

Your browser does not support the video tag.

Video: An official overview of the Soundcore Life Note True Wireless Earbuds, highlighting their features and design.

Maintenance

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **EarTips:** Remove and clean the EarTips periodically with water and mild soap. Ensure they are completely dry before reattaching.
- **Water Resistance:** The earbuds are IPX5 water-resistant, meaning they can withstand splashes and sweat. Do not submerge them in water or expose them to prolonged periods of moisture. Ensure the charging port is dry before charging.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

Troubleshooting

Problem	Solution
Earbuds not pairing	◦ Ensure both earbuds are in the charging case and have sufficient charge. ◦ Close the case, wait 5 seconds, then open it again to re-enter pairing mode. ◦ On your device, forget "Soundcore Life Note" from your Bluetooth settings and try pairing again. ◦ If issues persist, reset the earbuds (refer to Soundcore support for specific reset instructions if not in manual).
Only one earbud playing audio	◦ Place both earbuds back into the charging case, close the lid, and then open it again. ◦ Ensure both earbuds are charged. ◦ Check if the earbuds are in Mono Mode. If so, take the other earbud out to switch to Stereo Mode.
Poor sound quality	◦ Ensure the EarTips provide a secure seal in your ear canal. Try different sizes. ◦ Clean the earbud nozzles and EarTips to remove any debris. ◦ Move closer to your connected device to avoid interference.
Charging case not charging	◦ Ensure the USB-C cable is securely connected to both the case and the power source. ◦ Try a different USB-C cable or power adapter. ◦ Clean the charging port on the case.

Specifications

Feature	Detail
Model Name	A3908
Connectivity Technology	Bluetooth 5.0, Wireless
Audio Driver Type	Dynamic Driver (Graphene)
Battery Life (Earbuds)	7 Hours
Total Playtime (with Charging Case)	40 Hours
Charging Port	USB-C
Microphones	4 (with cVc Noise Reduction)
Water Resistance Level	IPX5
Control Type	Touch Control, Media Control
Product Dimensions	3.15 x 2.05 x 1.18 inches
Item Weight	5.8 ounces (0.17 Kilograms)
Color	White
Frequency Range	20Hz - 20kHz

Warranty and Support

Soundcore products come with a limited warranty. For detailed warranty information, technical support, or customer service inquiries, please visit the official Soundcore website or contact their customer support team.
Website: us.soundcore.com

© 2024 Soundcore. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08G8BHBBP

More documents and user manuals: **https://manuals.plus/**