



Manuals.plus /

› Easytry123 /

› Easytry123 Replacement Air Conditioner Remote Control Instruction Manual

Easytry123 RG32A/E

Instruction Manual for Easytry123 Replacement Air Conditioner Remote Control

Model: RG32A/E

1. INTRODUCTION

This manual provides essential information for the proper use and maintenance of your Easytry123 replacement remote control for Midea, Olmo, VIOTTO, NOMA, and Mirage RG32A/E series air conditioners. This remote is designed as a direct infrared replacement for your original unit.

Important Note: Please ensure your original remote control is identical in appearance and model number to the remote shown in this manual and on the product listing. This replacement remote may not offer all functions of your original remote if there are significant differences.

2. PRODUCT OVERVIEW

The Easytry123 replacement remote control features an ergonomic design with clearly labeled buttons for common air conditioner functions.



Figure 2.1: Front view of the Easytry123 replacement remote control, displaying the power, mode, sleep, swing, timer, energy saver, one touch, and fan/speed buttons.



Figure 2.2: Angled view of the remote control, providing a better perspective of its design and button layout.

3. SETUP: BATTERY INSTALLATION

Your remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) ends align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: Always replace both batteries at the same time. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote will not be used for an extended period.



Figure 3.1: Rear view of the remote control with the battery cover removed, illustrating the battery compartment.

4. OPERATING INSTRUCTIONS

This infrared replacement remote operates your air conditioner by sending signals directly to the unit. Point the remote control directly at the air conditioner's receiver when pressing buttons.

Button Functions:

- **POWER:** Turns the air conditioner ON or OFF.
- **MODE:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **SLEEP:** Activates or deactivates the sleep mode for comfortable overnight operation.
- **SWING:** Controls the vertical swing of the air conditioner's louvers.

- **TIMER:** Sets the timer for automatic ON/OFF operation.
- **ENERGY SAVER:** Activates or deactivates energy-saving functions.
- **ONE TOUCH:** Activates a pre-set comfort setting with a single press.
- **FAN/SPEED:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **▲ / ▼ (Up/Down Arrows):** Adjusts temperature settings or navigates menu options.

Note: The exact functionality of each button may vary slightly depending on your specific air conditioner model. Refer to your air conditioner's original manual for detailed explanations of each function.

5. COMPATIBILITY

This remote control is specifically designed as a replacement for air conditioner models Midea RG32A/E, Olmo RG32A/E, VIOTTO RG32A/E, NOMA RG32A/E, and Mirage RG32A/E. It is crucial to verify that your original remote control matches the appearance of this replacement remote to ensure full compatibility.

If your air conditioner model number is not explicitly listed in the product title or if your original remote differs significantly in appearance, this replacement remote may not be fully compatible or may not offer all desired functions.

We Sell

Replace



- NOT Easy Broken
- Easy Hold
- NOT Easy Lost
- Easy to Operate
- Cheap Battery
- Reliable Quality
- Long Life




Figure 5.1: Visual comparison highlighting the replacement remote's design similarity to the original, indicating its intended use as a direct replacement.

6. TROUBLESHOOTING

- **Remote not responding:**
 - Ensure batteries are installed correctly with proper polarity.
 - Replace old batteries with new AAA batteries.
 - Point the remote directly at the air conditioner's infrared receiver.
 - Check for any obstructions between the remote and the air conditioner.
- **Certain functions not working:**
 - This replacement remote may not support all advanced or unique functions of your original air conditioner remote if they are not standard features or if the original remote had a different button layout.
 - Verify that your air conditioner model is listed as compatible.
- **Intermittent operation:**
 - Weak batteries can cause intermittent signals. Replace them.
 - Ensure there is no strong light source (like direct sunlight) interfering with the infrared signal.

7. SPECIFICATIONS

Brand	Easytry123
Model	RG32A/E (Replacement)
Compatible Devices	Midea, Olmo, VIOTTO, NOMA, Mirage RG32A/E Air Conditioners
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Power Source	2 x AAA Batteries (not included)
Special Feature	Ergonomic design, Direct replacement

8. MAINTENANCE

To ensure the longevity and proper functioning of your remote control:

- Keep the remote clean by wiping it with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- Avoid dropping the remote or subjecting it to strong impacts.
- Do not expose the remote to extreme temperatures, direct sunlight, or high humidity.
- Remove batteries if the remote will not be used for an extended period to prevent battery leakage.

9. SUPPORT & CONTACT

If you encounter any issues or have questions regarding your Easytry123 replacement remote control, please do not hesitate to contact us. We recommend messaging us freely first for any doubts or concerns.

Please refer to your purchase platform or the seller's information for direct contact methods.

