

- Manuals.plus /
- > [AEG](#) /
 - > AEG RDB424E1AX Free-Standing Double Door Fridge User Manual

AEG RDB424E1AX 925992224

AEG RDB424E1AX Free-Standing Double Door Fridge User Manual

Model: RDB424E1AX 925992224 | Brand: AEG

PRODUCT OVERVIEW

The AEG RDB424E1AX Free-Standing Double Door Fridge is designed to offer reliable and efficient food preservation. This model features a top freezer and a bottom refrigerator compartment, providing ample storage for various food items. Key features include LowFrost technology to minimize ice build-up, energy-efficient LED lighting, and an anti-fingerprint stainless steel coating for easy maintenance. The appliance is built for durability and long-lasting performance.



Figure 1: Front view of the AEG RDB424E1AX Free-Standing Double Door Fridge in stainless steel silver.



Figure 2: Detail of the door handle and side profile, showcasing the anti-fingerprint stainless steel finish.

SETUP AND INSTALLATION

This AEG refrigerator is a free-standing unit, designed for easy placement in your kitchen. Proper installation ensures optimal performance and longevity.

Unpacking and Placement

- Carefully unpack the appliance and remove all packaging materials.
- Ensure adequate ventilation space around the unit as per the installation diagram.
- The appliance is equipped with adjustable feet at the front to ensure stability and proper leveling on uneven surfaces.
- The door hinge is located on the right side but can be changed to the left by a qualified technician if required for your kitchen layout.

Electrical Connection

Before connecting the appliance, ensure your power supply matches the specifications. The refrigerator operates on 230 Volts and has a wattage of 110 watts.

Dimensions

The overall dimensions of the refrigerator are approximately 21.54 x 21.65 x 56.46 inches (Width x Depth x Height). Refer

to the diagram below for detailed measurements and clearance requirements.




Figure 3: Detailed dimensions and clearance requirements for installation.

OPERATING INSTRUCTIONS

Familiarize yourself with the controls and features to optimize the performance of your AEG refrigerator.

Temperature Control

The appliance features electronic temperature control, allowing precise adjustment of the internal temperature. The control panel is located inside the refrigerator compartment. Adjust the setting to your desired cooling level. For optimal food preservation, a setting of 4°C is generally recommended for the refrigerator section.



Figure 4: Electronic temperature control panel.

Internal Organization

The refrigerator compartment includes three height-adjustable glass shelves, an egg tray for 6 eggs, and a dedicated fruit and vegetable drawer. The freezer section features FlexiSpace, with removable glass shelves, allowing for flexible storage of larger items.



Figure 5: Interior view of the refrigerator, showcasing adjustable shelves and storage compartments.

Lighting

The interior is illuminated by energy-efficient and durable LED lighting, providing clear visibility throughout the refrigerator compartment.

MAINTENANCE

Regular maintenance helps to keep your AEG refrigerator operating efficiently and extends its lifespan.

Cleaning

The exterior features an anti-fingerprint stainless steel coating, which reduces visible smudges and makes cleaning easier. For general cleaning, use a soft cloth with mild detergent and water. Avoid abrasive cleaners or solvents.

Defrosting

This model incorporates LowFrost technology, which significantly reduces the formation of ice and frost in the freezer compartment. This means defrosting is required less frequently and is a quicker process when needed. The defrost system is manual. Refer to the full user manual for detailed defrosting instructions.



Figure 6: Rear view of the appliance, highlighting the compressor and cooling system.

TROUBLESHOOTING

Should you encounter any issues with your appliance, please refer to the comprehensive troubleshooting guide in the full user manual. Common issues and their solutions are typically covered there. If the problem persists, contact AEG customer support.

SPECIFICATIONS

Feature	Detail
Brand	AEG
Model Number	RDB424E1AX 925992224
Capacity	205 Liters
Configuration	Freezer-on-Bottom
Color	Silver

Feature	Detail
Product Dimensions (WxDxH)	21.54 x 21.65 x 56.46 inches
Item Weight	92.4 pounds (42 Kilograms)
Voltage	230 Volts
Wattage	110 watts
Sound Level	39 dB
Defrost System	Manual (with LowFrost technology)
Number of Doors	2
Special Features	5-year warranty on compressor, Adjustable front feet, Reversible door hinge, Electronic temperature control, Anti-fingerprint coating, FlexiSpace.
Included Components	3 height-adjustable glass shelves, Egg tray, Flexi-Space removable freezer shelves, Fruit and vegetable drawer.

WARRANTY AND SUPPORT

Warranty Information

AEG provides a **5-year warranty on the inverter compressor** of this appliance. This warranty covers the cost of repairs, transport, gas extraction and refilling, general maintenance, and service related to the compressor.

Customer Support

For any inquiries, technical assistance, or warranty claims, please contact AEG customer support. You can find contact details on the official AEG website or through your retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08G8WWXT3>

More documents and user manuals: <https://manuals.plus/>