

BLACK+DECKER BD60016

BLACK+DECKER BD60016 6-Bottle Thermoelectric Wine Cooler Instruction Manual

Model: BD60016

PRODUCT OVERVIEW

The BLACK+DECKER BD60016 6-Bottle Thermoelectric Wine Cooler is designed to store up to 6 bottles of wine at optimal temperatures. This compact unit features thermoelectric cooling for energy efficiency and low vibration, a clear triple-pane glass door, two chrome full-length racks, and a convenient interior light. It is also equipped with adjustable leveling legs and a recessed door handle for ease of use and placement. The unit is ETL safety certified.

- **Capacity:** Stores up to 6 standard wine bottles.
- **Cooling Technology:** Thermoelectric for quiet, low-vibration operation.
- **Temperature Range:** 46°F to 65°F (8°C to 18°C).
- **Door:** Clear triple-pane glass for insulation and visibility.
- **Shelving:** 2 chrome full-length racks.
- **Features:** Interior light, adjustable leveling legs, recessed door handle.
- **Dimensions:** 10.24" W x 20.08" D x 15.28" H.
- **Weight:** 19.1 lbs.

SETUP AND INSTALLATION

Before operating your wine cooler, please follow these setup instructions:

1. **Unpacking:** Carefully remove all packaging materials. Ensure all components are present.
2. **Handle Installation:** Attach the recessed door handle. This typically involves removing two screws from behind the door gasket, aligning the handle, and re-securing the screws.
3. **Placement:** Place the wine cooler on a flat, stable surface. Ensure adequate ventilation around the unit. Avoid direct sunlight or heat sources.
4. **Leveling:** Adjust the leveling legs at the bottom of the unit to ensure it is perfectly level. This helps with proper operation and door sealing.
5. **Initial Power-On:** Plug the unit into a grounded electrical outlet. Allow the cooler to reach its set temperature before loading bottles.

Triple Pane Glass Door



Image: The BLACK+DECKER BD60016 wine cooler with its handle installed, ready for use.

Adjustable Leveling Legs




Image: Close-up of the adjustable leveling legs on the wine cooler, used to ensure stability and proper function.

OPERATING INSTRUCTIONS

Your wine cooler features intuitive digital controls for easy temperature management and lighting.

Temperature Control:

The temperature can be set between 46°F and 65°F (8°C and 18°C). Use the up and down arrow buttons on the control panel to adjust the desired temperature. The digital display will show the current internal temperature.

Interior Light:

A soft interior light illuminates the contents of your wine cooler. Press the light button on the control panel to turn the light on or off.

Temperature Unit Conversion:

Switch between Fahrenheit (°F) and Celsius (°C) display by pressing the °F/°C button on the control panel.

Electronic Control with LED Display



46° - 65° range

Image: Close-up of the electronic control panel with LED display, showing temperature adjustment buttons and light control.

Chrome Shelving



Image: The interior of the wine cooler illuminated by a blue LED light, highlighting the wine bottles on the racks.

LOADING AND STORAGE

The wine cooler is equipped with chrome racks designed to hold standard wine bottles securely.

- **Rack Capacity:** Each of the two chrome racks can hold multiple standard-sized wine bottles.
- **Flexible Storage:** Racks can be removed to accommodate larger or irregularly shaped bottles, though this may reduce the total bottle capacity.
- **Bottle Orientation:** Store bottles horizontally to keep corks moist and prevent air from entering the bottle.

Convenient Interior Light



Image: A hand demonstrating the ease of pulling out a chrome wine rack from the cooler for loading or unloading bottles.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your wine cooler.

- **Cleaning:** Disconnect the power before cleaning. Use a soft cloth with a mild detergent and water to clean the interior and exterior surfaces. Avoid abrasive cleaners.
- **Door Gasket:** Regularly check and clean the door gasket to ensure a tight seal, which is crucial for maintaining internal temperature.
- **Dust Removal:** Periodically clean the rear ventilation grilles to prevent dust buildup, which can affect cooling efficiency.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	BLACK+DECKER
Model Info	BD60016
Item Weight	17.6 pounds
Product Dimensions	20.08" D x 10.24" W x 15.28" H
Capacity	0.7 Cubic Feet (6 Bottles)
Annual Energy Consumption	90 Watts
Installation Type	Freestanding
Special Features	Thermoelectric
Color	Black
Voltage	115 Volts
Wattage	65 KW
Racks	2 Chrome Slide-out Wine Racks
Defrost System	Automatic
Door Material Type	Glass
Certification	ETL Safety Certified

WARRANTY AND SUPPORT

The BLACK+DECKER BD60016 6-Bottle Thermoelectric Wine Cooler comes with a one-year warranty covering parts and labor. For warranty claims or technical support, please refer to the contact information provided in your product packaging or visit the official BLACK+DECKER website.

OFFICIAL PRODUCT VIDEOS

B+D BD60016 6 Bottle Wine Cellar Overview

Your browser does not support the video tag.

Video: An official overview of the BLACK+DECKER BD60016 6-Bottle Wine Cellar, showcasing its features and design.

Wine Cooler Refrigerator with Glass Door

Your browser does not support the video tag.

Video: A demonstration of a wine cooler refrigerator with a glass door, highlighting its aesthetic and functional aspects.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question