

- Manuals.plus /
- › Brookstone /
- › Brookstone Big Blue Go Party Speaker Instruction Manual

Brookstone BKS800

Brookstone Big Blue Go Party Speaker User Manual

Brand: Brookstone | Model: BKS800

PRODUCT OVERVIEW

The Brookstone Big Blue Go Party Speaker is a high-powered, portable Bluetooth speaker designed for both indoor and outdoor use. Featuring 60-watt RMS drivers for incredible sound and extreme bass, it includes a mixed-color LED light show with three selectable modes (Chill, Mood, Party). Its IPX5 waterproof rating makes it suitable for poolside or beach use. The speaker offers easy linking for endless stereo sound, a built-in mic input for karaoke, and a convenient wireless charging pad for smartphones. With a durable design and long battery life, it's built to deliver powerful audio and vibrant visuals for any gathering.



Front view of the Brookstone Big Blue Go Party Speaker, showcasing its dual speakers and vibrant LED lighting.

WHAT'S IN THE BOX

- Brookstone Big Blue Go Party Speaker
- Charging Cable
- Auxiliary Cable
- User Manual

SETUP

Initial Charging

Before first use, fully charge your speaker for approximately 15 hours. The battery life is up to 20 hours depending on usage.

Powering On/Off

To power on the speaker, press and hold the central button on the front panel until the lights activate and you hear an audible prompt. To power off, press and hold the same button.

Placement

The speaker can be placed vertically or horizontally. Both orientations feature strong rubber grips on the sides to ensure stability and prevent slipping.

IPX5, LINKING & PORTABLE



EASY-LINK

Link two Party speakers to create a wireless stereo environment.



IPX5

Water splash resistance



PORTABILITY

Up to 10 hours playing time

The speaker is designed for versatile placement, featuring rubber grips for stability in both vertical and horizontal positions.

OPERATING INSTRUCTIONS

Bluetooth Pairing

Press the Bluetooth button on the top panel to enter pairing mode. The speaker will announce "Connected" once successfully paired with your device. It quickly recognizes previously paired devices.

LED Light Show

The speaker features a mixed-color LED light show with three selectable modes: Chill, Mood, and Party. Press the light bulb button on the top panel to cycle through the modes. The Party mode synchronizes with the rhythm of your music.



The speaker's LED lights offer various modes to enhance your listening experience.

Audio Controls

Adjust volume using the '+' and '-' buttons on the top panel. Fine-tune your audio experience with dedicated knobs on the back for Bass, Treble, Mic volume, and Echo effects.



SERIOUS HI-RES SOUND

Fill any room with pure, distortion-free sound with 60W of power, (2x) 5.25" Subwoofers, (2x) 2" Tweeters and (2x) 5x7" Passive Radiators.

The speaker delivers serious hi-res sound with 60W of power, dual 5.25" subwoofers, dual 2" tweeters, and dual 5x7" passive radiators.

Microphone Input

Connect a microphone to the dedicated mic input on the back panel for karaoke or public speaking. Adjust mic volume and echo using the corresponding knobs.



MICROPHONE INPUT

Grab a microphone and MC the party or belt out your favorite Karaoke tunes.

Smart-tablet stand is perfect for reading lyrics.

Enjoy karaoke nights by connecting a microphone to the speaker.

Wireless Charging Pad

Place your Qi-compatible smartphone on the integrated wireless charging pad located on the top of the speaker to charge your device while enjoying music.

DESIGNED FOR SMART DEVICES

Charge your compatible smart device using the seamlessly integrated Qi wireless charging mat or USB port.


WIRELESS
CHARGING MAT



The speaker features a convenient wireless charging pad for your smartphone.

Linking Multiple Speakers

Connect endless amounts of Brookstone Big Blue GO Speakers for intense sound quality and volume. Simply press the link button on both speakers to create a right and left channel for a true wireless stereo experience.

Official Product Video

Watch the official product video for a comprehensive overview of the Brookstone Big Blue Go Party Speaker's features and capabilities.

MAINTENANCE

Water Resistance

The speaker is IPX5 waterproof, meaning it is resistant to water splashes. This makes it suitable for outdoor use near pools or at the beach. However, it should not be submerged in water.

Cleaning

Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.

TROUBLESHOOTING

No Power/Not Turning On

- Ensure the speaker is fully charged.
- Press and hold the power button for several seconds.

Bluetooth Pairing Issues

- Ensure Bluetooth is enabled on your device and the speaker is in pairing mode.
- Move your device closer to the speaker.
- Forget the speaker from your device's Bluetooth list and try pairing again.

Sound Distortion

- Reduce the volume on both the speaker and your connected device.
- Adjust the Bass and Treble controls on the back of the speaker.

Resetting the Speaker

If you experience persistent issues, locate the reset button on the back panel (often a small pinhole) and use a thin object (like a paperclip) to press it. This will restore factory settings.

SPECIFICATIONS

Feature	Detail
Brand	Brookstone
Model Name	Big Blue High Power
Model Number	BKS800
Speaker Type	Bluetooth
Special Feature	Multiroom, Stereo pairing
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Speaker Maximum Output Power	100 Watts
RMS Power	60 Watts
Battery Life	20 Hours

Feature	Detail
Charging Time	15 Hours
Water Resistance Level	IPX5 (Waterproof)
Product Dimensions	10"D x 10"W x 15"H
Item Weight	6 Pounds
Material	Metal
Color	Black
UPC	680079459093



Detailed dimensions of the speaker.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Brookstone website. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08G9X83X5>

More documents and user manuals: **<https://manuals.plus/>**