

IRIS USA PCF-SC15T

IRIS USA WOOZOO Air Circulator Fan

MODEL: PCF-SC15T

Important Safety Instructions

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Always unplug the fan before cleaning or performing any maintenance.
- Do not immerse the fan in water or other liquids.
- Keep the fan away from open flames, heat sources, and flammable materials.
- Ensure the power cord is not damaged and is placed where it cannot be tripped over.
- Do not insert fingers or any objects into the fan grille.
- This appliance is for indoor use only.
- Supervise children when the fan is in operation.

Product Overview

The IRIS USA WOOZOO Air Circulator Fan (Model PCF-SC15T) is a compact and powerful fan designed to maximize airflow and provide comfortable cooling in various indoor environments. It features multiple speed settings, oscillation capabilities, and a convenient remote control for ease of use.



Figure 1: WOZZOO Air Circulator Fan with Remote Control

Package Contents

- WOZZOO Air Circulator Fan (Model PCF-SC15T)
- Remote Control (Battery Included)
- Instruction Manual

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Placement:** Place the fan on a stable, flat surface in the desired location. Ensure there is adequate space around the fan for proper air circulation and oscillation.
3. **Power Connection:** Plug the power cord into a standard 120VAC, 60Hz electrical outlet. The cord length is approximately 5.9 feet.
4. **Remote Control:** The remote control comes with a battery pre-installed. If needed, replace the battery according to the instructions on the remote.

Operating Instructions

The fan can be operated using the control panel on the base unit or the included remote control.

Control Panel Functions

- **Power Button ():** Press to turn the fan ON or OFF.
- **Speed Adjustment (◀/▶):** Adjusts between 5 fan speeds. The lowest setting is whisper quiet (below 28dB).
- **Timer Button ():** Sets the auto-off timer for 1, 2, or 4 hours.
- **Natural Breeze Mode ():** Activates a natural breeze setting that alternates airflow strength to mimic outdoor breezes.
- **Horizontal Oscillation (↔):** Activates left and right oscillation.
- **Vertical Oscillation (⬆/⬆):** Activates up and down oscillation.
- **All-Direction Oscillation:** Press both Horizontal and Vertical oscillation buttons to activate simultaneous movement.

Remote Control Functions

The remote control duplicates all functions available on the control panel, allowing for convenient operation from a distance.



NATURAL BREEZE

Setting replicates breeze patterns
by alternating airflow strength.



Figure 2: Natural Breeze setting replicates varying airflow patterns.



Figure 3: Fan demonstrating 6 vertical tilt positions and horizontal oscillation.

Video 1: This video demonstrates the compact size and powerful cooling capabilities of the WOZZOO fan, highlighting its various features and quiet operation.

Video 2: This video showcases the fan's ability to oscillate in multiple directions and its various speed settings, providing a comprehensive view of its functionality.

Maintenance

Regular cleaning ensures optimal performance and extends the life of your fan.

- **Cleaning:** Unplug the fan from the power outlet. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Dust Removal:** Use a vacuum cleaner with a brush attachment or compressed air to remove dust from the grilles.
- **Storage:** When not in use, store the fan in a cool, dry place, preferably in its original packaging.

Troubleshooting

Problem	Possible Cause	Solution
Fan does not turn on	Not plugged in; Power outage; Faulty outlet	Ensure plug is securely in outlet; Check circuit breaker; Try a different outlet.
Remote control not working	Dead battery; Obstruction between remote and fan sensor	Replace remote battery; Remove any obstructions; Ensure remote is aimed at the fan's sensor.
Unusual noise during operation	Dust buildup; Loose parts	Clean fan grilles; Contact customer support if noise persists.

Specifications

Feature	Detail
Model Name	PCF-SC15T
Dimensions (D x W x H)	8.27" x 8.27" x 11.42"
Item Weight	3.53 ounces (approx. 100 grams)
Power Source	Corded Electric
Wattage	50 watts
Voltage	5 Volts (Input: 120VAC, 60Hz)
Noise Level	28 Decibels (on low setting)
Number of Power Levels	5
Control Method	Remote
Special Feature	Oscillating (Horizontal & Vertical)
Cable Length	5.9 Feet
Material	Plastic (Polypropylene)
UPC	762016484280

Warranty and Support

This IRIS USA WOOZOO Air Circulator Fan is covered by a Manufacturer's 5-Year Warranty.

For warranty claims, technical support, or any questions regarding your product, please contact IRIS USA customer service.

Contact information can typically be found on the official IRIS USA website or on your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question