Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fafeicy Fafeicy gk0zm8ec5h

Fafeicy 16.8V Tile Vibrator User Manual

Model: Fafeicy gk0zm8ec5h
Brand: Fafeicy

1. Introduction and Product Overview

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your Fafeicy 16.8V Tile Vibrator. Please read this manual thoroughly before using the product to ensure proper handling and to prevent damage or injury.



Figure 1: Fafeicy 16.8V Tile Vibrator with included battery, charger, and carrying case.

2. Safety Instructions

Always adhere to the following safety guidelines to ensure safe operation and to prevent personal injury or damage to the tool.

- **Eye Protection:** Always wear appropriate eye protection (safety glasses or goggles) when operating the tile vibrator.
- **Stable Surface:** Ensure the tile and working surface are stable and clear of obstructions before beginning work.
- **Proper Grip:** Maintain a firm grip on the tool handle during operation.
- **Avoid Water:** Do not expose the tool to rain or wet conditions. Keep the work area well-lit and dry.
- **Battery Safety:** Use only the specified battery and charger. Do not short-circuit, disassemble, or expose the battery to extreme temperatures.

- **Ventilation:** Ensure adequate ventilation in the work area, especially when working with adhesives or grouts that may emit fumes.
- **Children and Bystanders:** Keep children and bystanders away from the operating area.
- **Unplug When Not In Use:** Disconnect the battery when not in use, before cleaning, or when changing accessories.

3. Package Contents

Verify that all items listed below are included in your package:

- 1 x Tile Vibrator
- 1 x Battery
- 1 x Adapter (Charger)
- 1 x User Manual (this document)

4. Product Features

The Fafeicy 16.8V Tile Vibrator is designed for efficient and precise tile leveling, offering several key features:

- **Large Bearing Capacity:** Equipped with a high-quality rubber suction cup, providing super suction power and a maximum load-bearing capacity of 100KG.
- **Intelligent Multi-stage Speed Regulation:** Features a computer intelligent mode button and six-speed adjustment settings to fine-tune the vibration frequency according to the size and type of tile.
- **Wide Application:** Suitable for both wall tiles and floor tiles up to 1 meter in size.
- **Long Battery Life:** The ceramic tile leveling machine offers extended battery life, capable of operating for more than 8 hours on a full charge.
- **Convenient One-Button Lock:** Allows for easy locking of the suction, releasing hand pressure and simplifying the movement of tiles.

5. Setup

Follow these steps to prepare your tile vibrator for use:

1. **Charge the Battery:** Connect the adapter (charger) to a standard 100-240V AC power outlet and then connect it to the battery. Allow the battery to fully charge before first use. The charging indicator light on the charger will typically change color or turn off when charging is complete.





Figure 2: The AC/DC adapter used for charging the battery.

2. **Attach the Battery:** Once charged, slide the battery pack firmly into the battery slot at the rear of the tile vibrator handle until it clicks into place.



Figure 3: Tile vibrator with the battery properly attached.

3. **Inspect the Suction Cup:** Before each use, ensure the rubber suction cup is clean and free of debris to guarantee maximum suction power.

6. Operating Instructions

This section details how to operate your Fafeicy Tile Vibrator for effective tile installation.

1. **Prepare the Tile:** Apply the appropriate adhesive to the surface where the tile will be laid, following the adhesive manufacturer's instructions.
2. **Position the Tile:** Carefully place the tile onto the adhesive, aligning it as desired.
3. **Apply Suction:** Place the suction cup of the tile vibrator onto the center of the tile. Press down firmly on the tool to engage the suction cup.



Figure 4: Side view illustrating the suction cup and handle.

4. **Engage One-Button Lock:** For prolonged use or to maintain suction without continuous hand pressure, press the one-button lock mechanism (refer to Figure 5 for button location).
5. **Adjust Vibration Frequency:** Use the intelligent multi-stage speed regulation buttons on the control panel to select the desired vibration frequency (refer to Figure 5). Start with a lower setting and increase as needed based on tile size and adhesive consistency.



Figure 5: Control panel with power and vibration adjustment buttons.

6. **Vibrate the Tile:** Press the power button to start the vibration. Move the vibrator gently across the surface of the tile to evenly distribute the adhesive and remove air bubbles, ensuring a level installation.



Figure 6: Tile vibrator in operation, ensuring even adhesive spread.

7. **Release Suction:** Once the tile is properly set, release the one-button lock (if engaged) and lift the tool from the tile.

Your browser does not support the video tag.

Video 1: Demonstration of the Tile Vibrator in use for floor plaster and tile leveling.

7. Maintenance

Regular maintenance will prolong the life of your tile vibrator and ensure optimal performance.

- **Cleaning:** After each use, wipe down the tool, especially the suction cup, with a clean, damp cloth to remove any adhesive residue or dust. Do not use harsh chemicals or abrasive cleaners.
- **Battery Care:** Store the battery in a cool, dry place away from direct sunlight. If storing for extended periods, ensure the battery is partially charged (around 50%) to maintain its health. Recharge the battery periodically if not in use.
- **Storage:** Store the tile vibrator and its accessories in the provided carrying case in a dry, secure location, out of reach of children.

- **Inspection:** Periodically inspect the power cord, battery, and suction cup for any signs of wear or damage. If damage is found, discontinue use and contact customer support.

8. Troubleshooting

This section addresses common issues you might encounter with your tile vibrator.

Problem	Possible Cause	Solution
Tool does not turn on or vibrate.	Battery is not charged or not properly inserted.	Ensure battery is fully charged and securely inserted.
Weak or no suction.	Suction cup is dirty, damaged, or not properly applied.	Clean the suction cup. Ensure it is placed on a clean, flat, non-porous tile surface. Check for damage to the rubber.
Vibration is inconsistent or too weak.	Low battery charge; incorrect speed setting.	Recharge the battery. Adjust the vibration frequency using the control panel.
Battery not charging.	Charger or battery fault; power outlet issue.	Check power outlet. Ensure charger is properly connected. If problem persists, contact customer support.

9. Specifications

Detailed technical specifications for the Fafeicy 16.8V Tile Vibrator:



Figure 7: Product dimensions.

Specification	Value
Brand	Fafeicy

Specification	Value
Model Number	Fafeicy gk0zm8ec5h
Item Type	Tile Vibrator
Color	Green
Power Source	Battery Powered
Voltage	100-240V
Wattage	8 watts
Lithium Battery Power	8000mA
Vibration Frequency	50-150 Hz
Max Bearing Weight	100KG
Battery Range	8 Hours or More after Fully Charged
Item Weight	5.21 pounds
Surface Recommendation	Floor, Tile
Special Features	One Button Lock, Intelligent Multi-stage Speed Regulation

10. Warranty and Support

Your Fafeicy 16.8V Tile Vibrator comes with a limited warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including coverage duration and what is covered.
For technical support, warranty claims, or any questions regarding the operation or maintenance of your product, please contact Fafeicy customer service through the retailer where you purchased the product or visit the official Fafeicy brand store online.

Note: Keep your purchase receipt as proof of purchase for warranty purposes.

© 2023 Fafeicy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08GFNCGSS

More documents and user manuals: **https://manuals.plus/**