



Manuals.plus /

› KEMEI /

› KEMEI Foil Professional Electric Shaver KM-2026 User Manual

KEMEI KM-2026

KEMEI Foil Professional Electric Shaver KM-2026 User Manual

Model: KM-2026

1. INTRODUCTION

Thank you for choosing the KEMEI Foil Professional Electric Shaver KM-2026. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new shaver. Please read this manual thoroughly before first use and keep it for future reference.

2. PRODUCT OVERVIEW

The KEMEI KM-2026 is a versatile 2-in-1 electric shaver designed for both close shaving and trimming. It features a powerful motor, adjustable speeds, and an LED display for clear indication of power and speed settings. Its cordless design and USB charging capability offer convenience for daily use and travel.

2.1 Key Features

- **Dual Functionality:** Combines a foil shaver for bald and stubble with a trimmer for fade work.
- **Adjustable Speed:** Three speed settings (6500 RPM, 7000 RPM, 7500 RPM) to suit different hair types and lengths.
- **LED Display:** Clearly shows current speed and remaining battery percentage.
- **Cordless & Corded Use:** Operates on battery or while connected via USB cable.
- **Long Battery Life:** Up to 120 minutes of run time on a 2-hour charge.
- **Hypoallergenic Foils:** Titanium hypoallergenic foils designed for sensitive skin, preventing razor burn.
- **Wet/Dry Shaving:** Suitable for both dry shaving and wet shaving with foam or gel.
- **Pop-up Trimmer:** Integrated trimmer for precise shaping of sideburns and mustache.

2.2 Package Contents

Upon unpacking, please ensure all items are present:

- KEMEI KM-2026 Foil Shaver
- Foil Replacement Head
- USB Charging Cable
- Cleaning Brush
- Travel Bag



Image: KEMEI KM-2026 Shaver, showing the main unit, replaceable foil head, USB charging cable, cleaning brush, and travel bag.

3. SETUP AND CHARGING

3.1 Initial Charge

Before first use, fully charge the shaver for approximately 2 hours. A full charge provides up to 120 minutes of cordless operation.

1. Connect the USB charging cable to the charging port on the shaver.

2. Plug the other end of the USB cable into a compatible USB power adapter (e.g., phone adapter, portable charger) or a computer USB port.
3. The LED display will indicate the charging status and battery percentage. A red light will appear when charging.
4. Once fully charged, disconnect the shaver from the power source.



Ultra Thin Foil Technology

Cuts hair length to less than .05mm



Hypoallergenic Titanium Plated Trimmers

Enhanced comfort for users with sensitive skin



Wet Dry Convenience

Shave dry or wet in the bath or shower



Pop-up Trimmer

Precise shaping for sideburns and mustache



Floating double net design

Stick face, very thorough shave, easy to fix



Image: The KEMEI KM-2026 shaver being charged via a USB cable connected to a laptop, illustrating the convenient charging method.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off and Speed Adjustment

- To power on the shaver, press the power button.
- To adjust the speed, press the speed adjustment button (indicated on the LED display). The display will show the current RPM (6500, 7000, or 7500).
- To power off, press the power button again.



Image: Close-up of the KEMEI KM-2026 shaver's LED display, indicating the current speed in RPM and the remaining battery percentage.

4.2 Shaving Techniques

The KEMEI KM-2026 is suitable for both dry and wet shaving. For best results, ensure your skin is clean before shaving.

- **For Dry Shaving:** Use on dry skin. Hold the shaver at a right angle to your skin and move it in short, circular motions against the direction of hair growth.
- **For Wet Shaving:** Apply shaving foam or gel to your face. Shave as you would with a manual razor, moving the shaver gently over your skin. Rinse the shaver head under running water during and after use.
- **For Bald Shaving:** The foil shaver is designed to provide a very close shave, ideal for achieving a bald look. Move the shaver over the scalp in gentle, even strokes.
- **For Stubble and Beard Line:** The foil shaver effectively removes stubble for a clean finish. For precise beard lines or sideburns, use the integrated pop-up trimmer.

USB charge, more convenient

Lithium battery & fast charge



Charging time
120 minutes

Working time
120 minutes



Image: A man demonstrating both wet shaving with foam and dry shaving with the KEMEI KM-2026 shaver, highlighting its versatility.



Dry shave

More convenient
and faster

Wet shave

More Comfortable
and Cleaner

Suitable for dry and wet shaving

Image: A man using the KEMEI KM-2026 shaver to shave his bald head, demonstrating its effectiveness for close head shaves.

4.3 Using the Pop-up Trimmer

The integrated pop-up trimmer is ideal for detailing and shaping.

1. Locate the pop-up button on the side of the shaver.
2. Press the button to extend the trimmer blade.
3. Use the trimmer to define sideburns, mustache, or beard lines.
4. Push the trimmer back into its housing when finished.



Image: A detailed view of the KEMEI KM-2026 shaver, highlighting the pop-up button and the extended sideburns blade.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your shaver.

5.1 Cleaning the Shaver Head

1. Ensure the shaver is turned off and disconnected from any power source.
2. Press the button on the right side of the shaver to release and remove the foil net.
3. Use the provided cleaning brush to remove hair clippings from the foil net and the inner blades.
4. For a more thorough clean, the foil net and blades can be rinsed under running water. Ensure they are completely dry before reattaching.
5. Reattach the foil net securely until it clicks into place.



Image: The KEMEI KM-2026 shaver disassembled, showing the replaceable foil head and the cleaning brush, illustrating the ease of cleaning.

5.2 Replacing the Foil and Blades

For continued optimal performance, it is recommended to replace the foil and blades periodically, depending on usage. A replacement foil head is included with your purchase.

1. Turn off the shaver.
2. Remove the old foil net as described in section 5.1.
3. Carefully remove the old inner blades.
4. Place the new inner blades onto the shaver's drive shaft.
5. Align the new foil net with the shaver body and press down until it clicks securely into place.

5.3 Storage

Store the shaver in a cool, dry place, away from direct sunlight and moisture. Use the provided travel bag for protection when not in use or during travel.

6. TROUBLESHOOTING

If you encounter any issues with your KEMEI KM-2026 shaver, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 2 hours.
Poor shaving performance / pulling hair.	Foil or blades are dull or clogged with hair.	Clean the shaver head thoroughly. Consider replacing the foil and blades if performance does not improve.
Shaver makes unusual noise.	Hair clippings inside the shaver head or improper assembly.	Clean the shaver head. Ensure the foil net is securely attached.
LED display not working.	Shaver is off or battery is completely dead.	Press the power button. Charge the shaver.

7. SPECIFICATIONS

Feature	Detail
Model Number	KM-2026
Power Source	Battery Powered (USB Rechargeable)
Battery Type	1 A battery (included)
Charging Time	Approx. 2 hours
Operating Time	Approx. 120 minutes
Adjustable Speeds	6500 RPM, 7000 RPM, 7500 RPM
Special Features	Portable, Cordless, Dry/Wet Shave, Rechargeable, LED Display, Pop-up Trimmer
Dimensions	7.09 x 5.91 x 7.09 inches
Weight	6.81 ounces
Manufacturer	KEMEI
UPC	744306734695

8. WARRANTY AND SUPPORT

KEMEI products are manufactured with high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your product or contact KEMEI customer support.

For technical assistance, troubleshooting not covered in this manual, or replacement parts, please contact KEMEI customer service through the official KEMEI website or your point of purchase.

