

[Manuals.plus](#) /

› [Funlot](#) /

› Funlot Christmas Window Stickers (262 PCS) Instruction Manual - Model fk55fretgfe

## Funlot fk55fretgfe

# Funlot Christmas Window Stickers (262 PCS) Instruction Manual

Model: fk55fretgfe

## 1. INTRODUCTION

This manual provides instructions for the proper application, removal, and care of your Funlot Christmas Window Stickers. These static cling decals are designed for temporary festive decoration on smooth surfaces such as windows, glass, and mirrors. Please read these instructions carefully before use.

## 2. PRODUCT CONTENTS

Your Funlot Christmas Window Stickers package includes:

- 8 sheets of assorted Christmas-themed static cling window stickers.
- A total of 262 individual sticker pieces, featuring various designs such as Santa Claus, reindeer, snowmen, Christmas trees, and snowflakes.



Figure 2.1: Overview of the 8 sheets included in the Funnlot Christmas Window Stickers package, illustrating the variety of designs and approximate sheet dimensions.

### 3. SETUP AND APPLICATION

1. **Prepare the Surface:** Ensure the window or glass surface is clean, dry, and smooth. Remove any dust, dirt, or grease. A clean surface is crucial for optimal adhesion.
2. **Peel the Sticker:** Carefully peel the desired sticker from its backing sheet. Avoid touching the cling side excessively to maintain its static properties.
3. **Apply to Surface:** Position the sticker on the clean surface. Gently press it down, starting from the center and smoothing outwards to remove any air bubbles.
4. **Adjust as Needed:** If the placement is not ideal, you can gently peel the sticker off and reposition it.

These stickers are designed to be double-sided, meaning the image is visible from both the inside and outside of the window once applied.



Figure 3.1: Illustration of peeling a sticker and the double-sided visibility feature when applied to a window.



Figure 3.2: Example of Funlot Christmas Window Stickers applied to a window, showcasing a festive arrangement.

## 4. REMOVAL AND STORAGE

To remove the stickers, gently peel them off the surface. They are designed to be removed without leaving residue or damaging the surface. For reuse, carefully place the stickers back onto their original backing sheets or onto a piece of wax paper. Store them flat in a cool, dry place away from direct sunlight to preserve their static cling properties for future use.

## 5. CARE AND MAINTENANCE

- Keep the stickers clean and free from dust. If they lose some cling, gently wipe the cling side with a damp cloth and allow it to air dry.
- Avoid applying stickers to rough, textured, or porous surfaces, as they may not adhere properly.
- Do not expose stickers to extreme heat or prolonged direct sunlight when stored, as this may affect their material

and reusability.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Stickers do not cling well.	Surface is dirty, oily, or textured. Sticker cling side is dusty.	Clean the application surface thoroughly. Gently wipe the cling side of the sticker with a damp cloth and let it dry before reapplying. Ensure the surface is smooth.
Difficulty peeling stickers from backing.	Sticker is tightly adhered to the backing.	Gently bend the backing sheet to help lift an edge of the sticker, then carefully peel it off.
Air bubbles under applied sticker.	Uneven application.	Gently lift the sticker from the edge closest to the bubble and reapply, smoothing from the center outwards.

## 7. SPECIFICATIONS

- **Brand:** Funnlot
- **Model Number:** fk55fretgfe
- **UPC:** 783971264519
- **Number of Pieces:** 262
- **Material:** Static Cling Vinyl
- **Color:** Multicolor (White, Red, Green, etc.)
- **Recommended Use:** Windows, Glass, Mirrors, other smooth, non-porous surfaces.
- **Feature:** Reusable, Double-Sided
- **Package Dimensions:** Approximately 11.61 x 8.39 x 0.28 inches
- **Item Weight:** Approximately 4.6 ounces

## 8. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Funnlot Christmas Window Stickers, please contact the manufacturer directly through their official channels. Specific warranty information is not provided in this manual. Please refer to the product packaging or the retailer's website for details on return policies or manufacturer contact information.

