

[Manuals.plus](#) /

› [greencycle](#) /

› greencycle Toner Cartridge Instruction Manual for Dell 1100 / 1110 Printers (Model DE1100-1PK)

greencycle DE1100-1PK

greencycle Toner Cartridge Instruction Manual

Model: DE1100-1PK for Dell 1100 / 1110 Laser Printers

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your greencycle DE1100-1PK black toner cartridge. This cartridge is designed as a compatible replacement for Dell 1100 and Dell 1110 laser printers.



Compatible for Dell Printers

Compatible for Dell 1100 Printer


Compatible for Dell 1110 Printer



Figure 1: greencycle toner cartridge compatible with Dell 1100 and 1110 printers.

The greencycle toner cartridge is engineered to deliver consistent print quality, producing clear, crisp text and graphics. Each cartridge offers a page yield of approximately 2,000 pages based on 5% page coverage of A4 Letter paper.

Premium components



Smart Chip
Accurately identify



Refined toner
Healthy and environmentally



Plastic Parts
Premium harmless materials



OPC drum
Thicker coating Long printing life

Figure 2: Internal components of the greencycle toner cartridge, highlighting the smart chip, refined toner, plastic parts, and OPC drum.

2. SETUP AND INSTALLATION


Follow these steps to properly install the greencycle toner cartridge into your Dell 1100 or 1110 laser printer:

1. **Unpack the new cartridge:** Carefully remove the new toner cartridge from its packaging.
2. **Shake the toner:** Gently shake the toner cartridge horizontally from side to side 6-8 times. This action helps to evenly distribute the toner powder inside the cartridge, ensuring consistent print quality.
3. **Remove protective covers:** Locate and pull out the black or orange plastic protective cover from the toner cartridge. Also, pull out the sealing tape. Ensure all protective materials are removed before installation.
4. **Insert the cartridge:** Open your printer's toner compartment. Align the toner cartridge with the corresponding slots inside the printer and gently push it in until it snaps securely into place.
5. **Close printer cover:** Close the printer cover. The printer should now be ready for use.




Easy To Install

- 1 Shake the toner cartridge horizontally from side to side several times to ensure that the toner is evenly distributed



- 2 Remove the black sealing sheet / orange plastic sealing tab. (some models also need to remove the black plastic protective cover)



- 3 Install the toner cartridge into the printer and start enjoying your printing




Figure 3: Visual guide for toner cartridge installation steps.

3. OPERATING INSTRUCTIONS

Once installed, the greencycle toner cartridge operates seamlessly with your Dell 1100 or 1110 printer. The cartridge is designed for standard office printing, general use, and producing documents with clear, bold text and graphics.

Excellent Printing Effect



Figure 4: Example of excellent printing effect, showing clear text and graphics.

The estimated page yield is 2,000 pages. Actual page yield may vary based on factors such as the content printed (e.g., text density, graphics), printer settings, and environmental conditions.



High Yield



2,000 Pages

Pages Per Toner Cartridge
5% coverage of A4 paper



Figure 5: High page yield of 2,000 pages per cartridge.



Crisp Black



Figure 6: Examples of crisp black print output.

4. MAINTENANCE

To ensure optimal performance and longevity of your toner cartridge and printer:

- **Storage:** Store unused toner cartridges in their original, sealed packaging in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid touching the OPC drum (the green or blue roller) on the cartridge, as oils from your skin can affect print quality.
- **Printer Cleaning:** Regularly clean your printer according to its manufacturer's instructions to prevent toner buildup and maintain print quality.
- **Disposal:** Dispose of empty toner cartridges responsibly, following local recycling guidelines.

5. TROUBLESHOOTING

If you encounter issues with your greencycle toner cartridge, consider the following solutions:

- **Cartridge Not Recognized:**

- Ensure the cartridge is fully seated in its slot. Remove and reinsert it firmly until it clicks into place.
- Turn the printer off, wait for 30 seconds, then turn it back on. This can sometimes reset the printer's sensors.
- Check for any remaining protective tape or plastic covers on the cartridge, especially over the chip or contacts.

- **Poor Print Quality (Streaks, Fading, Light Prints):**

- Gently shake the toner cartridge horizontally several times to redistribute the toner powder.
- Ensure the printer's drum unit (if separate) is clean and free from damage.
- Check printer settings to ensure they are appropriate for your print job (e.g., print density).

- **Cartridge Does Not Fit:**

- Double-check that all protective plastic pieces, including any shipping covers or tabs, have been completely removed from the cartridge. Some models may have a black plastic piece that needs to be pulled off.
- Verify that you have the correct cartridge model (DE1100-1PK) for your specific Dell printer model (1100 or 1110).

6. SPECIFICATIONS

Feature	Detail
Brand	greencycle
Model Number	DE1100-1PK
Compatible Printer Models	Dell 1100, Dell 1110
Ink Colour	Black
Page Yield	Up to 2,000 pages (based on 5% coverage of A4 Letter)
Item Weight	907 g
Cartridge Type	Compatible
Printer Type	Laser
Included Components	Toner Cartridge

7. WARRANTY INFORMATION

For specific warranty terms and conditions regarding your greencycle toner cartridge, please refer to the documentation included with your purchase or contact greencycle customer support directly. Warranty coverage typically addresses manufacturing defects.

8. CUSTOMER SUPPORT

If you require further assistance, have questions, or need to report an issue, please contact greencycle customer support. Contact information can usually be found on the product packaging or the official

