Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SnapFresh BBT-YOR01

SnapFresh 20V Cordless Leaf Blower User Manual

Model: BBT-YOR01 | Brand: SnapFresh

1. Introduction

This manual provides essential instructions for the safe operation, assembly, maintenance, and troubleshooting of your SnapFresh 20V Cordless Leaf Blower, Model BBT-YOR01. Please read this manual thoroughly before first use and retain it for future reference.

Safety Information

For detailed safety guidelines, refer to the "Safety Information (PDF)" document available for download. Always wear appropriate personal protective equipment (PPE) such as eye protection, hearing protection, and gloves during operation. Keep bystanders, especially children and pets, away from the operating area.
Important: Only use the battery and charger supplied or recommended by SnapFresh for this product.

2. Product Components

The SnapFresh 20V Cordless Leaf Blower includes the following components:

- Blower Unit
- Extension Nozzle
- 20V 2.0Ah Lithium-Ion Battery
- Fast Charger
- User Manual (this document)
- Warranty Card



Figure 2.1: Main components of the SnapFresh Cordless Leaf Blower, including the blower unit, extension nozzle, battery, and charger.

3. Setup and Assembly

3.1 Charging the Battery

1. Connect the fast charger to a standard power outlet.
2. Slide the 20V 2.0Ah Lithium-Ion Battery onto the charger until it clicks into place.
3. The charger indicator light will show the charging status. A full charge typically takes approximately 1 hour.
4. Once fully charged, remove the battery from the charger.



Figure 3.1: The 20V 2.0Ah battery connected to the rapid charger. The charger features indicator lights for charging status.

3.2 Attaching the Extension Nozzle

1. Align the extension nozzle with the blower unit's air outlet.
2. Push the nozzle firmly onto the blower unit until it locks securely into place.
3. To detach, press the release button (if present) and pull the nozzle off.



Figure 3.2: Illustration of attaching the extension tube to the main blower unit for extended reach.

3.3 Installing the Battery

1. Ensure the blower's power switch is in the "OFF" position.
2. Slide the charged battery into the battery slot on the blower unit until it clicks securely.
3. To remove the battery, press the battery release button and slide the battery out.

4. Operating Instructions

4.1 Starting and Stopping

1. Ensure the battery is fully charged and securely installed.
2. To start the blower, slide the power switch to the desired speed setting (Low or High).
3. To stop the blower, slide the power switch to the "OFF" position.



Figure 4.1: The 2-speed selection switch located on the handle for easy operation.

4.2 Speed Settings

- **Low Speed:** Provides an average no-load speed of 60 mph, suitable for lighter debris and extended runtime (up to 25 minutes).
- **High Speed:** Provides an average no-load speed of 130 mph, ideal for heavier debris and faster cleaning (up to 20 minutes runtime).

4.3 General Operation Tips

- Hold the blower firmly with one hand, directing the nozzle towards the debris.
- Use a sweeping motion to gather leaves and debris into piles.
- For optimal performance, work in dry conditions.
- The adjustable tube length allows for comfortable use across various tasks, from clearing driveways to patios.



Figure 4.2: Demonstrating the leaf blower in use, clearing leaves from a paved surface.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your leaf blower. Always disconnect the battery before performing any maintenance.

5.1 Cleaning

- Wipe the exterior of the blower with a clean, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure air vents are clear of debris to prevent overheating. Use a soft brush or compressed air if necessary.
- Clean the nozzle regularly to maintain efficient airflow.

5.2 Storage

- Store the leaf blower in a dry, cool place, away from direct sunlight and moisture.
- Remove the battery from the blower before storage.
- Store the battery in a partially charged state (around 50%) if storing for extended periods to prolong its life.

- The detachable design allows for compact storage.

6. Troubleshooting

If you encounter issues with your SnapFresh Leaf Blower, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Blower does not start.	Battery not charged or not properly installed.	Ensure battery is fully charged and securely clicked into place.
Reduced airflow.	Nozzle or air vents are blocked.	Clear any debris from the nozzle and air vents.
Short runtime.	Battery not fully charged or aged battery.	Fully charge the battery. If the issue persists, the battery may need replacement.
Unusual noise or vibration.	Internal obstruction or loose components.	Immediately stop operation, remove battery, and inspect for visible obstructions. If problem persists, contact customer support.

7. Specifications

Feature	Detail
Brand	SnapFresh
Model Number	BBT-YOR01
Power Source	Cordless Electric, Battery Powered
Voltage	20 Volts
Battery Type	Lithium Ion (2.0Ah included)
Form Factor	Handheld
Maximum Air Speed	130 Miles per Hour (High Speed)
Low Air Speed	60 Miles per Hour (Low Speed)
Item Weight	2.7 Pounds
Product Dimensions	25.09"L x 5.51"W x 5.91"H
Included Components	Battery, Charger, Extension Nozzle, User Manual, Warranty Card

8. Warranty and Support

Your SnapFresh 20V Cordless Leaf Blower comes with a warranty. Please refer to the included Warranty Card for specific terms and conditions. For technical support, replacement parts, or warranty claims, please contact SnapFresh customer service.

Online Resources:

- User Guide (PDF): Download User Guide
- Certificate of Compliance (PDF): Download Certificate
- Safety Information (PDF): Download Safety Information

9. Product Videos

No official product videos from the seller were provided in the available data for embedding in this manual.

© 2023 SnapFresh. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08GG5YDX7

More documents and user manuals: **https://manuals.plus/**