

[Manuals.plus](#) /

› [Cybex](#) /

› Cybex Sirona S Convertible Car Seat User Manual

Cybex 519004435

Cybex Sirona S Convertible Car Seat User Manual

Model: 519004435

INTRODUCTION

The Cybex Sirona S is a convertible car seat designed for the safe transportation of children from infancy through toddlerhood. It features an innovative 360-degree rotatable seat, allowing for easy transitions between rear-facing and forward-facing positions, and simplifying the process of securing and removing your child.

Key features include a steel-reinforced frame, an anti-rebound design, and a Linear Side-Impact Protection (L.S.P.) system for enhanced safety. The integrated SensorSafe chest clip provides real-time alerts to your mobile device regarding your child's safety and comfort. The car seat is designed for easy installation with a one-time belt installation system and an EasyLock Bar.



Image: The Cybex Sirona S convertible car seat in Urban Black, showcasing its sleek design and integrated base with load leg.

SAFETY INFORMATION

The Sirona S is engineered with multiple safety features to provide maximum protection for your child:

- **360° Rotatable Seat with Load Leg:** This feature not only simplifies child placement but also includes a load leg that reduces rotation in certain crash scenarios by up to 30%.
- **Steel-Reinforced Frame and Anti-Rebound Design:** Provides structural integrity and reduces car seat rebound movement during a collision.
- **Linear Side-Impact Protection (L.S.P.) System:** Absorbs up to 25% more impact in a side collision compared to the same car seat without L.S.P. extended.
- **SensorSafe Chest Clip:** This smart technology syncs with a mobile app to provide critical alerts, including:
 - Child unbuckles themselves.
 - Back seat temperature is too warm or too cold.

- Child has been seated for too long.
- Driver accidentally leaves the child behind.



Image: A smartphone displaying a SensorSafe alert, indicating a connected car seat and a buckled clip, highlighting the real-time safety monitoring feature.

SETUP AND INSTALLATION

Proper installation is crucial for your child's safety. The Sirona S offers a straightforward installation process.

EasyLock Bar and Belt Installation

The EasyLock Bar significantly reduces the force needed for secure installation. The car seat supports a one-time belt installation for both rear-facing and forward-facing positions, allowing for seamless transitions without re-installation.

ONE-TIME VEHICLE BELT INSTALLATION

ALLOWS SEAMLESS TRANSITION FROM REAR-FACING TO
FORWARD-FACING MODE WITHOUT HAVING TO RE-INSTALL



Image: A close-up view of the car seat's one-time vehicle belt installation mechanism, showing the path for the seatbelt and the EasyLock bar.

Installation Videos

For detailed visual instructions, please refer to the official installation videos provided by Cybex:

Rear-Facing Installation with Lower Anchors

Your browser does not support the video tag.

Video: Demonstrates the proper method for installing the Sirona S car seat in a rear-facing position using the vehicle's lower anchors.

Forward-Facing Installation with Lower Anchors & Tether

Your browser does not support the video tag.

Video: Illustrates the correct procedure for installing the Sirona S car seat in a forward-facing position using both lower anchors and the top tether.

Forward Facing Installation with Seat Belt & Tether

Forward-Facing Installation with Seat Belt & Tether

Your browser does not support the video tag.

Video: Shows how to install the Sirona S car seat in a forward-facing position using the vehicle's seat belt and the top tether.

Adjustable Headrest

The Sirona S features a 12-position headrest with a no-rethread harness, allowing you to easily adjust the height of the shoulder straps as your child grows, ensuring a perfect and safe fit at all times.

OPERATING THE CAR SEAT

The unique design of the Sirona S simplifies daily use.

360° Swivel Function

The 360° rotatable seat allows you to turn the car seat towards the car door, making it significantly easier to place your child into the seat and take them out, reducing strain on your back.



Image: A child comfortably seated in the Cybex Sirona S car seat, positioned in a vehicle, demonstrating the ease of access provided by the swivel feature.

Recline Positions

The car seat offers multiple recline positions to ensure your child's comfort, whether they are awake or asleep. Always ensure the car seat is at the proper recline angle as indicated by the dual-level indicators for safe use.

SensorSafe App Connection

To utilize the full benefits of SensorSafe technology, download the SensorSafe app on your smartphone. The chest clip automatically syncs with the app, providing real-time alerts. Ensure your phone's Bluetooth is enabled and the app is running when using the car seat.

MAINTENANCE

Regular maintenance helps ensure the longevity and cleanliness of your Cybex Sirona S car seat.

- **Cleaning Fabric Covers:** The fabric covers are *machine washable*. Refer to the care label on the covers for specific washing instructions. Use mild detergent and cold water. Do not bleach or tumble dry.
- **Cleaning Hard Parts:** Wipe down plastic and metal parts with a damp cloth and mild soap. Do not use abrasive cleaners or solvents.
- **Harness System:** Inspect the harness straps regularly for any signs of wear, fraying, or damage. Clean the harness straps with a damp cloth and mild soap. Do not immerse the harness in water.
- **Storage:** When not in use, store the car seat in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

If you encounter any issues with your Cybex Sirona S, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Car seat feels loose or wobbles after installation.	Insufficient tightening of the LATCH connectors or vehicle seat belt.	Ensure the EasyLock Bar is fully engaged and the LATCH belt or vehicle seat belt is pulled as tight as possible. The car seat should not move more than one inch side-to-side or front-to-back at the belt path. Refer to installation videos.
SensorSafe app not receiving alerts or connecting.	Bluetooth not enabled, app not open, or connection issue.	Ensure Bluetooth is active on your phone. Open the SensorSafe app before each use. If issues persist, try restarting your phone and the app. Check for app updates.
Harness straps are difficult to adjust.	Harness may be twisted or not properly routed.	Check that the harness straps are not twisted and are routed correctly through the appropriate slots for your child's height. Ensure the no-rethread mechanism is functioning smoothly.

If these solutions do not resolve the issue, please contact Cybex customer support.

SPECIFICATIONS

Attribute	Detail
Product Dimensions	25.3 x 20 x 25.5 inches

Attribute	Detail
Item Model Number	519004435
Target Gender	Unisex
Minimum Weight Recommendation	3 Kilograms (6.6 lbs)
Maximum Weight Recommendation	65 Pounds
Minimum Height Recommendation	17 Inches
Maximum Height Recommendation	49 Inches
Material Type	Polyester
Material Composition	100% Polyester
Care Instructions	Machine Washable
Number of Reclining Positions	12
Batteries Required	Yes (for SensorSafe)
Orientation	Rear Facing / Forward Facing
Rear-Facing Minimum Child Weight	4 Pounds
Rear-Facing Maximum Child Weight	50 Pounds
Forward-Facing Minimum Child Weight	22 Pounds
Forward-Facing Maximum Child Weight	65 Pounds
Harness Type	5-Point
Item Weight	30.4 pounds
Country/Region of Origin	China
Installation Type	LATCH / Seat Belt
Color	Urban Black

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Cybex website or the full user manual provided with your product. A digital version of the user manual is often available online for download.

You can access the official User Manual (PDF) [here](#).

For further assistance, contact Cybex customer service directly.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question