



Manuals.plus /

- › Keurig /
- › Keurig K-Supreme Coffee Maker User Manual

Keurig 062151515284

Keurig K-Supreme Coffee Maker User Manual

Brand: **Keurig** | Model: **062151515284**

1. PRODUCT OVERVIEW

The Keurig K-Supreme Single Serve coffee maker elevates your coffee experience with its innovative MultiStream Technology. This technology saturates coffee grounds more evenly, extracting full flavor and aroma from every K-Cup pod. The brewer offers customization options, including a Strong button for a more intense taste and the ability to brew hot over ice for refreshing iced coffee. It supports multiple brew sizes (177, 237, 296, or 355 ml / 6, 8, 10, or 12 oz) and features a travel mug-friendly design. The stylish 1.95 L (66 oz) dual-position reservoir simplifies refilling and allows for flexible countertop placement. You can use hundreds of K-Cup pod varieties or brew your own ground coffee with the My K-Cup Universal Reusable Coffee Filter (sold separately).



The Keurig K-Supreme Coffee Maker, designed for single-serve brewing, shown with a red coffee mug.

K-Supreme™/MC

SINGLE SERVE COFFEE MAKER
CAFETIÈRE UNE TASSE À LA FOIS



MULTISTREAM TECHNOLOGY™

saturates the coffee grounds more evenly* to extract full flavor and aroma

*vs. leading national Keurig® K-Classic® coffee maker



TECHNOLOGIE MULTIJET™

permet une infusion plus uniforme* pour extraire le goût riche et tous les arômes du café

*par rapport à la cafetière chef de file nationale Keurig® K-Classic®



MultiStream Technology ensures even saturation of coffee grounds for enhanced flavor extraction.

K-Supreme™/MC

SINGLE SERVE COFFEE MAKER
CAFETIÈRE UNE TASSE À LA FOIS



CUSTOMIZE YOUR CUP

with strong option, or make it iced by brewing hot over ice and enjoying cold



PERSONNALISEZ VOTRE TASSE

avec l'option intense, ou optez pour une version glacée et savourez votre boisson froide en effectuant une infusion sur glace



Customize your brew with options for stronger coffee or refreshing iced coffee.

K-Supreme™/MC

SINGLE SERVE COFFEE MAKER
CAFETIÈRE UNE TASSE À LA FOIS



1.95L (66 oz) DUAL-POSITION RESERVOIR

Choose the perfect position for optimal counter space



RÉSERVOIR À DEUX POSITIONS DE 1,95L (66 oz)

Choisissez la position parfaite pour optimiser l'espace sur le comptoir



The 1.95L (66 oz) dual-position reservoir offers flexible placement on your countertop.

Key Features:

- **MultiStream Technology:** Extracts full flavor and aroma in every brew.
- **Customizable Brew:** Brew a stronger cup, or brew hot over ice for refreshing iced coffee.
- **Multiple Brew Sizes:** Offers 177, 237, 296, or 355 ml (6, 8, 10, or 12 oz) cup options.
- **Dual-Position Reservoir:** 1.95 L (66 oz) removable reservoir for optimal counter space and easy refilling.
- **Fast Brewing:** Delivers fresh-brewed coffee in minutes.

2. SETUP AND FIRST USE

Initial Setup:

1. **Unpack:** Remove all packaging materials and tape from the coffee maker.
2. **Clean Reservoir:** Wash the water reservoir and reservoir lid with warm, soapy water. Rinse thoroughly.
3. **Fill Reservoir:** Fill the water reservoir with fresh water up to the MAX fill line.
4. **Position Reservoir:** Place the filled reservoir onto the coffee maker base. The dual-position design allows placement on either the side or rear of the brewer.
5. **Plug In:** Plug the coffee maker into a grounded outlet. The power button will illuminate.

First Cleansing Brew:

Perform a cleansing brew to ensure optimal performance and cleanliness before your first beverage.

1. Place a large mug (at least 12 oz) on the drip tray.
2. Do not insert a K-Cup pod.
3. Lift and lower the handle to close the K-Cup pod holder.
4. Select the 12 oz brew size button. The cleansing brew will begin.
5. Once complete, discard the hot water. The coffee maker is now ready for use.

K·Supreme^{TM/MC}

SINGLE SERVE COFFEE MAKER
CAFETIÈRE UNE TASSE À LA FOIS



Removable water reservoir
makes refilling easy



Le réservoir amovible
facilite le remplissage

The removable water reservoir makes refilling simple and convenient.

3. OPERATING INSTRUCTIONS

Brewing with K-Cup Pods:

1. Place a mug on the drip tray.
2. Lift the handle and insert a K-Cup pod into the K-Cup pod holder.
3. Lower the handle completely to close the lid.
4. Select your desired brew size (6, 8, 10, or 12 oz).
5. For a stronger brew, press the **STRONG** button before selecting your brew size.
6. For iced coffee, fill a large cup with ice, insert a K-Cup pod, and press the **OVER ICE** button before selecting your brew size.

7. The brew will begin automatically.

8. Once brewing is complete, lift the handle and dispose of the used K-Cup pod.

K•Supreme^{TM/MC}

SINGLE SERVE COFFEE MAKER
CAFETIÈRE UNE TASSE À LA FOIS



Easily insert a K-Cup pod for a quick and convenient single-serve brew.

Brewing with Ground Coffee (using My K-Cup Universal Reusable Coffee Filter - sold separately):

1. Remove the K-Cup pod holder from the brewer.
2. Insert the My K-Cup Universal Reusable Coffee Filter into the K-Cup pod holder.
3. Fill the reusable filter with your desired amount of ground coffee (do not overfill).
4. Place the assembled filter and holder back into the brewer.
5. Lower the handle completely.
6. Select your desired brew size.
7. The brew will begin automatically.
8. Once brewing is complete, remove and clean the reusable filter.

K•Supreme^{TM/MC}

SINGLE SERVE COFFEE MAKER
CAFETIÈRE UNE TASSE À LA FOIS



4 CUP SIZES

Brew a 177, 237, 296, or 355 ml (6, 8, 10, or 12 oz) cup



4 FORMATS DE TASSE

Infusez une tasse de 177, 237, 296 ou 355 ml (6, 8, 10 ou 12 oz)

The control panel offers various brew sizes and options like Strong and Over Ice.

4. MAINTENANCE

Cleaning:

- **External Cleaning:** Wipe the exterior of the coffee maker with a damp, non-abrasive cloth.
- **Drip Tray:** The drip tray can accumulate up to 8 ounces of overflow. It should be emptied and cleaned regularly. Remove the drip tray, discard contents, and wash with warm, soapy water.
- **K-Cup Pod Holder:** The K-Cup pod holder can be removed for cleaning. Separate the funnel from the pod holder. Wash both parts with warm, soapy water.
- **Water Reservoir:** Clean the water reservoir and lid periodically with warm, soapy water.

Descaling:

Mineral deposits (calcium) can build up in your coffee maker over time, affecting performance. The DESCALING indicator light will illuminate when it's time to descale. Follow these steps:

1. **Prepare Solution:** Turn off the coffee maker. Empty the water reservoir. Pour an entire bottle of Keurig Descaling Solution into the reservoir.
2. **First Descale Brew:** Place a large mug on the drip tray. Lift and lower the handle. Select the 12 oz brew size. Repeat until the "ADD WATER" light illuminates.
3. **Soak:** Let the coffee maker stand for at least 30 minutes while the descaling solution works.
4. **Rinse Brews:** After soaking, empty and rinse the reservoir thoroughly. Fill the reservoir with fresh water. Perform 12 oz cleansing brews until the reservoir is empty.
5. **Repeat if Necessary:** If the DESCALING light remains illuminated, repeat the descaling process.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Coffee maker does not turn on.	Not plugged in; power outage; circuit breaker tripped.	Ensure the power cord is securely plugged into a grounded outlet. Check your home's circuit breaker.
"ADD WATER" light is on.	Water reservoir is low or empty.	Refill the water reservoir with fresh water to the MAX fill line.
Coffee is not brewing.	K-Cup pod not properly seated; air in water lines; brewer needs descaling.	Ensure K-Cup pod is fully inserted and handle is lowered. Perform a cleansing brew without a pod. Descal the brewer if the DESCALING light is on.
Coffee tastes weak or watery.	Incorrect brew size selected; K-Cup pod not suitable for desired strength; brewer needs descaling.	Select a smaller brew size. Use the STRONG button. Try a different K-Cup pod. Descal the brewer.
Brewing stops mid-cycle.	Water reservoir empty; K-Cup pod clogged; brewer needs descaling.	Check water level. Remove and re-insert K-Cup pod. Descal the brewer.

6. SPECIFICATIONS

Feature	Detail
Brand	Keurig
Model Number	062151515284
Coffee Maker Type	Drip Coffee Machine
Coffee Input Type	Pods and Ground Coffee
Water Reservoir Capacity	1.95 L (66 oz) Dual-Position, Removable
Brew Sizes	177, 237, 296, 355 ml (6, 8, 10, 12 oz)
Special Features	MultiStream Technology, Strong Brew, Over Ice Brew
Operation Mode	Manual (Button Interface)
Product Dimensions (L x W x H)	7.05 x 17.91 x 14.41 inches
Item Weight	5.9 pounds
Included Components	Filter (likely referring to the K-Cup pod holder filter, or a general filter type)
UPC	062151515284

K·Supreme™/MC

SINGLE SERVE COFFEE MAKER
CAFETIÈRE UNE TASSE À LA FOIS



PRODUCT DIMENSIONS

Water reservoir on side:

30.8 cm Height (12.15")

19.94 cm Width (7.85")

30.53 cm Depth (12.02")



DIMENSIONS DE LA CAFETIÈRE HORS DE LA BOÎTE

Réservoir d'eau sur le côté :

30,8 cm de hauteur (12,15 po)

19,94 cm de largeur (7,85 po)

30,53 cm de longueur (12,02 po)



Detailed product dimensions for proper placement and fit.

7. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Keurig website. You can also contact Keurig customer service directly for assistance with product registration, troubleshooting, or parts replacement.

Keurig Official Website: www.keurig.com