

8Jo6Poe Blue Hive Wall Clock with Numerals

8Jo6Poe Blue Hive Wall Clock with Numerals Instruction Manual

Model: Blue Hive Wall Clock with Numerals

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your 8Jo6Poe Blue Hive Wall Clock with Numerals. Please read these instructions carefully before use to ensure proper function and longevity of your product.

SETUP

1. Unpacking

1. Carefully remove the wall clock from its packaging.
2. Inspect the clock for any signs of damage. If damage is found, do not proceed with setup and contact customer support.
3. Retain packaging materials for future transport or storage.

2. Battery Installation

1. Locate the battery compartment on the back of the clock.
2. Insert one AA battery (not included) according to the polarity indicators (+ and -) inside the compartment.
3. Close the battery compartment cover securely.

3. Mounting the Clock

The 8Jo6Poe Blue Hive Wall Clock is lightweight and designed for easy installation using a hook or nail.

1. Choose a suitable location on a wall, ensuring it is level and free from obstructions.
2. Insert a nail or screw into the wall at the desired height. Ensure the nail or screw is securely fastened and can support the clock's weight.
3. Align the back nail slot of the clock with the nail or screw on the wall.

4. Gently lower the clock until it rests securely on the nail or screw.



This image displays the front view of the 8Jo6Poe Blue Hive Wall Clock. It features a circular face with a teal-blue background and a repeating hexagonal pattern. White numerals from 1 to 12 are clearly visible, along with white hour and minute hands. The clock is designed for wall mounting.

OPERATING INSTRUCTIONS

1. Setting the Time

1. Locate the time-setting knob on the back of the clock mechanism.
2. Gently turn the knob in either direction until the clock hands display the correct time.
3. Avoid forcing the hands directly, as this may damage the movement.

2. Silent Movement

Your 8Jo6Poe Blue Hive Wall Clock is equipped with a high-quality quartz movement designed for silent operation. This ensures a quiet environment, suitable for bedrooms, offices, or any space where noise reduction is desired.

MAINTENANCE

1. Cleaning

- To clean the clock face and frame, use a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or water directly on the clock, as this may damage the finish or internal components.

2. Battery Replacement

- Replace the AA battery annually or when the clock begins to lose time or stop.
- Always use a fresh, high-quality AA battery for optimal performance.
- Dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock not running	Dead or incorrectly installed battery	Replace battery with a fresh AA battery, ensuring correct polarity.
Clock runs slow or stops intermittently	Low battery power	Replace battery with a fresh AA battery.
Hands are stuck or not moving smoothly	Hands are bent or obstructed	Gently check if hands are touching each other or the clock face. Carefully adjust if necessary.

SPECIFICATIONS

- **Model:** Blue Hive Wall Clock with Numerals
- **Brand:** 8Jo6Poe
- **Material:** MDF (Medium Density Fiberboard)
- **Diameter:** 12 inches (approximately 30 cm)
- **Movement:** Silent Quartz Movement
- **Power Source:** 1 x AA Battery (not included)
- **ASIN:** B08GPNS3BN
- **Manufacturer:** Duoketti

WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the documentation provided at the time of purchase or contact your retailer. If you encounter any issues not covered in this manual, please reach out to the seller or manufacturer for assistance.