

Timex TW2U40000

# Timex Modern Easy Reader 40mm Men's Expansion Band Watch User Manual

Model: TW2U40000 | Brand: Timex

## INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Timex Modern Easy Reader 40mm Men's Expansion Band Watch. Please read this manual carefully to ensure proper use and longevity of your timepiece. This watch combines classic design with modern functionality, featuring a clear dial and the signature INDIGLO night-light.

## PRODUCT OVERVIEW



Front view of the watch, showcasing the clear dial with large numerals and the two-tone expansion band.



Side profile, highlighting the watch case

thickness and the design of the expansion band.



Rear view, displaying the stainless steel case back with engraved details.

## SETUP

---

### Setting the Time

1. **Pull the Crown:** Locate the small knob (crown) on the side of the watch case. Gently pull the crown out to its furthest position. The second hand will stop moving.
2. **Adjust the Time:** Turn the crown clockwise or counter-clockwise to move the hour and minute hands until the desired time is displayed.
3. **Push the Crown In:** Once the time is set, push the crown back into its original, closed position. The second hand will resume movement, indicating the watch is now running.

## OPERATING INSTRUCTIONS

---

### INDIGLO Night-Light Feature

Your Timex watch is equipped with the INDIGLO night-light, which illuminates the entire watch dial for easy reading in low-light conditions.

- **Activation:** To activate the INDIGLO night-light, simply press and hold the crown (the same knob used for setting the time).
- **Duration:** The light will remain on as long as the crown is pressed. Release the crown to turn off the light.

### Water Resistance

This watch is water resistant to 30 meters (98 feet). This rating means the watch is suitable for short periods of recreational swimming, such as in a pool or shallow water. However, it is **not** recommended for diving, snorkeling, or high-impact water sports. To maintain water resistance, avoid pressing the crown or operating any buttons while the watch is wet or submerged.

## MAINTENANCE

---

- **Cleaning:** Regularly wipe the watch case and band with a soft, dry, lint-free cloth to remove dust and fingerprints. For more thorough cleaning, a slightly damp cloth can be used, but ensure the watch is completely dry afterward.
- **Battery Replacement:** The watch operates on one CR2 battery. Battery life varies depending on usage, particularly the frequency of INDIGLO light activation. When the watch stops or the INDIGLO light dims significantly, it indicates a low battery. It is highly recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain the watch's water resistance.
- **Storage:** When not in use for extended periods, store your watch in a cool, dry place away from direct

sunlight, extreme temperatures, and strong magnetic fields.

- **Avoid Chemicals:** Do not expose the watch to harsh chemicals, solvents, detergents, perfumes, or cosmetic sprays, as these can damage the watch case, band, or internal components.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch stops or runs slowly	Low battery	Replace the battery. It is recommended to have this done by a professional.
INDIGLO light not working or dim	Low battery or internal contact issue	Replace the battery. If the issue persists after battery replacement, contact Timex customer support.
Condensation inside the crystal	Exposure to extreme temperature changes or water ingress	Immediately take the watch to a qualified watch technician for inspection and repair to prevent internal damage. Do not attempt to dry it yourself.
Time is incorrect after setting	Crown not fully pushed in	Ensure the crown is fully pushed back into its closed position after setting the time.

## SPECIFICATIONS

- **Model Number:** TW2U40000
- **Movement:** Quartz with three hands display
- **Case Diameter:** Approximately 40mm
- **Product Dimensions:** 1.57 x 3.94 x 2.36 inches
- **Item Weight:** 3.84 ounces
- **Water Resistance:** 30 meters (98 feet)
- **Battery Type:** 1 CR2 battery (included)
- **Features:** INDIGLO Light-Up Watch Dial

## WARRANTY AND SUPPORT

For detailed information regarding warranty coverage, terms, and conditions, please refer to the official Timex website or the warranty card included with your purchase. Keep your purchase receipt as proof of purchase for any warranty claims.

For customer support, technical assistance, or service inquiries, please visit the official Timex website or contact their customer service department directly.

Official Timex Website: [www.timex.com](http://www.timex.com)