

[manuals.plus](#) /› [TOOLPORT](#) /› [TOOLPORT 10x15 ft PES 700 Pop-Up Canopy Tent Instruction Manual \(Model 59049\)](#)

## TOOLPORT 59049

# TOOLPORT 10x15 ft PES 700 Pop-Up Canopy Tent Instruction Manual

Model: 59049 | Brand: TOOLPORT

## 1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your TOOLPORT 10x15 ft PES 700 Pop-Up Canopy Tent. Please read this manual thoroughly before initial use to ensure safe and correct handling of the product.

### Important Safety Information

- Wind and snow loads have not been tested for this gazebo.
- Always ensure that the tent is assembled correctly and securely anchored.
- In the case of moderate snowfall, clear the roof promptly to prevent accumulation.
- In the case of emerging wind, use additional storm sets (not included) for enhanced stability.
- During strong winds, heavy snowfall, or significant rainfall, temporary disassembly of the gazebo is recommended to prevent damage.
- Keep the tarpaulin away from heat sources and open flames at all times.
- Observe all safety information provided in the assembly instructions.

## 2. ASSEMBLY INSTRUCTIONS

The TOOLPORT Pop-Up Canopy Tent features a modern scissors mechanism designed for straightforward setup and takedown. No special tools are required for assembly. It is recommended that 1-2 persons perform the assembly.

1. **Unpack Components:** Carefully remove all parts from the carrying bag and lay them out. Verify that all components listed in the packing list are present.
2. **Expand the Frame:** With two people, grasp opposite sides of the collapsed frame and gently pull outwards to begin expanding it.

3. **Attach Roof Tarp:** Before fully expanding the frame, drape the roof tarpaulin over the partially expanded frame. Ensure the tarp is correctly oriented and secured to the frame corners.
4. **Fully Expand Frame:** Continue pulling the frame outwards until it is fully expanded. The click system will engage to lock the frame in place.
5. **Adjust Height:** Press the release buttons on each leg and extend the legs to the desired height. The canopy offers three adjustable height settings. Ensure all legs are locked at the same height.
6. **Install Sidewalls (Optional):** If using sidewalls, attach them to the frame using the integrated fastening mechanisms (e.g., Velcro straps, zippers).
7. **Secure the Canopy:** Use the provided ground stakes and guy ropes to anchor the canopy securely to the ground. This is crucial for stability, especially in windy conditions.



Image: The steel frame of the canopy, partially expanded, before the roof tarp is fully stretched.



## ■ ASSEMBLY

Due to comprehensible assembly instructions, the pop up gazebo can be set up by 1-2 persons without complications. No tools needed. After setting up the frame construction, pull open lightly. Then cover with tarpaulin and pull open completely (add side panels if applicable).



Image: Visual guide illustrating the four main steps of pop-up canopy assembly, from collapsed to fully erected frame.




Image: A hand demonstrating how to adjust the height of a canopy leg using the push-button mechanism.

## 3. OPERATION

The TOOLPORT Pop-Up Canopy Tent is designed for quick and versatile use, providing temporary

shelter for various outdoor activities.

## Height Adjustment

The canopy frame features a 3-way adjustable click system, allowing you to set the desired height. To adjust, press the metal button on each leg and slide the inner leg section up or down until the button locks into the next hole. Ensure all four legs are adjusted to the same height for stability.

## Sidewall Usage

The included sidewalls can be attached to provide additional protection from wind, sun, or rain. They feature panorama windows for visibility. Attach them securely to the frame using the integrated fasteners.



Image: A fully assembled white pop-up canopy tent, showcasing the sidewalls with panorama windows.

## 4. CARE AND MAINTENANCE

Proper care and maintenance will extend the lifespan of your TOOLPORT canopy tent.

### Cleaning

- The roof tarpaulin is made from high-performance polyester with PVC coating, making it 100% waterproof, UV protected, and dirt repellent.
- Clean the tarpaulin with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.
- Ensure the tarpaulin is completely dry before folding and storing to prevent mildew.

- Wipe down the steel frame with a damp cloth to remove dirt and debris.

## Storage

- The canopy frame folds compactly for easy storage.
- Store the canopy tent in its provided carrying bag in a dry, cool place, away from direct sunlight and extreme temperatures.



Image: A close-up view of the canopy's waterproof fabric, showing water droplets beading on the surface.



Image: The black carrying bag designed for convenient transport and storage of the folded canopy tent.

## 5. TROUBLESHOOTING

This section addresses common issues you might encounter with your canopy tent.

Problem	Possible Cause	Solution
Canopy is unstable or wobbly.	Legs not fully extended/locked; insufficient anchoring; uneven ground.	Ensure all legs are locked at the same height. Use all ground stakes and guy ropes. Move to level ground if possible.
Water pooling on the roof.	Improper tensioning of the roof tarp; heavy rain.	Ensure the roof tarp is stretched tightly and evenly across the frame. Adjust frame height if necessary to create proper slope. Disassemble in heavy rain.
Frame difficult to expand or collapse.	Frame joints are stiff or dirty; not enough people assisting.	Clean and lubricate joints if necessary. Ensure at least two people are expanding/collapsing the frame.
Sidewalls do not fit correctly.	Incorrect orientation; frame not fully expanded.	Check sidewall orientation. Ensure the main frame is fully expanded and locked before attaching sidewalls.

## 6. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	TOOLPORT
Model Number	59049
Product Dimensions (L x W x H)	177"L x 118"W x 132"H (approx. 10x15 ft footprint)
Item Weight	60.2 pounds (27300 Grams)
Material (Poles)	Steel, 1.2x1.2 inch square profile, powder-coated
Material (Tarpaulin)	High Performance Polyester (PES 700) with PVC coating
Color	White
Water Resistance Level	Water Resistant (100% waterproof seams)
Ultraviolet Light Protection	No (UV protected fabric, but not rated for specific UV protection level)
Assembly Required	No (Pop-up design, minimal assembly)



Image: A technical diagram illustrating the length, width, and height dimensions of the canopy tent in both meters and feet.

## 7. WARRANTY AND CUSTOMER SUPPORT

For specific warranty information regarding your TOOLPORT Pop-Up Canopy Tent, please refer to the documentation included with your purchase or contact TOOLPORT customer service directly. For additional support and product information, visit the official TOOLPORT store on Amazon:

[Visit the TOOLPORT Store](#)

© 2024 TOOLPORT. All rights reserved.