

VMAI INR 18650-26E

VMAI INR 18650-26E Replacement Battery User Manual

For VMAI G700 Electric Mop

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your VMAI INR 18650-26E Replacement Battery. This battery is designed exclusively for the VMAI G700 Electric Mop. Please read this manual thoroughly before installation and use to ensure proper function and longevity of your battery.

2. PRODUCT OVERVIEW

The VMAI INR 18650-26E is a lithium-ion replacement battery specifically engineered for the VMAI G700 Electric Mop. It is crucial to verify your mop model before purchasing and installing this battery. The G700 Electric Mop is typically identified by its green and white color scheme. This battery is compatible with G700 models manufactured from 2023 onwards. For older G700 models, please contact VMAI customer support for assistance.

Key Features:

- Designed for VMAI G700 Electric Mop (Green and White model).
- Provides power for cordless operation.
- Lithium-Ion technology.

3. SETUP: BATTERY INSTALLATION

Follow these steps to correctly install the replacement battery into your VMAI G700 Electric Mop:

1. Ensure the VMAI G700 Electric Mop is powered off and disconnected from any charging source.
2. Locate the battery compartment on your G700 Electric Mop. This is typically found at the base of the handle or within the main body of the mop.
3. If an old battery is present, carefully remove it by pressing any release tabs or unlatching the compartment cover.
4. Align the new VMAI INR 18650-26E battery with the battery slot, ensuring the connectors match.
5. Gently push the battery into the compartment until it clicks securely into place.

6. Close the battery compartment cover, if applicable.



Image: The VMAI INR 18650-26E battery is shown being inserted into the designated slot of the VMAI G700 Electric Mop, illustrating the installation process.

4. CHARGING THE BATTERY

To ensure optimal performance, fully charge the battery before its first use and whenever the power level is low.

1. Connect the VMAI G700 Electric Mop's charger to a power outlet.
2. Plug the charger into the charging port on the mop.
3. The charging indicator lights on the mop will illuminate, typically showing progress or a full charge status.
4. A full charge typically takes approximately 2.5 to 3 hours.
5. Once fully charged, disconnect the charger from the mop and the power outlet.

Long-Lasting & Detachable Battery

Longer working time! Cleans up to 2150 sq.ft area

40: mins Wet Mopping

60: mins Dry Mopping



2.5-3 hrs

Fast Charging

2550mAh



Image: The VMAI G700 Electric Mop is displayed, highlighting its long-lasting and detachable battery. Text indicates a working time of 40 minutes for wet mopping and 60 minutes for dry mopping, with a fast charging time of 2.5-3 hours for its 2550mAh capacity.

5. OPERATING WITH THE G700 MOP

Once the battery is installed and fully charged, your VMAI G700 Electric Mop is ready for use. Refer to your VMAI G700 Electric Mop's primary instruction manual for detailed operating procedures. The battery provides the necessary power for the mop's cordless cleaning functions.

6. MAINTENANCE AND CARE

Proper care extends the life of your battery:

- **Use Correct Charger:** Always use the original charger provided with your VMAI G700 Electric Mop. Using an incorrect charger can damage the battery and void the warranty.
- **Storage:** If storing the battery for an extended period, ensure it is partially charged (around 50%) and stored in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Deep Discharge:** Do not allow the battery to completely drain before recharging.
- **Cleaning:** Keep the battery contacts clean and free from dust or debris.

7. TROUBLESHOOTING

If you encounter issues with your replacement battery, consider the following:

- **Battery Not Charging:** Ensure the charger is properly connected to both the mop and the power outlet. Verify that the power outlet is functional. Check if the battery is securely installed in the mop.
- **Mop Not Powering On:** Confirm the battery is fully charged and correctly installed. If the issue persists, the battery may need replacement or there might be an issue with the mop itself.
- **Short Operating Time:** Battery performance can degrade over time. Ensure the battery is fully charged. If operating time remains significantly reduced, the battery may be nearing the end of its lifespan.
- **Compatibility Check:** Double-check that your VMAI G700 Electric Mop is the green and white model and from 2023 or later, as this battery is specifically designed for these versions. Incompatibility can lead to non-functionality.

For persistent issues, please contact VMAI customer support.

8. SPECIFICATIONS

Attribute	Detail
Model Number	INR 18650-26E
Battery Type	Lithium Ion
Compatibility	VMAI G700 Electric Mop (Green & White, 2023+ models)
Item Weight	7.4 ounces
Package Dimensions	4.13 x 3.82 x 3.15 inches

9. SAFETY INFORMATION

Observe the following safety precautions:

- Do not disassemble, puncture, or modify the battery.
- Do not expose the battery to water, fire, or extreme temperatures.
- Keep the battery away from children and pets.
- Dispose of used batteries according to local regulations.
- If the battery shows signs of damage, swelling, or leakage, discontinue use immediately and dispose of it safely.

10. WARRANTY AND SUPPORT

For warranty information or technical support regarding your VMAI INR 18650-26E Replacement Battery, please refer to the documentation included with your original VMAI G700 Electric Mop or contact VMAI customer service directly. Contact details can typically be found on the VMAI official website or through your purchase platform.

