

[manuals.plus](#) /› [HAUSWIRT](#) /› [HAUSWIRT Blender Attachment User Manual](#)

HAUSWIRT HM740

HAUSWIRT Blender Attachment User Manual

Model: HM740 Blender Accessory

For use with HAUSWIRT 5.3 qt Stand Mixer

1. INTRODUCTION

Thank you for choosing the HAUSWIRT Blender Attachment. This accessory is designed to seamlessly integrate with your HAUSWIRT 5.3 qt Stand Mixer (Model HM740), expanding its functionality to include blending tasks. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your new blender attachment. Please read these instructions carefully before first use and retain them for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the blender attachment.
- Ensure the blender attachment is securely installed on the stand mixer before operation.
- Always unplug the stand mixer from the outlet before assembling, disassembling, or cleaning the blender attachment.
- Do not operate the blender attachment with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Avoid contact with moving parts. Keep hands and utensils out of the blender jar while blending to prevent personal injury and/or damage to the blender.
- The blades are sharp. Handle with extreme care when cleaning the blender jar.
- Do not overfill the blender jar. Refer to the maximum fill line indicated on the jar.
- Do not blend hot liquids that exceed 140°F (60°C) as this may cause pressure buildup and result in scalding.
- This blender attachment is designed for household use only. Do not use outdoors.
- Supervise children closely when the appliance is in use.

3. PRODUCT COMPONENTS

The HAUSWIRT Blender Attachment consists of the following parts:

- **Blender Jar:** Made of durable glass with a 50.7 oz (approximately 1.5 liters) capacity. Features measurement markings for convenience.
- **Blade Assembly:** Equipped with 4 sharp stainless steel blades for efficient blending.
- **Lid:** Securely fits on top of the blender jar to prevent spills during operation.
- **Base Connector:** The part that connects the blender jar to the stand mixer's power hub.



Figure 3.1: HAUSWIRT Stand Mixer with Blender Attachment installed.



Figure 3.2: Close-up view of the glass blender jar.



Figure 3.3: View of the stainless steel blades inside the blender jar.



Figure 3.4: The blender attachment in use, preparing various beverages.

4. SETUP AND ASSEMBLY

Before first use, wash all removable parts of the blender attachment (jar, lid, blade assembly) in warm, soapy water, then rinse and dry thoroughly. Ensure the stand mixer is unplugged from the power outlet before assembly.

- 1. Prepare the Stand Mixer:** Ensure your HAUSWIRT 5.3 qt Stand Mixer (Model HM740) is clean and unplugged. Locate the power hub on the top of the stand mixer, usually covered by a cap.
- 2. Attach the Blender Jar:** Align the base connector of the blender jar with the power hub on the stand mixer. Gently push down and twist clockwise until the blender jar is securely locked into place. You should feel it click or firmly seat.
- 3. Verify Connection:** Once attached, gently try to lift the blender jar to ensure it is firmly seated and will not detach during operation.

For detailed instructions on operating your HAUSWIRT Stand Mixer, please refer to its dedicated user manual.

5. OPERATING INSTRUCTIONS

The blender attachment is ideal for preparing milkshakes, smoothies, and vegetable juices. Always ensure the stand mixer is stable on a flat, dry surface before operation.

- 1. Add Ingredients:** Place your desired ingredients into the glass blender jar. Do not exceed the 50.7 oz (1.5 liter) maximum fill line. For best results, add liquids first, then soft ingredients, and finally harder ingredients or ice.
- 2. Secure the Lid:** Place the lid firmly onto the blender jar. Ensure it is properly sealed to prevent splashing during operation.
- 3. Plug In and Select Speed:** Plug the stand mixer into a suitable power outlet. Use the speed control knob on your stand mixer to select the desired blending speed. The HAUSWIRT Stand Mixer features a Pulse Function, which is convenient for short bursts of blending or for crushing ice.
- 4. Start Blending:** Turn the stand mixer on. The blender attachment will begin to operate. Note that the mixer's main arm may also rotate during blending, which is normal operation for this integrated system.
- 5. Monitor and Adjust:** Blend until desired consistency is achieved. If ingredients stick to the sides, turn off the mixer, unplug it, remove the lid, and use a spatula to push ingredients down. Never use your hands or other utensils while the blender is running.
- 6. Finish Blending:** Once blending is complete, turn the speed knob to the "OFF" position and unplug the stand mixer from the power outlet. Carefully remove the blender jar from the stand mixer by twisting counter-clockwise and lifting.

Tip: For optimal blending of thicker mixtures, use the Pulse function in short bursts to help move ingredients towards the blades.

6. CARE AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your blender attachment.

- Immediate Cleaning:** Clean the blender jar and blade assembly immediately after each use to prevent food residue from drying and sticking.
- Dishwasher Safe:** The glass blender jar and lid are dishwasher safe, making cleaning convenient. Place them on the top rack of your dishwasher.
- Hand Washing:** For hand washing, disassemble the blade assembly from the jar by twisting the base. Wash the jar, lid, and blade assembly with warm, soapy water. Use a brush to safely clean around the blades. Rinse thoroughly and allow all parts to air dry completely before reassembling or storing.
- Base Connector:** Wipe the base connector of the blender attachment and the power hub of the stand mixer with a damp cloth. Do not immerse the stand mixer base in water.
- Storage:** Store the clean and dry blender attachment in a cool, dry place, away from direct sunlight.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Blender does not operate.	Not properly attached to stand mixer; Stand mixer not plugged in or turned on; Overload protection activated.	Ensure blender is securely twisted onto the power hub. Check if the stand mixer is plugged in and the power switch is on. If overloaded, unplug, remove some ingredients, wait 15 minutes, then try again.
Ingredients are not blending smoothly.	Too little liquid; Too many solid ingredients; Ingredients are too large; Incorrect speed setting.	Add more liquid. Reduce the amount of solid ingredients. Cut ingredients into smaller pieces. Increase speed or use the Pulse function.
Loud noise during operation.	Hard ingredients (e.g., ice, frozen fruit); Blender not seated correctly; Worn blades.	This can be normal with hard ingredients. Ensure the blender is securely attached. If noise is excessive or new, inspect blades for damage.
Mixer arm rotates while blending.	Normal operation.	This is an intended design feature of the HAUSWIRT Stand Mixer when the blender attachment is in use. No action is required.

If you encounter issues not listed here, or if the problem persists, please contact HAUSWIRT customer support.

8. PRODUCT SPECIFICATIONS

Brand	HAUSWIRT
Model Compatibility	HAUSWIRT 5.3 qt Stand Mixer (HM740)
Capacity	50.7 Oz (approximately 1.5 Liters)
Material	Glass Jar, Stainless Steel Blades
Product Dimensions	7.08"D x 8.26"W x 11.41"H (Blender Attachment only)
Item Weight	4.55 pounds
Dishwasher Safe	Yes (Jar and Lid)
Special Feature	Multiple Speeds (controlled by stand mixer)

9. WARRANTY INFORMATION

Specific warranty details for the HAUSWIRT Blender Attachment are typically provided with the original product packaging or can be found on the official HAUSWIRT website. Please retain your proof of purchase for any warranty claims. The warranty generally covers defects in material and workmanship under normal household use. For detailed warranty terms and conditions, please visit the official HAUSWIRT website or contact their customer service department.

10. CUSTOMER SUPPORT

If you have any questions, require assistance, or need to report an issue with your HAUSWIRT Blender Attachment, please contact HAUSWIRT customer support. You can typically find contact information on the HAUSWIRT official website or through the retailer where you purchased the product.

For more information about HAUSWIRT products, you may visit the [HAUSWIRT Store on Amazon](#).