



Manuals.plus /

- › [IKEA](#) /
- › [IKEA UTRUSTA Base Cabinet Carousel Instruction Manual](#)

IKEA IK.602.152.91

IKEA UTRUSTA Base Cabinet Carousel Instruction Manual

Model: IK.602.152.91

Brand: IKEA

1. PRODUCT OVERVIEW

The IKEA UTRUSTA Base Cabinet Carousel is designed to maximize the utility of corner cabinet spaces. It features two adjustable swivel shelves that allow for easy access and visibility of stored items. Its durable melamine construction ensures a scratch-resistant and easy-to-maintain surface, making it ideal for organizing kitchen essentials such as pots, pans, and dry goods.



Figure 1: The IKEA UTRUSTA Base Cabinet Carousel, showing its two swivel shelves and central support pole.

2. SAFETY INFORMATION

- Ensure all components are securely fastened during assembly to prevent instability.
- Do not exceed the maximum load capacity of **12 kg (26.5 lbs)** per shelf to avoid damage or injury.
- Keep small parts away from children during assembly.
- Use appropriate tools as specified in the assembly instructions.
- If any parts are missing or damaged, contact IKEA customer support.

3. PACKAGE CONTENTS

Verify that all parts are present before beginning assembly. Refer to the included assembly diagram for a complete list of

components.

- 2 x Melamine Swivel Shelves
- 1 x Central Support Pole (adjustable height)
- Mounting Hardware (screws, brackets, etc.)
- Assembly Instructions (separate document, usually pictorial)

4. SETUP AND ASSEMBLY

Assembly typically involves securing the central support pole within the corner cabinet and then attaching the two swivel shelves at desired heights. Detailed, step-by-step instructions with diagrams are provided in the separate assembly guide included with your product. It is recommended to have two people for easier installation.

4.1. Pre-Assembly Checks

- Ensure the cabinet dimensions are compatible with the carousel (Frame width: 87.5 cm, Frame depth: 88 cm, Diameter: 79 cm).
- Clear the work area and lay out all components.

4.2. Installation Steps (Summary)

1. Attach the base of the central support pole to the bottom of the cabinet.
2. Extend the central support pole to the desired height and secure its top to the cabinet ceiling.
3. Slide the swivel shelves onto the central pole at your preferred heights.
4. Secure the shelves in place using the provided locking mechanisms.



Figure 2: The UTRUSTA carousel installed in a corner base cabinet, demonstrating its use for storing kitchenware.

5. OPERATING INSTRUCTIONS

The UTRUSTA Base Cabinet Carousel is designed for simple operation. To access items, gently rotate either of the two shelves. The shelves swivel independently, allowing you to bring items from the back of the corner cabinet to the front for easy retrieval. Adjust the height of the shelves as needed to accommodate different sized items.

6. MAINTENANCE AND CARE

- **Cleaning:** Wipe the melamine shelves and metal components with a damp cloth and a mild cleaner. Dry thoroughly. Avoid abrasive cleaners or scouring pads, which can damage the surface.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Load Management:** Distribute weight evenly on the shelves and avoid placing excessively heavy items on one side.

7. TROUBLESHOOTING

Common Issues and Solutions

| Problem | Possible Cause | Solution |
|---------------------------------|---|---|
| Shelves do not swivel smoothly. | Dust or debris in the swivel mechanism; uneven weight distribution. | Clean the central pole and shelf mechanisms. Redistribute items evenly. |
| Carousel feels wobbly. | Support pole not securely fastened; shelves not properly locked in place. | Check and tighten all mounting screws for the central pole. Ensure shelves are correctly seated and locked. |
| Items fall off shelves. | Overloading; items placed too close to the edge. | Do not exceed the 12 kg load limit. Arrange items securely within the shelf boundaries. |

8. SPECIFICATIONS

| Feature | Detail |
|--------------------------------|----------------------------------|
| Model Number | IK.602.152.91 |
| Brand | IKEA |
| Material | Melamine (shelves), Metal (pole) |
| Color | White |
| Frame Width | 87.5 cm (34.4 inches) |
| Frame Depth | 88 cm (34.6 inches) |
| Diameter | 79 cm (31.1 inches) |
| Min. Height | 66.2 cm (26.1 inches) |
| Max. Height | 76.2 cm (30 inches) |
| Shelf Thickness | 1.2 cm (0.5 inches) |
| Max. Load Capacity (per shelf) | 12 kg (26.5 lbs) |

9. WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or technical support, please refer to the official IKEA website or contact IKEA customer service directly. Keep your proof of purchase for any warranty claims.

You can find more information and contact details on the official IKEA website www.ikea.com

