

[Manuals.plus](#) /

› [IKEA](#) /

› IKEA STÄLL Shoe Cabinet User Manual

IKEA STÄLL

IKEA STÄLL Shoe Cabinet User Manual

Model: STÄLL | Brand: IKEA

1. PRODUCT OVERVIEW

The IKEA STÄLL shoe cabinet is designed to help organize your shoes efficiently while saving floor space. Its slim design allows it to stand close to the wall, even above skirting boards, thanks to legs positioned only at the front. The cabinet features four compartments that provide adequate ventilation, helping to keep your shoes fresh and in good condition for longer.



Image: Front view of the IKEA STÄLL shoe cabinet in white, featuring four pull-down compartments.



Image: The STÄLL shoe cabinet positioned in an entryway, demonstrating its compact design against a wall.

2. SAFETY INFORMATION

For your safety, it is crucial to secure the STÄLL shoe cabinet to the wall. This prevents tipping, especially in households with children or pets. Always use the wall attachment device(s) provided with the product. Different wall materials require different types of fastening devices. Use fastening devices suitable for the walls in your home (not included). If you are unsure, consult a professional.

- Always follow the assembly instructions carefully, paying close attention to wall attachment steps.
- Do not overload the compartments.
- Ensure the cabinet is placed on a level surface.

3. SETUP AND ASSEMBLY

The IKEA STÄLL shoe cabinet requires assembly. Detailed assembly instructions are included in the product packaging. Please follow these instructions step-by-step to ensure correct and safe assembly.

1. Unpack all components and verify against the parts list in the assembly manual.
2. Assemble the cabinet frame according to the diagrams.
3. Attach the four shoe compartments.
4. **Crucial Step:** Secure the cabinet to the wall using appropriate fasteners for your wall type. This is essential for stability and safety.



Image: Detail of the cabinet's base and front legs, illustrating how it can sit flush against a wall above a skirting board.

4. OPERATING AND USAGE

The STÄLL shoe cabinet features four pull-down compartments designed to store shoes efficiently. Each compartment opens downwards, allowing easy access to your footwear. The design promotes air circulation, which is beneficial for shoe longevity.

- To open a compartment, gently pull the handle outwards and downwards.
- Place shoes inside with the toes pointing towards the back of the compartment for optimal storage.
- To close, push the compartment upwards until it clicks securely into place.
- While primarily designed for shoes, the compartments can also store other small items if desired, as shown in some examples.



Image: A compartment of the STÄLL cabinet opened, revealing shoes stored neatly inside.



Image: A compartment of the STÄLL cabinet used to store a laptop bag and other small items, demonstrating versatile storage.



Image: A close-up view of the integrated handle design on a compartment of the STÄLL cabinet.

5. MAINTENANCE

To keep your STÄLL shoe cabinet in optimal condition, follow these simple maintenance guidelines:

- Wipe clean with a damp cloth.
- Use only mild cleaning agents if necessary.
- Wipe dry with a clean cloth.
- Regularly check wall attachments to ensure they remain secure.

6. TROUBLESHOOTING

If you encounter any issues with your STÄLL shoe cabinet, consider the following common solutions:

Problem	Possible Cause	Solution
Cabinet feels unstable or wobbly.	Not properly secured to the wall or uneven floor.	Ensure the cabinet is securely attached to the wall using appropriate fasteners. Check if the floor is level; use shims if necessary.

Problem	Possible Cause	Solution
Compartments do not close smoothly.	Obstruction inside the compartment or mechanism issue.	Remove all items from the compartment and check for any obstructions. Ensure shoes are placed correctly and not overfilling the compartment. If the issue persists, refer to the assembly manual for mechanism details.
Shoes do not fit.	Shoes are too large or compartment is overfilled.	The cabinet is designed for typical shoe sizes. Larger boots or high heels might require specific placement or may not fit. Avoid overfilling.

7. SPECIFICATIONS

- Model Name:** STÄLL
- Brand:** IKEA
- Dimensions (Width x Depth x Height):** 96 cm x 17 cm x 90 cm (approximately 37.8"W x 6.69"D x 35.43"H)
- Number of Compartments:** 4
- Color:** White
- Material:** Engineered Wood
- Assembly Required:** Yes
- Mounting Type:** Floor Mount, Wall Mount (wall attachment recommended)

8. WARRANTY AND SUPPORT

- For information regarding warranty, spare parts, or further assistance, please contact IKEA customer service or visit your local IKEA store. You can also find more information on the official IKEA website.
- IKEA Official Website:** www.ikea.com
- Please have your proof of purchase and product details (Model: STÄLL, Brand: IKEA) ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question