

[Manuals.plus](#) /

› [Ikea](#) /

› IKEA KULLEN 5-Drawer Chest Instruction Manual (70x40x112 cm)

Ikea KULLEN IK.203.936.62

IKEA KULLEN 5-Drawer Chest Instruction Manual

Model: KULLEN IK.203.936.62 (70x40x112 cm)

1. PRODUCT OVERVIEW

The IKEA KULLEN 5-drawer chest is designed for storage in bedrooms and other living spaces. It features five spacious drawers for organizing clothing and other items. This manual provides essential information for safe assembly, operation, and maintenance of your KULLEN chest.



Image 1: The IKEA KULLEN 5-drawer chest, a white storage unit with five drawers.

2. SAFETY INFORMATION

WARNING: Furniture tipping hazard. To prevent tipping, this furniture must be permanently attached to the wall using the wall attachment device(s) provided. Different wall materials require different types of fastening devices. Use fastening devices suitable for the walls in your home (not included).

Always ensure the chest is placed on a level surface. Do not allow children to climb on drawers or shelves.



Image 2: The KULLEN chest of drawers positioned in a room, demonstrating typical placement and the importance of secure installation.

3. PACKAGE CONTENTS

The IKEA KULLEN 5-drawer chest is supplied in two packages. Please verify that all components are present before beginning assembly.

- **Package 1:** Length: 114 cm, Width: 40 cm, Height: 10 cm, Gross Weight: 19.36 kg, Net Weight: 18.48 kg
- **Package 2:** Length: 114 cm, Width: 39 cm, Height: 9 cm, Gross Weight: 19.46 kg, Net Weight: 18.44 kg

4. ASSEMBLY INSTRUCTIONS

Assembly of the KULLEN 5-drawer chest is required. Detailed pictorial instructions are included with your product. Please follow these instructions carefully, step-by-step, to ensure correct and safe assembly. It is recommended to have two people for assembly.

Ensure all screws and fittings are tightened securely. Periodically check and re-tighten fittings as necessary.




Image 3: Dimensional diagram of the KULLEN chest, indicating overall size and drawer depth.

5. OPERATION

The KULLEN chest features five smooth-gliding drawers designed for easy access to your stored items. The drawers are

equipped with a soft-close mechanism for quiet and gentle closing.

- To open a drawer, gently pull the handle.
- To close a drawer, push it until the soft-close mechanism engages, allowing it to close quietly.
- Avoid overloading drawers to ensure smooth operation and prevent damage.



Image 4: An open drawer of the KULLEN chest, illustrating its storage capacity for various items.

6. CARE AND MAINTENANCE

To maintain the appearance and longevity of your KULLEN chest, follow these care instructions:

- Wipe clean with a dry cloth.
- For stubborn marks, use a soft cloth dampened with water and a mild detergent. Dry thoroughly.
- Avoid using abrasive cleaners or chemical solvents, as these can damage the finish.



Image 5: A close-up of the KULLEN chest's white finish, highlighting the smooth surface for easy cleaning.

7. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	Ikea
Model Name	KULLEN
Model Number	IK.203.936.62
Color	White
Dimensions (Assembled)	Width: 70 cm, Depth: 40 cm, Height: 112 cm
Drawer Depth (Interior)	34 cm
Product Weight	42 kg
Special Features	Storage drawer, Soft-close mechanism
Assembly Required	Yes
Care Instructions	Wipe clean with a dry cloth

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question