Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JVC SPSA2BT

JVC SPSA2BT Portable Wireless Speaker User Manual

Model: SPSA2BT

Introduction | Package Contents | Product Overview | Setup | Operation | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

Thank you for purchasing the JVC SPSA2BT Portable Wireless Speaker. This speaker is designed to provide high-quality audio with the convenience of Bluetooth 5.0 connectivity and a durable, waterproof design. Please read this manual thoroughly before using the product to ensure proper operation and to maximize its lifespan.



Image: The JVC SPSA2BT Portable Wireless Speaker in black, featuring a mesh grille and a convenient carabiner clip for portability.

2. What's in the Box

Verify that all items are present in your package:

- JVC SPSA2BT Portable Wireless Speaker
- USB Charging Cable
- User Manual (this document)

3. Product Overview

3.1 Speaker Components

Familiarize yourself with the speaker's physical features and controls.




Image: A close-up view of the control buttons on the JVC SPSA2BT speaker, including Power, Mode, Volume Down, and Volume Up.

1. **Power Button ( )**: Press and hold to power on/off. Short press to play/pause music.

2. **Mode Button (M)**: Short press to switch between Bluetooth and other modes (if available).
3. **Volume Down Button (-)**: Short press to decrease volume. Press and hold for previous track.
4. **Volume Up Button (+)**: Short press to increase volume. Press and hold for next track.
5. **Microphone**: For hands-free calling.
6. **Charging Port**: USB port for charging the speaker.
7. **Carabiner Clip**: For easy attachment and portability.

4. Setup

4.1 Charging the Speaker

Before first use, fully charge the speaker. The charging time is approximately 14 hours.

- Connect the supplied USB charging cable to the speaker's charging port.
- Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
- The charging indicator light will illuminate during charging and turn off when fully charged.

7 hours



LONG BATTERY LIFE - Enjoy up to 7 hours of playtime with built- in rechargeable battery

JVC

Image: The JVC SPSA2BT speaker illustrating its 7-hour battery life with a visual representation of battery charge levels.

4.2 Bluetooth Pairing

Pair your speaker with a Bluetooth-enabled device to enjoy wireless audio.

1. Ensure the speaker is charged and powered off.
2. Press and hold the Power button () for approximately 3 seconds until you hear an audible prompt and the LED indicator flashes blue, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "JVC SPSA2BT" from the list of devices.
5. Once paired, the LED indicator will turn solid blue, and you will hear a confirmation tone.
6. The speaker will automatically connect to the last paired device when powered on, if the device's Bluetooth is active and within range (up to 33 feet).






Image: The JVC SPSA2BT speaker demonstrating its wireless connectivity with a smartphone, symbolizing superior wireless range.

5. Operating Instructions

5.1 Basic Functions

- **Power On/Off**: Press and hold the Power button () for 3 seconds.
- **Play/Pause Music**: Short press the Power button ().
- **Volume Control**: Short press the Volume Up (+) or Volume Down (-) buttons.
- **Next Track**: Press and hold the Volume Up (+) button.
- **Previous Track**: Press and hold the Volume Down (-) button.

5.2 Hands-Free Calling

When connected to a smartphone via Bluetooth:

- **Answer Call**: Short press the Power button ().
- **End Call**: Short press the Power button () during a call.
- **Reject Call**: Press and hold the Power button () for 2 seconds.

6. Maintenance and Care

6.1 Waterproof (IPX4) Information

The JVC SPSA2BT speaker is rated IPX4, meaning it is resistant to splashing water from any direction. This makes it suitable for outdoor use or near water, but it is not designed to be submerged in water.

- Do not submerge the speaker in water.
- Ensure the charging port cover is securely closed before exposing the speaker to water.
- If the speaker gets wet, wipe it dry with a soft cloth before charging or opening the port cover.



Image: Several blue JVC SPSA2BT speakers depicted with water droplets, highlighting their IPX4 waterproof capability.

6.2 General Care

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid dropping the speaker or subjecting it to strong impacts.

7. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in pairing mode (flashing blue LED). Turn on Bluetooth on your device. Move device closer to speaker (within 33 feet).
No sound or low volume.	Volume too low on speaker or device; speaker not connected.	Increase volume on both speaker and connected device. Re-pair the speaker if disconnected.
Sound distortion.	Device too far from speaker; interference.	Move device closer to speaker. Avoid obstacles between speaker and device.

8. Specifications

Feature	Detail
Model Name	SPSA2BT
Brand	JVC
Wireless Technology	Bluetooth 5.0
Bluetooth Range	Up to 33 feet (10 meters)
Water Resistance	IPX4 (Splashproof)
Battery Life	Up to 7 hours
Charging Time	Approximately 14 hours
Speaker Output Power	6 Watts
Product Dimensions	1.8"D x 5"W x 5"H
Item Weight	7.2 ounces
Included Components	User manual, USB Charging cable
Compatible Devices	Smartphone, Tablet, MP3 Player, Laptop

9. Warranty and Support

9.1 Limited Warranty

This JVC SPSA2BT Portable Wireless Speaker comes with a limited warranty. Please refer to the warranty card included in your package or visit the official JVC website for detailed warranty terms and conditions. Keep your purchase receipt as proof of purchase.

9.2 Customer Support

For technical assistance, product inquiries, or warranty claims, please contact JVC customer support. You can find contact information on the official JVC website or through the retailer where you purchased the product.

JVC Official Website: www.jvc.com

© 2024 JVC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08GWGGQ7K

More documents and user manuals: **https://manuals.plus/**