

[Manuals.plus](#) /

› [BABY JOY](#) /

› BABY JOY 3-in-1 Portable Pack and Play Instruction Manual

BABY JOY 156447

BABY JOY 3-in-1 Portable Pack and Play Instruction Manual

Model: 156447

IMPORTANT SAFETY INFORMATION

Read all instructions before assembly and use of the portable pack and play. Keep this manual for future reference.

- **WARNING:** Never leave child unattended.
- **WARNING:** Discontinue use of the bassinet feature when the infant begins to push up on hands and knees or has reached 20 lbs (9 kg), whichever comes first.
- **WARNING:** Discontinue use of the changing table feature when the infant has reached 24 lbs (10.8 kg).
- **WARNING:** Discontinue use of the playard feature when the child is able to climb out or has reached 33 lbs (15 kg) or 35 inches (89 cm) in height, whichever comes first.
- Ensure all locking mechanisms are engaged before placing a child in the product.
- Do not use this product if any parts are broken, torn, or missing.
- Only use the mattress/pad provided by the manufacturer. Never add a secondary mattress, pillow, comforter, or other padding for additional cushioning, as this can cause suffocation.
- Keep the product away from open flames, heaters, and other strong heat sources.
- Always place the product on a firm, horizontal, and dry surface.

PRODUCT COMPONENTS

The BABY JOY 3-in-1 Portable Pack and Play includes the following components:

- Main Playard Frame with Mesh Sides
- Removable Bassinet Insert
- Removable Diaper Changing Table
- Foldable Mattress Pad
- Toy Arch with 3 Hanging Toys
- Side Storage Shelf with Compartments
- Two Universal Wheels with Brakes
- Oxford Carry Bag

Multifunctional Pack and Play

Baby Bassinet

Baby Playpen

Changing Table

Figure 1: Overview of the 3-in-1 Portable Pack and Play components.

SETUP INSTRUCTIONS

Unfolding the Playard

1. **Step 1:** Stand the folded playard upright.
2. **Step 2:** Pull up and lock all four bed rails. Ensure each rail clicks into place. If a rail does not lock, lift the center of the floor slightly and try again.
3. **Step 3:** Verify all playard rails are securely locked.
4. **Step 4:** Press down firmly on the center of the playard bottom until it lies flat.

Important: Always ensure all four rails are locked before pressing down the bottom of the bed.

Tool-Free Folding & Unfolding

Carrying Bag Included



1 Keep playpen upright



2 Pull up and lock all 4 bed rails



3 Ensure all playpen rails are secured



4 Press down on playpen bottom



Attention: Install Playpen by pulling up all four sides and ensuring they are locked before pressing down the bottom of the bed

Figure 2: Step-by-step guide for unfolding the playard.

Installing the Bassinet

The bassinet is designed for newborns and provides a raised sleeping surface. It supports infants up to 20 lbs.

1. **Step 1:** Ensure the main playard is fully assembled and locked.
2. **Step 2:** Place the bassinet insert into the playard, ensuring the support hooks attach securely to the top rails of the playard.
3. **Step 3:** Lay the foldable mattress pad flat inside the bassinet insert.
4. **Step 4:** Attach the toy arch to the designated slots on the bassinet rails.

Baby Crib



3 Cute Hanging Toys

Included Foldable
Mattress



Figure 3: Bassinet setup with hanging toys.

Attaching the Diaper Changing Table

The changing table provides a convenient surface for diaper changes. It supports infants up to 24 lbs.

1. **Step 1:** Position the changing table over one of the playard's side rails.
2. **Step 2:** Secure the changing table by engaging its clips onto the playard rail. Ensure it is stable and level.
3. **Step 3:** Attach the side storage shelf to the exterior of the playard near the changing table for easy access to essentials.



Figure 4: Diaper changing table in use with storage.

OPERATING INSTRUCTIONS

Using the Playard

Once the bassinet and changing table are removed, the main playard can be used as an activity center for older infants and toddlers up to 33 lbs. The mesh sides provide visibility and ventilation.

Baby Playpen

360° breathable and visible mesh for better interaction



Figure 5: Baby in the playard activity center.

Engaging Wheel Brakes

The playard is equipped with two universal wheels for easy movement. To secure the playard in place, press down on the brake levers located on each wheel until they lock. To move the playard, lift the brake levers.



Figure 6: Lockable wheels for stability and mobility.

Folding for Storage and Travel

To fold the playard for storage or travel, reverse the unfolding steps:

1. **Step 1:** Remove the bassinet insert, changing table, and toy arch.
2. **Step 2:** Pull up the center of the playard floor.
3. **Step 3:** Release the locking mechanisms on each of the four rails by pressing the buttons or levers as indicated in the assembly diagram.
4. **Step 4:** Push the rails downwards to fold the playard compactly.
5. **Step 5:** Place the folded playard and mattress pad into the Oxford carry bag for transport.

MAINTENANCE AND CARE

- **Cleaning:** Clean the fabric parts (Oxford cloth, net yarn) with a damp cloth and mild soap. Allow to air dry completely. Do not use bleach.

- **Frame:** Wipe the iron pipes and plastic components with a damp cloth.
- **Mattress Pad:** The foldable mattress pad can be spot cleaned. Ensure it is completely dry before re-use.
- **Storage:** When not in use, store the playard in its carry bag in a clean, dry place.
- **Inspection:** Regularly check the product for loose fasteners, worn material, or broken stitching. Replace damaged parts immediately.

TROUBLESHOOTING

Problem	Solution
Playard rails do not lock.	Ensure the center of the playard floor is slightly raised before attempting to lock the rails. Pull up firmly on each rail until it clicks into place. Do not press the center of the floor down until all rails are locked.
Playard is difficult to fold.	Ensure the center of the playard floor is pulled up completely before attempting to release the rail locks. Release each rail lock individually.
Bassinet or changing table feels unstable.	Verify that all attachment clips are fully engaged with the playard rails. Ensure the playard itself is fully assembled and locked. Do not exceed the maximum weight limits for each component.
Hanging toys detach easily.	Ensure the toy arch is securely fastened to the designated slots. Regularly check the attachment points.

SPECIFICATIONS

Feature	Detail
Brand	BABY JOY
Model Number	156447
Age Range Description	Newborn to 36 months
Material Type	Iron Pipes, Oxford Cloth, Net Yarn
Item Weight	23.5 Pounds (approx. 10.66 kg)
Item Dimensions (Unfolded)	40 x 28.5 x 41 inches (approx. 101.6 x 72.4 x 104.1 cm)
Folded Size	30.5 x 9 x 9 inches (approx. 77.5 x 22.9 x 22.9 cm)
Maximum Weight Recommendation (Bassinet)	20 lbs (9 kg)
Maximum Weight Recommendation (Changing Table)	24 lbs (10.8 kg)
Maximum Weight Recommendation (Playard)	33 lbs (15 kg)
Color	Pink



Figure 7: Product dimensions and weight capacities.

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the contact details provided with your purchase or visit the official BABY JOY website. Keep your purchase receipt as proof of purchase.

