Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

proscenic M8 PRO

Proscenic M8 PRO Robot Vacuum and Mop User Manual

Model: M8 PRO | Brand: Proscenic

1. Introduction

The Proscenic M8 PRO is an advanced robotic vacuum cleaner and mop designed to provide efficient and automated floor cleaning. Equipped with laser navigation, powerful suction, and a self-empty dust disposal station, it offers a comprehensive solution for maintaining clean floors with minimal effort. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your device.

The M8 PRO is capable of simultaneously vacuuming and mopping, adapting to various floor types including hard floors and carpets. Its intelligent mapping system allows for customized cleaning plans, including setting no-go zones and specific room cleaning schedules via the Proscenic App.

2. Package Contents

Carefully unpack the box and ensure all items are present and in good condition. If any items are missing or damaged, please contact Proscenic customer support.

- Proscenic M8 PRO Robotic Vacuum Cleaner
- Automatic Suction Station with Dust Bag
- AC Adapter
- Dust Container (pre-installed in robot)
- Cleaning Brush
- 2 HEPA Filters (1 pre-installed, 1 spare)
- 2 Side Brushes (1 set pre-installed, 1 spare set)
- 2 Mopping Pads (1 pre-installed, 1 spare)
- User Manual
- Remote Control



Image: The Proscenic M8 PRO robot vacuum and its automatic dirt disposal station, along with the remote control and app interface.

3. Setup

3.1 Charging the Robot

Before first use, fully charge the robot vacuum. Place the robot on the charging pins of the automatic suction station. Ensure the power adapter is connected to the station and plugged into a wall outlet. The indicator lights on the robot will show charging status.

3.2 Installing Side Brushes

Attach the two side brushes to the corresponding posts on the bottom of the robot until they click into place.

3.3 Setting Up the Automatic Suction Station

Place the automatic suction station against a wall in an open area, ensuring there are no obstacles within 1 meter (3 feet) to the sides and 1.5 meters (5 feet) in front. This allows the robot to easily dock and empty its dustbin.



Image: Illustration of the automatic dirt disposal process, showing dust being transferred from the robot to the station's dust bag.

3.4 App Download and Connection

Download the 'ProscenicHome' app from the App Store (iOS) or Google Play Store (Android). Follow the in-app instructions to connect your M8 PRO to your home Wi-Fi network. **Note: The robot only supports 2.4GHz Wi-Fi networks.**



Image: A user interacting with the Proscenic app on a smartphone, highlighting compatibility with Amazon Alexa and Google Assistant.

4. Operating Instructions

4.1 Initial Mapping

For the first cleaning cycle, allow the robot to complete a full cleaning of your home to create an accurate map. Remove any obstacles that might hinder its movement. The advanced laser navigation system (LDS) will scan its surroundings 360 degrees to build a real-time map.



Image: An overhead view illustrating the robot vacuum's ability to map a home's layout and allow for scheduled cleaning of specific rooms at different times.

4.2 Cleaning Modes

- **Vacuuming:** The robot will vacuum floors, collecting dust and debris into its internal dustbin.
- **Mopping:** Attach the mopping module with a wet pad. The robot will dispense water and mop hard floors.
- **Vacuum & Mop Simultaneously:** For a deeper clean, the robot can vacuum and mop at the same time. Ensure the water tank is filled and the mopping pad is attached. The 5200mAh battery provides up to 200 minutes of run-time.



Image: The robot vacuum performing both vacuuming and mopping functions, with indicators for dust box and water tank capacities.

4.3 App Control Features

The Proscenic App provides comprehensive control over your M8 PRO:

- **Real-time Map:** View the robot's cleaning path and current location.
- **No-Go Zones & No-Mop Zones:** Draw virtual boundaries on the map to prevent the robot from entering specific areas or mopping carpeted areas.
- **Scheduling:** Set specific cleaning times and days for individual rooms or the entire house.
- **Suction Power & Water Flow Adjustment:** Customize cleaning intensity based on floor type and dirt level (4 adjustable water flow levels).
- **Spot Cleaning:** Direct the robot to clean a specific small area.



Image: A child playing near the robot vacuum, illustrating the concept of 'no-go zones' and 'no-mopping zones' set via the app, enabled by upgraded laser navigation.

4.4 Voice Control

The M8 PRO is compatible with Amazon Alexa and Google Assistant. Link your Proscenic account in the respective voice assistant app to control the robot with voice commands (e.g., "Alexa, start cleaning").

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your Proscenic M8 PRO.

5.1 Emptying the Robot Dustbin

Although the automatic suction station handles most dust disposal, it is recommended to periodically check and manually empty the robot's internal dustbin, especially if you frequently clean very dirty areas.

5.2 Replacing the Automatic Suction Station Dust Bag

The 4.3L disposable dust bag in the automatic suction station can hold debris for up to 180 days (approximately 8

weeks) depending on usage. Replace the dust bag when the indicator light on the station signals it is full.

5.3 Cleaning Brushes and Filters

- **Main Brush:** Remove the main brush cover and lift out the brush. Use the provided cleaning tool to remove hair and debris tangled around the brush. Clean weekly.
- **Side Brushes:** Check side brushes for tangled hair or debris. Remove and clean as needed. Replace if worn.
- **HEPA Filters:** Tap the HEPA filter to remove dust. Do not wash with water. Replace filters every 3-6 months, or more frequently with heavy use.

5.4 Cleaning Water Tank and Mopping Pad

- **Water Tank:** After each mopping session, empty any remaining water from the tank and allow it to air dry.
- **Mopping Pad:** Remove the mopping pad after each use and wash it thoroughly. Air dry before reattaching or storing.

5.5 Cleaning Sensors

Wipe the cliff sensors, wall sensors, and charging contacts on both the robot and the station with a clean, dry cloth to ensure proper operation.

6. Troubleshooting

If you encounter issues with your M8 PRO, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Robot does not start or respond.	Low battery; Power switch off; Robot stuck.	Charge the robot; Turn on the power switch; Clear any obstructions.
Robot cannot find charging station.	Station obstructed; Station not powered; Robot too far.	Ensure clear area around station; Check power connection; Manually place robot closer to station.
Poor cleaning performance.	Dustbin full; Brushes tangled; Filter clogged; Low suction setting.	Empty dustbin; Clean brushes; Clean/replace filter; Increase suction power via app.
Mopping function not working.	Water tank empty; Mopping pad dry; Water flow setting too low.	Fill water tank; Wet mopping pad; Adjust water flow level in app.
App connection issues.	Incorrect Wi-Fi band (not 2.4GHz); Incorrect password; Router issues.	Ensure 2.4GHz Wi-Fi; Re-enter password; Restart router and robot.
Robot gets stuck frequently.	Small obstacles; Loose cables; Cliff sensors dirty.	Clear floor of small items; Secure cables; Clean cliff sensors. Consider setting no-go zones.

7. Specifications

Feature	Specification
Brand	Proscenic
Model Number	M8 PRO
Product Dimensions	35 x 35 x 9.8 cm

Feature	Specification
Item Weight	6.7 kg
Dust Bag Capacity (Station)	4.3 liters
Power/Wattage	50 watts
Voltage	3.6 Volts
Noise Level	63 dB
Battery Life	Up to 200 minutes
Battery Cell Composition	Lithium
Navigation Type	Laser Distance Sensor (LDS)
Special Features	Cordless, Dirt Detection Sensor, No-Go Zone, Scheduling, Self-Emptying
Compatible Voice Assistants	Amazon Echo, Google Home
Surface Recommendation	Hard Floor, Carpets
Filter Type	HEPA

8. Warranty and Support

Proscenic offers a 1-year warranty on the M8 PRO Robotic Vacuum Cleaner. For technical support, warranty claims, or any inquiries, please contact Proscenic customer service.

Toll-Free Call (North & South America): +1(833) 313 1310

Hours: Monday - Friday, 6:00 AM - 3:00 PM ET (English only)

Please have your product model number (M8 PRO) and purchase information ready when contacting support.

© 2023 Proscenic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08GX53BWR

More documents and user manuals: **https://manuals.plus/**