



Manuals.plus /

› GOFORJUMP /

› GOFORJUMP 9601G 7-inch Car MP5 Stereo Player User Manual

GOFORJUMP 9601G

GOFORJUMP 9601G 7-inch Car MP5 Stereo Player User Manual

Model: 9601G

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your GOFORJUMP 9601G 7-inch Car MP5 Stereo Player. Please read this manual thoroughly before using the device to ensure proper functionality and safety.

The GOFORJUMP 9601G is a versatile car multimedia system featuring a 7-inch high-definition touchscreen, Bluetooth connectivity for hands-free calls and music streaming, FM/AM radio, GPS navigation support, and various media playback options including USB, SD card, and AUX input.

2. SAFETY INFORMATION

- Do not operate the device in a way that distracts you from driving. Always prioritize road safety.
- Ensure proper installation by a qualified professional to prevent damage to the device or vehicle.
- Avoid exposing the unit to extreme temperatures, direct sunlight for prolonged periods, or moisture.
- Do not attempt to disassemble or modify the unit. This may void the warranty and cause damage.
- Keep the volume at a safe level to avoid hearing damage and to remain aware of traffic sounds.

3. PACKAGE CONTENTS

Please verify that all items are present in the package:

- GOFORJUMP 9601G Car MP5 Stereo Player
- Power Cable
- Remote Control
- GPS Antenna (if included with specific model variant)
- User Manual
- 8GB Navigation Map Card (pre-installed or separate)

4. PRODUCT OVERVIEW

The GOFORJUMP 9601G features a single DIN chassis with a retractable 7-inch touchscreen display. Key components include:

- **7-inch High-Definition Touchscreen:** For intuitive control and media display.
- **Physical Buttons:** For essential functions like volume, mode, and power.
- **USB Port:** For media playback and charging mobile devices.
- **SD Card Slot:** For media playback and GPS map data.
- **AUX Input:** For connecting external audio sources.
- **GPS Antenna Port:** For navigation functionality.
- **Rear View Camera Input:** Supports reversing video input with priority display.



Image 1: Front view of the GOFORJUMP 9601G Car MP5 Stereo Player with its 7-inch screen extended, displaying a GPS navigation map. The main unit features control buttons and a rotary knob.

FM RADIO

FM Radio Function

Listen to the music or the broadcast or the news as you like, relax driving.

High quality digital stereo FM radio, support automatic search and record station. Convenient to listen the music and news you like



Image 2: Dimensional drawing of the GOFORJUMP 9601G Car MP5 Stereo Player, showing its single DIN size (172mm width, 50mm height) and the extended screen dimensions (189mm width, 114mm height).

5. INSTALLATION GUIDE

Important: Professional installation is highly recommended. Incorrect wiring can damage the unit or your vehicle's electrical system.

5.1 Wiring Diagram

Refer to the wiring diagram provided with your unit. Common connections include:

- **Yellow Wire (B+):** Connect to constant 12V power.
- **Red Wire (ACC):** Connect to switched 12V power (ignition).
- **Black Wire (GND):** Connect to vehicle chassis ground.
- **Blue Wire (ANT):** Connect to power antenna or amplifier remote turn-on.
- **Orange Wire (ILL):** Connect to vehicle illumination wire.
- **Brown Wire (BACK):** Connect to reverse light trigger for rear camera.
- **Speaker Wires:** Connect to vehicle speakers (ensure correct polarity).
- **GPS Antenna:** Connect to the dedicated GPS antenna port and mount the antenna in a location with

a clear view of the sky.

5.2 Mounting the Unit

1. Remove the existing car stereo from the dashboard.
2. Connect all necessary wiring harnesses to the GOFORJUMP 9601G.
3. Slide the unit into the single DIN opening in your dashboard.
4. Secure the unit using the provided mounting brackets or screws.
5. Reassemble the dashboard trim.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

Press the **POWER** button (usually a rotary knob) to turn the unit on or off. The screen will automatically extend upon power-on.

6.2 Main Menu Navigation

The 7-inch touchscreen provides access to all functions. Tap icons to select modes such as Radio, Bluetooth, Music, Video, GPS, AUX, and Settings.




Image 3: Examples of the GOFORJUMP 9601G user interface screens, including Bluetooth dialing, video playback, radio tuner, music player, wallpaper settings, and general settings with language options.

6.3 Bluetooth Operation

1. **Pairing:** Go to the Bluetooth menu. Enable Bluetooth on your mobile device and search for "GOFORJUMP" or "9601G". Select it and confirm pairing.
2. **Hands-Free Calling:** Once paired, you can dial numbers directly from the unit's screen or answer/end calls using the interface.
3. **Bluetooth Audio Streaming:** Play music from your paired phone through the car speakers. Control playback (play/pause, skip) from the unit.

BLUETOOTH HANDSFREE CALLS

Bluetooth handsfree calls,
make phone calls whenever you need.

Bluetooth handsfree calls, convenient and safe calling.

Connect your phone to the MP5 by the bluetooth,
easy to answer and hang up a calling, make driving safer.



Image 4: Illustration of the GOFORJUMP 9601G's Bluetooth hands-free calling feature, showing a smartphone connected to the car stereo for safe communication while driving.

6.4 Radio (AM/FM)

1. Select the **Radio** icon from the main menu.
2. Use the **SCAN** or **SEEK** functions to find stations.
3. Press and hold a preset button (P1-P6) to save the current station.
4. The unit supports automatic scanning and memory for up to 18 FM stations.

HIGH-DEFINITION BIG SCREEN IS COMING

7 INCH BIG SCREEN BLUETOOTH CAR MP5 PLAYER



Image 5: Screenshot of the GOFORJUMP 9601G's FM Radio interface, displaying the current frequency (87.50 MHz) and preset buttons for quick station access.

6.5 GPS Navigation

The unit comes with an 8GB navigation map card. Insert the card into the designated slot. Select the **GPS** icon from the main menu to launch the navigation software. The unit supports dual-zone function, allowing you to listen to music while navigating.

6.6 Media Playback (USB/SD/AUX)

- **USB/SD:** Insert a USB drive or SD card into the respective slot. The unit will automatically detect and allow playback of supported audio (DIS, MP3, WMA, ACC, OGG, WAV, RA, AC3, MP2, AMR, APE, FLAC) and video (AVI, MP4, FLV, PMP, RM, RMVB, MPG) formats.
- **AUX Input:** Connect an external audio device (e.g., smartphone, MP3 player) to the 3.5mm AUX input jack. Select the **AUX** mode to play audio from the connected device.

6.7 Steering Wheel Control

The unit supports steering wheel control functionality. Connect the steering wheel control wires from your vehicle to the corresponding input on the MP5 player. This allows for convenient control of volume, track skipping, and call management without taking your hands off the wheel.

STEERING WHEEL CONTROL

Support Steering wheel control function

Direction control wire connected to the MP5
,make it safer and more convenience.

Compatibility agreement with the original car:

Video/Audio/VOL +/VOL-/Last
song/Next song/Answer or
hang up phone calls/Turn on or off



Image 6: Diagram illustrating the steering wheel control function, showing how vehicle steering wheel buttons can be used to control the GOFORJUMP 9601G for functions like volume, track change, and call handling.

6.8 Settings

Access the **Settings** menu to customize various parameters:

- **Display:** Adjust brightness, contrast, and wallpaper.
- **Audio:** Access the electronic sound processing (EQ) settings, including multiple equalization modes, treble, and bass adjustments.
- **Language:** Select your preferred language for the user interface.
- **Time:** Set the system time and date.
- **Other:** General system settings.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the screen and unit. Do not use abrasive cleaners or solvents.
- **Software Updates:** Check the manufacturer's website for any available firmware updates to ensure optimal performance and new features.
- **Storage:** If storing the vehicle for an extended period, ensure the unit is powered off.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not power on.	No power connection; Blown fuse.	Check power wiring (B+, ACC, GND). Inspect and replace fuses if necessary.
No sound.	Volume too low; Mute activated; Incorrect speaker wiring.	Increase volume. Check if mute is active. Verify speaker connections.
Bluetooth not connecting.	Bluetooth not enabled on phone; Unit not in pairing mode; Interference.	Ensure phone Bluetooth is on and discoverable. Re-enter pairing mode on the unit. Try pairing in a different location.
GPS signal weak or lost.	Antenna obstruction; Antenna not properly connected.	Ensure GPS antenna has a clear view of the sky. Check antenna connection.
USB/SD media not playing.	Unsupported file format; Corrupted media; Drive not recognized.	Check file formats against supported list. Try a different USB drive/SD card. Reformat media if necessary.

9. SPECIFICATIONS

Feature	Specification
Model	9601G
Screen Size	7-inch High-Definition Touchscreen
Power Supply	DC 12V
Output Power	60 Watts (per channel, 2 channels)
Bluetooth	Integrated Bluetooth for hands-free calls and music streaming
Radio	AM/FM Stereo, 18 FM station memory
GPS Navigation	Supports GPS navigation with 8GB map card (included)
Audio Formats	DIS, MP3, WMA, ACC, OGG, WAV, RA, AC3, MP2, AMR, APE, FLAC (24Bit 96KHz WAV support)
Video Formats	AVI, MP4, FLV, PMP, RM, RMVB, MPG
Image Formats	JPEG
Connectivity	USB 2.0, SD Card, AUX Input (3.5mm Jack), Rear View Video Input
Special Features	Steering Wheel Control support, Electronic EQ, Loudness switch, USB charging for mobile phones

10. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact GOFORJUMP customer service. Keep your proof of purchase for warranty claims.

Manufacturer: GOFORJUMP

Model Number: 9601G