Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RYOBI B08GY97VJQ

RYOBI 40-Volt Cordless Jet Fan Leaf Blower Instruction Manual

Model: B08GY97VJQ

Important Safety Information

Read and understand all instructions before using this product. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious personal injury.

- Always wear eye protection with side shields marked to comply with ANSI Z87.1.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- Keep children and bystanders away while operating a power tool.
- Avoid unintentional starting. Ensure the switch is in the off-position before connecting to battery pack, picking up or carrying the tool.
- Use the correct tool for your application. Do not force the tool.
- Disconnect the battery pack from the tool before making any adjustments, changing accessories, or storing power tools.
- Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.
- Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation.
- Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed.
- This product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm. Wash hands after handling.

Product Overview

The RYOBI 40-Volt Lithium-Ion Cordless Variable-Speed Jet Fan Leaf Blower is designed for efficient clearing of leaves and debris. This bare tool unit requires a RYOBI 40-Volt battery and charger (sold separately) for operation.

Key Features

- **40-Volt Lithium-Ion Power:** Provides cordless convenience and strong performance.
- **Variable-Speed Trigger:** Allows for precise control over airflow.
- **Jet Fan Technology:** Delivers powerful air volume for effective clearing.
- **Turbo Button:** Provides an extra burst of power for stubborn debris.
- **Lightweight Design:** Enhances user comfort during extended use.

Components

Refer to the images below for a visual guide to the blower's components.



Front view of the RYOBI 40-Volt Jet Fan Leaf Blower, highlighting the nozzle and main body.



Side view of the RYOBI 40-Volt Jet Fan Leaf Blower, showing the handle, trigger, and battery compartment.



Rear view of the RYOBI 40-Volt Jet Fan Leaf Blower, displaying the air intake fan and 40V battery slot.



Side profile of the RYOBI 40-Volt Jet Fan Leaf Blower, illustrating its ergonomic design.

Setup

Unpacking

Carefully remove the leaf blower from its packaging. Inspect the unit for any damage that may have occurred during shipping. Ensure all components are present.

Battery Installation

1. Ensure the leaf blower is turned off and the trigger is not engaged.
2. Align the ribs on the battery pack with the grooves in the blower's battery port.
3. Slide the battery pack into the blower until it clicks securely into place.
4. To remove the battery, press the latch on the battery pack and pull it out.

Note: This unit is sold as a bare tool. A RYOBI 40-Volt Lithium-Ion battery and charger are required and sold separately.

Operating Instructions

Starting the Blower

1. Ensure a fully charged 40-Volt battery is securely installed.
2. Grip the handle firmly.
3. Press the variable-speed trigger to start the blower. The airflow speed will increase as you press the trigger further.

Using the Turbo Button

For maximum power to clear stubborn debris, press the turbo button located on the handle while operating the blower. Release the button to return to variable speed operation.

Optimal Use

- Sweep from side to side, moving debris in front of you.
- Use lower speeds for light debris and delicate areas, and higher speeds or turbo mode for heavier debris.
- Avoid blowing debris towards people or animals.



A person holding the RYOBI 40-Volt Jet Fan Leaf Blower, demonstrating its use in a yard. The image shows the blower in action, clearing leaves.



A person operating the RYOBI 40-Volt Jet Fan Leaf Blower outdoors, effectively moving a pile of leaves across a lawn.

Maintenance

Cleaning

1. Disconnect the battery pack before performing any cleaning.
2. Use a clean, damp cloth to wipe down the exterior of the blower.
3. Keep the air vents free of debris to prevent overheating. Do not immerse the blower in water.

Storage

- Store the blower in a dry, well-ventilated area, out of reach of children.
- Remove the battery pack from the blower before storing for extended periods.
- Store battery packs in a cool, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Blower does not start	Battery not installed correctly	Ensure battery is fully seated and latched.
	Battery not charged	Charge the battery pack.
	Overload protection activated	Release the trigger, wait a few seconds, then restart. Reduce load if possible.
Reduced airflow	Air intake or nozzle blocked	Disconnect battery, clear any obstructions from intake or nozzle.
	Low battery charge	Recharge or replace the battery pack.

If problems persist, contact RYOBI customer support.

Specifications

Brand: RYOBI

Model: B08GY97VJQ

Power Source: Battery Powered (40-Volt Lithium-Ion)

Air Speed: Up to 110 MPH

Air Volume: Up to 525 CFM

Weight (Tool Only): Approximately 8 Pounds

Dimensions: 20"L x 10"W x 13"H

Special Feature: Cordless, Variable Speed, Jet Fan Technology, Turbo Button

UPC: 046396033123

Specifications are subject to change without notice.

Warranty and Support

For detailed warranty information, product registration, or technical support, please visit the official RYOBI website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

You can typically find support information at: www.ryobitools.com

© 2024 RYOBI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08GY97VJQ

More documents and user manuals: **https://manuals.plus/**