

Manuals.plus /

› Eureka Forbes /

› Eureka Forbes Compact 700 Watts Powerful Suction & Blower Vacuum Cleaner User Manual

Eureka Forbes GFCDSFPCM00000

Eureka Forbes Compact 700 Watts Vacuum Cleaner User Manual

Model: GFCDSFPCM00000

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance. Retain this manual for future reference.

- Always ensure the power supply matches the voltage specified on the rating label.
- Do not use the vacuum cleaner to pick up water or wet substances, as this is a dry vacuum cleaner.
- Do not pick up flammable or combustible materials, hot ashes, or sharp objects.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Unplug from the electrical outlet when not in use and before cleaning or servicing.
- Do not operate with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- The Forbes range of vacuum cleaners comes with a thermal cut-off mechanism that automatically switches off the device for the safety of our customers and product. If the unit overheats, allow it to cool down before resuming operation.

2. PRODUCT OVERVIEW

The Eureka Forbes Compact 700 Watts Vacuum Cleaner is designed for efficient dry cleaning with powerful suction and a blower function.

2.1 Components and Features

- **700 Watts Motor:** Delivers powerful suction of 15.5 KPA for deep cleaning.
- **Blower Function:** High power blower with 16.6 litres/minute efficiency, useful for blowing dust from areas like window channels.
- **Washable HEPA Filter:** Traps minute dust particles up to 0.3 microns, ensuring ultra-clean expelled air.
- **Bagless Design:** Features a dust cup for easy disposal of collected dust.

- **Compact & Lightweight:** Ergonomic design for easy maneuverability.
- **4-meter Long Cord:** Provides extended reach for cleaning without frequent socket switching.

2.2 Included Accessories

The vacuum cleaner comes with a wide range of accessories for various cleaning needs:

- **2-in-1 Brush:** Ideal for cleaning couches, curtains, and cushions.
- **Crevice Nozzle:** Soft brush for cleaning keyboards and other electronic gadgets, and reaching tight spaces.
- **Hose Pipe:** Rugged 5 ft. extra long and lightweight hose for flexible cleaning.
- **Extension Tubes:** Extends reach by 7 ft. for cleaning high ceilings and fans.
- **Blower Nozzle:** Specifically designed to clean doors and window top edges.
- **Floor-cum-Carpet Brush:** Toggle easily between bare floor and carpet/rug cleaning, providing a mild polishing effect.



Image: The Eureka Forbes Compact Vacuum Cleaner unit shown with all its included accessories laid out, including the main unit, hose, extension tubes, and various nozzles.

POWERFUL SUCTION **700 WATTS**

FOR DEEP CLEANING



Image: The Eureka Forbes Compact Vacuum Cleaner being used with extension tubes and floor brush to clean a floor, demonstrating its powerful 700 Watts suction for deep cleaning.


2 IN 1 BRUSH

For couch, curtains, cushions etc.



EXTENSION TUBES

Clean high ceiling, fans with ease with the extension tubes that extends the reach by 7 ft.



CREVICE NOZZLE

Soft brush to clean keyboards & other electronic gadgets



BLOWER NOZZLE

To clean doors, windows top edges



HOSE PIPE

Rugged 5ft. extra long & light weight hose to help you clean the desired area with ease



FLOOR CUM CARPET BRUSH

Toggle easily between bare floor & carpets/rugs. Gives the floor a mild polishing effect




Image: An illustration showing the HEPA filter trapping minute dust particles and expelling ultra-clean air, highlighting its filtration capability.



Image: A diagram illustrating the various accessories included with the vacuum cleaner, such as the 2-in-1 brush, crevice nozzle, hose pipe, extension tubes, blower nozzle, and floor-cum-carpet brush, with descriptions of their uses.

3. SETUP

Follow these steps to set up your Eureka Forbes Compact Vacuum Cleaner:

1. **Unpacking:** Carefully remove all components from the packaging. Check for any damage or missing parts.
2. **Filter Installation:** Ensure the Washable HEPA Filter is correctly installed in the dust cup compartment. Refer to the markings for proper orientation.
3. **Attaching Accessories:** Depending on your cleaning task, select the appropriate accessory (e.g., extension tubes, floor brush, crevice nozzle). Firmly attach it to the suction inlet of the main unit. For blower function, attach the blower nozzle to the air outlet.
4. **Power Connection:** Unwind the 4-meter power cord and plug it into a suitable electrical outlet.

4. OPERATING INSTRUCTIONS

4.1 Suction Mode

1. **Preparation:** Ensure the dust cup is empty and the HEPA filter is clean and dry.
2. **Power On:** Press the power button located on the handle to turn on the vacuum cleaner.
3. **Cleaning:** Move the vacuum cleaner slowly over the surface to be cleaned. For optimal results, use steady, overlapping strokes.
4. **Accessory Use:** Use the appropriate accessory for different surfaces. For example, the floor-cum-carpet brush for floors and carpets, the crevice nozzle for tight corners, and the 2-in-1 brush for upholstery.
5. **Power Off:** Once cleaning is complete, press the power button to turn off the appliance and unplug it from the outlet.

4.2 Blower Mode

1. **Preparation:** Locate the air outlet on the vacuum cleaner.
2. **Attach Blower Nozzle:** Firmly attach the blower nozzle to the air outlet.
3. **Power On:** Plug in the vacuum cleaner and press the power button.
4. **Blowing:** Direct the airflow towards areas where dust needs to be blown away, such as window channels or hard-to-reach crevices.
5. **Power Off:** Turn off the appliance and unplug it after use.



Image: A person using the Eureka Forbes Compact Vacuum Cleaner with an attachment to clean a sofa, demonstrating its compact and powerful design for effective cleaning.



POWERFUL SUCTION **700 WATTS**

FOR DEEP CLEANING

Image: The Eureka Forbes Compact Vacuum Cleaner being used with extension tubes and a floor brush to clean a floor, emphasizing its 700 Watts powerful suction for deep cleaning.

5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

5.1 Emptying the Dust Cup

1. **Frequency:** Empty the dust cup after each use or when it reaches the MAX fill line.
2. **Procedure:** Disconnect the vacuum cleaner from the power outlet. Detach the dust cup from the main unit. Tip the dust cup over a waste bin to dispose of the contents.

5.2 Cleaning the Washable HEPA Filter

1. **Frequency:** Clean the HEPA filter regularly, especially if you notice reduced suction power.
2. **Procedure:** Remove the HEPA filter from the dust cup. Rinse the filter under running water until the water runs clear. *Do not use detergent or hot water.*
3. **Drying:** Allow the filter to air dry completely for at least 24 hours before re-installing. *Kindly ensure there are no traces of moisture or water before use.*
4. **Re-installation:** Once completely dry, re-install the HEPA filter into the dust cup and reattach the dust cup to the vacuum cleaner.

5.3 Cleaning the Exterior

- Wipe the exterior of the vacuum cleaner with a soft, damp cloth. Do not use abrasive cleaners or solvents.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	Not plugged in; Power outlet faulty; Thermal cut-off activated.	Check power cord connection; Try a different outlet; Allow unit to cool down for 30 minutes if overheated.
Reduced suction power.	Dust cup full; HEPA filter clogged; Hose or attachment blocked.	Empty dust cup; Clean/dry HEPA filter; Check hose and attachments for blockages and remove.
Unusual noise during operation.	Blockage in hose/attachments; Motor issue.	Check for and remove any blockages; If noise persists, contact customer support.
Unit overheats quickly.	Clogged filter; Prolonged use; Blockage.	Clean HEPA filter; Limit continuous operation time; Check for blockages. The thermal cut-off will activate for safety.

7. SPECIFICATIONS

- **Model Name:** Compact
- **Model Number:** GFCDSFPCM00000
- **Wattage:** 700 Watts
- **Suction Power:** 15.5 KPA
- **Blower Efficiency:** 16.6 litres/minute
- **Filter Type:** Washable HEPA Filter
- **Capacity:** 0.8 litres (Dust Cup)
- **Cord Length:** 4 meters
- **Product Dimensions:** 12.5L x 5.1W x 6.2H Centimeters
- **Item Weight:** 1 kg 340 g
- **Noise Level:** 80 dB
- **Color:** Red & Black
- **Form Factor:** Handheld
- **Special Features:** Bagless, Compact, Lightweight

8. WARRANTY AND SUPPORT

Your Eureka Forbes Compact 700 Watts Vacuum Cleaner comes with a 1-year warranty.

- **Warranty Period:** 1 Year from the date of purchase.
- **Extended Warranty:** Extended warranty plans are available for purchase (e.g., 1 Year Extended Warranty, 2 Year Extended Warranty).
- **Customer Support:** For service, repairs, or any product-related queries, please contact Eureka Forbes customer service. Refer to your purchase documentation for contact details or visit the official Eureka Forbes website.

