

Manuals.plus /

› BEEM /

› BEEM TEATIME II Stainless Steel Tea Strainer Instruction Manual

BEEM TEATIME II Edelstahl-Teesieb

BEEM TEATIME II Stainless Steel Tea Strainer

Instruction Manual

INTRODUCTION

Thank you for choosing the BEEM TEATIME II Stainless Steel Tea Strainer. This accessory is designed to enhance your tea brewing experience with the BEEM TEATIME II 1.7 L water and tea kettle. This manual provides essential information for the safe and effective use of your tea strainer.

SAFETY INSTRUCTIONS

- Always handle the tea strainer with care, especially when hot.
- Ensure the tea strainer is correctly assembled before use.
- Keep out of reach of children.
- Do not use the tea strainer if it is damaged.
- This product is designed for use with the BEEM TEATIME II 1.7 L kettle. Do not attempt to use it with incompatible appliances.

PRODUCT OVERVIEW

The BEEM TEATIME II Stainless Steel Tea Strainer consists of a fine mesh sieve, a central rod, and a lid. It is designed to hold loose tea leaves for brewing directly within the BEEM TEATIME II kettle's glass carafe.



Image: Components of the BEEM TEATIME II Stainless Steel Tea Strainer, showing the disassembled parts and how they fit together. Small insets illustrate the strainer within the compatible kettle.



Image: The BEEM TEATIME II 1.7 L kettle, for which this tea strainer is an accessory. This image provides context for the compatible appliance.

SETUP AND INSTALLATION

1. **Assemble the Strainer:** Ensure the stainless steel sieve is securely attached to the central rod and the top plate.
2. **Add Tea Leaves:** Open the lid of the tea strainer and fill the sieve with your desired amount of loose tea leaves. The strainer has a capacity of approximately 60g of loose tea. Close the lid securely.
3. **Prepare Kettle:** Fill your BEEM TEATIME II 1.7 L kettle with water to the desired level, ensuring it does not exceed the maximum fill line.
4. **Insert Strainer:** Carefully place the assembled tea strainer into the glass carafe of the BEEM TEATIME II kettle. Ensure it sits properly within the kettle's opening.

BEEM
Designed for Life.



Image: A hand demonstrating the process of inserting the tea strainer into the BEEM TEATIME II kettle. Close-ups show the kettle's filter and the base controls.

OPERATING INSTRUCTIONS

1. **Heat Water:** Place the kettle with the inserted tea strainer (containing tea leaves) onto its base. Select your desired water temperature and start the heating process according to your BEEM TEATIME II kettle's instructions.
2. **Steep Tea:** Once the water reaches the selected temperature, allow the tea to steep for the recommended time based on the type of tea. The lid on the strainer helps ensure effective steeping.
3. **Serve:** After steeping, the tea is ready to be served directly from the kettle. The strainer keeps the loose tea leaves contained.
4. **Keep Warm:** If your BEEM TEATIME II kettle has a keep-warm function, you can utilize it to maintain the tea's temperature.



Image: The BEEM TEATIME II kettle with the stainless steel tea strainer inside, actively brewing tea. A cup of tea is shown next to the kettle.

CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and hygiene of your tea strainer.

1. **Disassembly:** After use, allow the tea strainer to cool down. Carefully remove it from the kettle. The stainless steel sieve can be separated from the rest of the tea strainer for thorough cleaning.
2. **Remove Tea Leaves:** Dispose of the used tea leaves.
3. **Washing:** Wash all parts of the tea strainer with warm, soapy water. Rinse thoroughly. The tea strainer is also dishwasher safe for convenient cleaning.
4. **Drying:** Allow all components to dry completely before reassembling or storing.



Image: The BEEM TEATIME II Stainless Steel Tea Strainer shown in its disassembled state, illustrating how it can be taken apart for easy and thorough cleaning.

TROUBLESHOOTING

- **Tea not brewing properly:** Ensure sufficient tea leaves are used and that the water temperature is appropriate for the tea type. Check that the strainer is fully submerged in the water.
- **Difficulty inserting/removing strainer:** Ensure the strainer is aligned correctly with the kettle's opening. Do not force it.

SPECIFICATIONS

Brand	BEEM
Model Number	BEEM TEATIME II Edelstahl-Teesieb
Material	Stainless Steel
Product Dimensions (L x W x H)	10 x 10 x 18 cm
Item Weight	60 Grams
Capacity (Loose Tea)	Approx. 60g
Dishwasher Safe	Yes
Country of Origin	China

WARRANTY AND SUPPORT

For information regarding warranty, spare parts, or technical support, please refer to the documentation provided with your BEEM TEATIME II kettle or contact BEEM customer service directly. Contact details can typically be found on the manufacturer's official website or on the product packaging.