

## Galanz GLR12TS5F

# Galanz GLR12TS5F 12.0 Cu.Ft. Dual Door Top Freezer Refrigerator User Manual

## WELCOME

Thank you for choosing the Galanz GLR12TS5F 12.0 Cu.Ft. Dual Door Top Freezer Refrigerator. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before use and keep it for future reference.

## IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury when using your refrigerator, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

## PRODUCT FEATURES

- **Space Saving & Large Capacity:** This top mount refrigerator measures 23.58 x 27.68 x 64.84 inches and offers a 12.0 cubic feet capacity, ideal for various living spaces.
- **Removable Glass Shelves:** Features glass shelves and a vegetable crisper drawer for organized food

storage. Shelves are removable for flexible organization.

- **Energy Saving & Low Noise:** Utilizes an R600a high-efficiency, low-energy consumption compressor for quick cooling and quiet operation. Includes bright LED interior lighting.
- **Adjustable Electrical Thermostat Control:** An adjustable electrical thermostat allows for precise temperature management in both the refrigerator and separate freezer compartment.

## COMPONENTS INCLUDED

- 1 x Refrigerator
- 5 x Removable Glass Shelf
- 1 x Crystal Crisper
- 1 x Power Cord
- 1 x User's manual
- 1 x Warranty Card

## PRODUCT DIMENSIONS AND SPECIFICATIONS

| Specification                    | Detail                       |
|----------------------------------|------------------------------|
| Brand                            | Galanz                       |
| Model                            | GLR12TS5F                    |
| Item Weight                      | 134.4 pounds                 |
| Product Dimensions               | 23.58 x 27.68 x 64.84 inches |
| Total Capacity                   | 12 Cubic Feet                |
| Refrigerator Fresh Food Capacity | 9.36 Cubic Feet              |
| Freezer Capacity                 | 2.65 Cubic Feet              |
| Annual Energy Consumption        | 346 Kilowatt Hours Per Year  |
| Installation Type                | Freestanding                 |
| Form Factor                      | Freezer Top                  |
| Color                            | Stainless Steel              |
| Voltage                          | 120 Volts                    |
| Defrost System                   | Frost Free                   |
| Number of Doors                  | 2                            |
| Shelf Type                       | Glass                        |
| Certification                    | DOE, UL                      |

For detailed dimensions, refer to the image below:



Image: Galanz GLR12TS5F Refrigerator with key dimensions (height, width, depth) and an Energy Guide label.

U.S. Government

Federal law prohibits removal of this label before consumer purchase.

# ENERGYGUIDE

## Refrigerator-freezer

- Automatic Defrost
- Top-Mounted freezer
- Without Through-the –Door Ice Service

Galanz

Models: GLR12TWEF  
GLR12TS5F  
GLR12TBKF

Capacity: 12 Cubic Feet

**Compare ONLY to other labels with yellow numbers.**  
Labels with yellow numbers are based on the same test procedures.

## Estimated Yearly Energy Cost

**\$42**

Cost Range

Models with  
similar features

\$37

\$51

All models

\$30

\$63

**346 kWh**

**Estimated Yearly Electricity Use**

- Your cost will depend on your utility rates and use.
- Cost range based only on models of similar capacity with automatic defrost, Top-Mounted freezer, Without Through-the –Door Ice Service.
- Estimated energy cost based on a national average electricity cost of 12 cents per kWh.

[ftc.gov/energy](http://ftc.gov/energy)

Image: Close-up of the Energy Guide label for the Galanz GLR12TS5F, showing an estimated yearly energy cost of \$42 and 346 kWh estimated yearly electricity use.

## SETUP AND INSTALLATION

### Unpacking

Carefully remove all packaging materials, including the base and any adhesive tape. Inspect the refrigerator for

any damage. Keep packaging materials away from children.

## Placement

- Place the refrigerator on a flat, solid surface strong enough to support it when fully loaded.
- Allow at least 4 inches of space between the back and sides of the refrigerator and the wall for proper air circulation.
- Avoid placing the appliance in direct sunlight or near heat sources like stoves or heaters.
- Ensure the refrigerator is level by adjusting the leveling feet. This helps with door alignment and proper operation.
- The door hinges are reversible (from left to right by default), allowing for flexible placement in your kitchen layout. Refer to the separate door reversal instructions if needed.

## Electrical Connection

Connect the refrigerator to a dedicated, properly grounded 120V, 60Hz AC outlet. Do not use an extension cord or adapter. Ensure the power cord is not pinched or damaged.

## Initial Operation

After installation, allow the refrigerator to stand upright for at least 2-4 hours before plugging it in. This allows the refrigerant to settle. Once plugged in, set the temperature control to the recommended setting and allow the appliance to cool for several hours before loading food.

## OPERATING INSTRUCTIONS

---

### Temperature Control

The refrigerator features an adjustable electrical thermostat control. Locate the control dial, typically inside the fresh food compartment or freezer. Adjust the dial to your desired cooling level. Higher numbers usually indicate colder temperatures. Allow several hours for the temperature to stabilize after adjustment.

### Storage Recommendations

- **Fresh Food Compartment:** Store fruits and vegetables in the crystal crisper drawer to maintain freshness. Utilize the removable glass shelves for dairy, meats, and beverages.
- **Freezer Compartment:** Ideal for frozen foods. Ensure packages are sealed to prevent freezer burn.

### Adjustable Shelves and Drawers

The glass shelves can be adjusted to different heights to accommodate various food items. To adjust, carefully lift the shelf and reposition it into the desired slots. The crisper drawer is designed for optimal humidity for produce.




Image: Interior view of the Galanz GLR12TS5F Refrigerator, showing the fresh food compartment with adjustable glass shelves, a crisper drawer, and door bins. The top freezer compartment is also visible with a wire shelf.

## MAINTENANCE

### Cleaning

- **Interior:** Unplug the refrigerator before cleaning. Wash the interior surfaces with a solution of warm

water and baking soda (2 tablespoons baking soda to 1 quart of water). Rinse and dry thoroughly.

- **Exterior:** Clean the exterior with a mild detergent and warm water. Wipe dry with a soft cloth. Do not use harsh chemicals or abrasive cleaners.
- **Door Gaskets:** Clean door gaskets regularly to ensure a proper seal.

### Defrosting

This refrigerator features a frost-free defrost system, eliminating the need for manual defrosting in the freezer compartment. However, occasional light frost may appear, which can be wiped away with a soft cloth.

### Power Outage

In case of a power outage, keep the refrigerator doors closed as much as possible to maintain internal temperature. Food should remain frozen for approximately 24 hours if the doors are kept closed.

### Moving the Appliance

Before moving, remove all food and secure all loose items inside. Unplug the power cord. Transport the refrigerator in an upright position to prevent damage to the cooling system.

### TROUBLESHOOTING

If you experience issues with your refrigerator, consult the table below for common problems and solutions. If the problem persists, contact customer support.

| Problem                       | Possible Cause                                                                                                       | Solution                                                                                                                            |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| Refrigerator does not operate | Not plugged in; circuit breaker tripped; temperature control set to OFF.                                             | Ensure plug is secure; reset circuit breaker; adjust temperature control.                                                           |
| Temperature is too warm       | Door opened too frequently; large amount of warm food added; poor air circulation; temperature control set too high. | Minimize door openings; allow food to cool before storing; ensure proper clearance; adjust temperature control to a colder setting. |
| Noisy operation               | Refrigerator not level; items vibrating inside; normal compressor operation.                                         | Adjust leveling feet; rearrange items; some noise is normal.                                                                        |
| Door does not close properly  | Refrigerator not level; door gasket dirty or damaged; food packages obstructing.                                     | Level the appliance; clean or replace gasket; rearrange food items.                                                                 |

### OFFICIAL PRODUCT VIDEO

Watch this video for an honest review and closer look at the Galanz GLR12TS5F Refrigerator.

Your browser does not support the video tag.

Video: A user provides an honest review of the Galanz GLR12TS5F Stainless Steel Refrigerator, highlighting its features and suitability for various needs.

### WARRANTY AND SUPPORT

## Warranty Information

Your Galanz GLR12TS5F Refrigerator comes with a Warranty Card. Please refer to this card for detailed information regarding warranty coverage, terms, and conditions. Keep your proof of purchase for warranty claims.

## Customer Support

For technical assistance, service, or warranty inquiries, please refer to the contact information provided on your Warranty Card or visit the official Galanz website. Ensure you have your model number (GLR12TS5F) and serial number ready when contacting support.