

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Gvirtue](#) /

› [Gvirtue Universal Remote Control for Samsung Smart TVs - Instruction Manual](#)

## Gvirtue Universal Remote Control

# Gvirtue Universal Remote Control for Samsung Smart TVs - Instruction Manual

## INTRODUCTION

---

This manual provides instructions for the Gvirtue Universal Remote Control, designed as a replacement for various Samsung Smart TV remotes. It covers setup, basic operation, and compatibility information to ensure a smooth user experience. This remote is not an original Samsung product and does not include voice control functionality.

## PRODUCT OVERVIEW

---

The Gvirtue Universal Remote Control offers a streamlined design with dedicated buttons for common functions and popular streaming services.




Image: Gvritue Universal Remote Control with labeled buttons. This diagram illustrates the function of each button on the remote.

- **Power Button:** Turns the TV on or off.
- **Menu Button:** Accesses the TV's main menu.
- **Ambient Mode Button:** Activates or deactivates Ambient Mode on compatible TVs.
- **Number Pad (123):** Displays a virtual number pad for direct channel input.
- **Directional Pad (Up/Down/Left/Right):** Navigates through menus and options.
- **Select Button:** Confirms selections.
- **Return Button:** Goes back to the previous screen or menu.
- **Smart Hub Button:** Opens the Samsung Smart Hub.
- **Play/Pause Button:** Controls media playback.
- **App Buttons (Netflix, Prime Video, Rakuten TV):** Provides one-click access to these streaming services.
- **Volume (VOL) Buttons:** Adjusts the TV's volume. Pressing and holding for 1 second or more may activate Accessibility Shortcuts.
- **Channel (CH) Buttons:** Changes TV channels. Pressing to view the Guide screen.

The Gvirtue Universal Remote Control requires no programming or complex setup. Simply install batteries to begin use.

## Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or outwards to open it.
3. Insert two (2) AA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



**Image:** Battery compartment for two AA batteries. Ensure correct polarity when inserting batteries.

The remote is now ready for use with your compatible Samsung TV.

## OPERATING INSTRUCTIONS

This remote functions similarly to your original Samsung TV remote for basic controls.

### Basic TV Control

- **Power:** Press the **Power** button to turn your TV on or off.
- **Volume:** Use the **VOL** up/down buttons to adjust the sound level. Press the center of the VOL button to mute.
- **Channel:** Use the **CH** up/down buttons to change channels. Press the center of the CH button to access the TV Guide.
- **Navigation:** Use the **Directional Pad** (up, down, left, right) to move through menus and the **Select** button to confirm.
- **Return:** Press the **Return** button to go back to the previous screen.
- **Smart Hub:** Press the **Smart Hub** button to open your TV's Smart Hub interface.

### Streaming Service Access

The remote features dedicated buttons for quick access to popular streaming applications:

- Press the **Netflix** button to launch the Netflix application.
- Press the **Prime Video** button to launch the Amazon Prime Video application.
- Press the **Rakuten TV** button to launch the Rakuten TV application.

# Long-Distance Precise Control

Strong signal by Infrared technology, further transmission for multi-angle induction



**Image:** Remote in use, demonstrating long-distance control. The remote utilizes infrared technology for precise control up to 12 meters (39 feet).

## COMPATIBILITY

This Gvirtue Universal Remote Control is designed to be compatible with a wide range of Samsung Smart TVs and replaces many original Samsung remote models.

### Compatible Samsung TV Types

- All Samsung LCD, LED, UHD, QLED, Frame, and Crystal Smart TVs.
- Includes LED TV, LCD TV, HDTV, UHD TV, SUHD TV, 3D TV, 4K TV, QLED TV, Smart TV.

# Universal Remote Control for All Samsung TVs



**Compatible for:**

**LED TV/LCD TV/ HDTV  
UHD TV/SUHD TV/3D TV  
4K TV/ QLED TV/ Smart TV**



**Image:** Remote control shown with a compatible Samsung TV, highlighting its universal compatibility across different Samsung TV technologies.

## Replaces Samsung Remote Models (Partial List)

- BN59-01312A, BN59-01312G, BN59-01241A, BN59-01245A, BN59-01259B, BN59-01259D, BN59-01259E, BN59-01260A, BN59-01265A, BN59-01266A, BN59-01267A, BN59-01274A, BN59-01292A, BN59-01296A, BN59-01298A, BN59-01310A, BN59-01310B, BN59-01312B, BN59-01312D, BN59-01312F, BN59-01312H, BN59-01312K, BN59-01312L, BN59-01312M, BN59-01312Q
- BN59-01178W, BN59-01199F, BN59-01289A, BN59-01301A, BN59-01302A, BN59-01315A, BN59-01315D, BN59-01315E, BN59-01315J, BN59-01223A, AA59-00784C, AA59-00666A, AA59-00594A
- And many more Samsung standard remote controls.

*Note: This remote does not support voice control functionality.*

## TROUBLESHOOTING

If you encounter issues with your Gvirtue Universal Remote Control, please refer to the following common solutions:

- **Remote Not Responding:**

- Ensure batteries are inserted correctly with the proper polarity (+/-).
  - Replace old batteries with fresh AA batteries.
  - Check for any obstructions between the remote and the TV's infrared receiver.
  - Confirm the remote is pointed directly at the TV.
- **Difficulty Opening Battery Compartment:**
    - The battery cover is designed to slide off. Apply firm, even pressure to slide it downwards or outwards. Refer to the battery installation image for guidance.
- **Specific Buttons Not Working:**
    - Some older Samsung TV models or specific TV settings might not fully support all advanced functions or dedicated app buttons. Verify your TV's compatibility.
    - Ensure the TV's software is up to date.

## SPECIFICATIONS

<b>Brand</b>	Gvirtue
<b>Model</b>	Universal Remote Control
<b>Color</b>	Black
<b>Product Dimensions</b>	0.01 x 0.01 x 0.01 inches (Approximate, as listed)
<b>Item Weight</b>	1.58 ounces
<b>Special Features</b>	Ergonomic, Lightweight, No Programming Required, Universal
<b>Max Number of Supported Devices</b>	1 (Television)



**Image:** Side and back profile of the remote control, illustrating its ergonomic design and dimensions.

## SUPPORT

For any questions or further assistance regarding your Gvirtue Universal Remote Control, please do not hesitate to contact us. We are committed to providing support for our products.