

## soges WK-JK80-OK

# soges WK-JK80-OK Computer Desk Instruction Manual

Model: WK-JK80-OK

## 1. INTRODUCTION AND SAFETY WARNINGS

---

Thank you for choosing the soges WK-JK80-OK Computer Desk. This manual provides essential information for the safe assembly, proper use, and maintenance of your new desk. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

### **Safety Warning:**

- Please assemble the desk carefully following the instructions to ensure stability.
- Avoid overloading the desk with excessive weight.
- Do not use the desk on uneven surfaces to prevent tipping.
- Keep small parts away from children during assembly.

## 2. PRODUCT OVERVIEW

---

The soges WK-JK80-OK Computer Desk is a versatile and compact furniture piece designed for various uses, including as a student desk, work desk, conference table, or even a dining table. Its minimalist design and sturdy construction make it suitable for small spaces.

### **Key Features:**

- Compact and multifunctional design.
- Sturdy metal frame with a finished coating.
- Durable 18mm thick particle board tabletop.
- Triangular support for enhanced stability and longevity.
- Easy to clean surface.



Figure 2.1: The soges WK-JK80-OK Computer Desk in Oak finish, showcasing its compact design suitable for various uses.

### 3. SETUP AND ASSEMBLY

---

The soges WK-JK80-OK desk is designed for easy self-assembly. Please ensure all components are present before starting.

#### Assembly Steps:

1. Unpack all components and verify against the parts list provided in the separate assembly instructions.
2. Attach the metal frame legs to the tabletop using the provided screws and tools. Ensure all connections are secure.
3. Install the triangular support bars between the legs for added stability.
4. Attach the adjustable feet to the bottom of each leg.
5. Carefully stand the desk upright. Adjust the feet to level the desk on uneven floors.

Refer to the detailed assembly instructions included in the packaging for specific diagrams and fastener information.




Figure 3.1: Technical drawing illustrating the dimensions of the soges WK-JK80-OK desk: 80cm length, 40cm width, and 75cm height. These dimensions are crucial for proper assembly and placement.

## 4. OPERATING INSTRUCTIONS

---

The soges WK-JK80-OK desk is designed for versatile use in various environments.

### Recommended Uses:

- **Computer Workstation:** Place your laptop, monitor, and peripherals on the spacious tabletop.
- **Study Desk:** Ideal for students, providing a dedicated area for books and study materials.
- **Dining Table:** Its compact size makes it suitable as a small dining table in kitchens or dining areas.
- **Display Stand:** Use it to showcase decorative items, plants, or other personal belongings.
- **Conference Table:** Can serve as a small meeting table in office or home office settings.

Always ensure the weight distribution on the desk is even to maintain stability.



Figure 4.1: The soges WK-JK80-OK desk configured as a workstation with a laptop and an optional small elevated shelf for accessories, demonstrating its practical application.

## 5. MAINTENANCE

---

Proper maintenance will ensure the longevity and appearance of your soges WK-JK80-OK desk.

### Cleaning Instructions:

- The tabletop is very easy to clean. Use a soft, damp cloth or a mild cleaning wipe.
- Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- Wipe up spills immediately to prevent staining or water damage.
- For the metal frame, use a dry or slightly damp cloth to remove dust and dirt.

### General Care:

- Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- Avoid placing hot items directly on the tabletop; use coasters or protective pads.
- Keep the desk away from direct sunlight and extreme temperature changes to prevent material degradation.

## 6. TROUBLESHOOTING

---

If you encounter any issues with your soges WK-JK80-OK desk, refer to the following common problems and solutions.

### Common Issues:

- **Desk is wobbly or unstable:**
  - Ensure all screws and fasteners are securely tightened.
  - Adjust the leveling feet at the bottom of each leg to compensate for uneven floor surfaces.
  - Verify that the triangular support bars are correctly installed.
- **Missing parts during assembly:**
  - Carefully check all packaging materials. Small parts can sometimes be overlooked.
  - If parts are genuinely missing, contact customer support with your purchase details and the specific missing components.
- **Surface scratches or damage:**
  - For minor scratches, furniture repair kits or markers matching the oak finish may be used.
  - Prevent future damage by using desk mats or protective covers.



Figure 6.1: Close-up view of the adjustable foot on the soges WK-JK80-OK desk, designed to ensure stability on uneven surfaces. Adjust these feet to eliminate wobbling.

## 7. SPECIFICATIONS

Feature	Detail
Brand	soges
Model Number	WK-JK80-OK
Color	Oak
Product Dimensions (L x W x H)	80 x 40 x 75 cm
Item Weight	9.12 Kilograms
Material	Wood (Particle Board), Metal
Top Material Type	Wood

Feature	Detail
Finish Type	Varnished
Desk Design	Computer Desk
Special Feature	Multifunctional, Stable structure with 18mm thick wooden panel

## 8. WARRANTY AND SUPPORT

---

soges is committed to providing high-quality products. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official soges website.

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact soges customer support through the retailer where you purchased the product or via the contact information provided on the official soges website.

Please have your model number (WK-JK80-OK) and purchase date ready when contacting support.