

Xbox Series X

Xbox Series X Console Instruction Manual

Model: 1882

Brand: Xbox

INTRODUCTION

Welcome to the Xbox Series X. This console is designed to deliver a premium gaming experience with advanced performance and features. This manual will guide you through the setup, operation, and maintenance of your console, ensuring you get the most out of its capabilities.



The Xbox Series X console and its accompanying wireless controller.

WHAT'S INCLUDED

Your Xbox Series X package contains the following items:

- Xbox Series X Console
- Xbox Wireless Controller
- Ultra High-Speed HDMI Cable
- Power Cable



The main components included in the Xbox Series X package: the console and the wireless controller.

INITIAL SETUP

Connecting the Console

1. Place the Xbox Series X console in a well-ventilated area. Ensure there is adequate space around the console for proper airflow.
2. Connect the Ultra High-Speed HDMI cable from the **HDMI OUT** port on the console to an HDMI input on your television or monitor.
3. Connect the power cable to the console's power input, then plug the other end into a power outlet.
4. Press the Xbox button on the front of the console or on the wireless controller to power on the system.



Découvrez la Xbox Series X, la plus rapide et la plus puissante Xbox de tous les temps.

The back of the Xbox Series X console, highlighting the HDMI, USB, Ethernet, and power ports for connection.

Controller Setup

1. Insert two AA batteries into the Xbox Wireless Controller.
2. Press and hold the Xbox button on the controller to turn it on.
3. Press the Pair button on the console (a small circular button near the front USB port) and then press and hold the Pair button on the controller (located on the top edge, near the USB port). The Xbox button on the controller will flash rapidly and then remain solid when successfully connected.



Quick Resume, des temps de chargement ultrarapides et une vitesse de jeu pouvant atteindre 120 FPS, le tout grâce à Xbox Velocity Architecture.

The Xbox Wireless Controller, illustrating its layout and buttons.

OPERATING INSTRUCTIONS

Powering On/Off

To power on the console, press the Xbox button on the console or the controller. To power off, hold the Xbox button on the controller and select "Turn console off" from the power menu, or press and hold the Xbox button on the console for 10 seconds.

System Navigation

Use the Xbox Wireless Controller to navigate the dashboard. The left stick controls movement, the A button confirms selections, and the B button cancels or goes back. The Xbox button opens the Guide menu for quick access to features and settings.

Installing Games

Insert a compatible game disc into the disc drive. Digital games can be downloaded from the Microsoft Store. Ensure you have sufficient storage space on the internal SSD or an expansion card.

Quick Resume

The Quick Resume feature allows you to seamlessly switch between multiple games and resume instantly from where you left off. This feature is enabled by the Xbox Velocity Architecture, minimizing wait times.

KEY FEATURES

The Xbox Series X offers a range of advanced features to enhance your gaming experience:

- **4K / 8K HDR Gaming:** Experience highly detailed worlds with native 4K HDR resolution. The console supports 8K HDR when connected to a compatible 8K TV, utilizing upscaling (4320p).
- **120 FPS Support:** Enjoy fluid and dynamic gameplay at up to 120 frames per second on compatible titles.
- **1TB SSD Storage:** Benefit from a 1TB Solid State Drive for rapid loading times and instant game resumption.
- **Raytracing:** Enhanced immersion with realistic lighting and reflections in supported Xbox games.
- **3D Spatial Audio:** Next-generation audio technology, including Dolby Atmos support for compatible games, places you at the center of the gaming experience.
- **100% Backward Compatibility:** Play a vast selection of Xbox One, Xbox 360, and original Xbox games directly on your Xbox Series X.
- **Smart Delivery:** Purchase a compatible Xbox game once and automatically receive the optimized Xbox Series X version when available at no additional cost.
- **Xbox Game Pass:** Access a large library of games for a monthly subscription (sold separately), including all Xbox Game Studios titles on day one.



12 teraflops de puissance de traitement graphique pure, DirectX ray tracing, un SSD personnalisé et des jeux en 4K*.

The Xbox Series X console, emphasizing its powerful gaming capabilities.

MAINTENANCE

Care and Cleaning

Use a soft, dry cloth to clean the exterior of the console. Avoid using liquid cleaners, abrasive materials, or chemical sprays. Regularly clean dust from ventilation areas to ensure optimal performance and prevent overheating.

Ventilation

Ensure the console is placed in an area with good airflow. Do not block the ventilation openings on the top, back, or sides of the console. Proper ventilation is crucial for preventing overheating and maintaining console longevity.

Storage

When not in use for extended periods, store the console in a cool, dry place away from direct sunlight and extreme temperatures. Disconnect all cables before storing to prevent damage.

TROUBLESHOOTING

Console Not Powering On

- Check if the power cable is securely connected to both the console and the power outlet.
- Ensure the power outlet is functional by testing it with another device.
- Try a different power cable if available to rule out a faulty cable.

No Video Output

- Verify the HDMI cable is correctly connected to the console's HDMI OUT port and an HDMI input on your TV/monitor.
- Ensure your TV/monitor is set to the correct HDMI input source.
- Try a different HDMI cable or a different HDMI port on your TV/monitor.

Controller Not Connecting


- Check the batteries in the controller and replace them if necessary.
- Re-pair the controller by pressing the pair buttons on both the console and the controller.
- Ensure there are no physical obstructions or excessive distance between the console and the controller.


SPECIFICATIONS



Detailed technical specifications for the Xbox Series X console:

Feature	Detail
Model Number	1882
Dimensions (L x W x H)	37.8 x 21.4 x 29.3 cm
Weight	6 kilograms
Storage	1TB Custom NVME SSD
Optical Drive	4K UHD Blu-ray Drive
Video Output	HDMI 2.1, 4K @ 120Hz, 8K HDR support
Audio Output	Dolby Digital 5.1, DTS 5.1, Dolby TrueHD with Atmos
Connectivity	Ethernet, Wi-Fi, USB 3.1 Gen 1
Power Supply	Internal
First Available Date	May 31, 2020




 XBOX ONE	<p><u>Xbox One Product and Regulatory Guide, Limited Warranty & Agreement</u></p> <p>Official product, safety, regulatory, and limited warranty information for the Microsoft Xbox One console and Kinect sensor, including setup, care, electrical safety, battery safety, and legal terms.</p>
<p>Product and Regulatory Guide Limited Warranty & Agreement</p>	

<div><div>How to Fix Your Xbox Problems</div><div><div>ifixit</div></div><div><div>Xbox One S Power Block Replacement</div><div>The guide will show how to replace the power block attached to the motherboard.</div><div>Written By: Eric Farnsworth</div></div><div></div><div><div>The information on this page is for informational purposes only. It is not intended to be used as a substitute for professional advice. If you are unsure, please consult a professional. © 2017 iFixit. All rights reserved.</div></div></div>	<div><div>Xbox One S Power Block Replacement Guide</div><div>Step-by-step instructions for replacing the internal power block of an Xbox One S console, including necessary tools and parts.</div></div>
<div><div>NOTE: This guide is for the Xbox One S console. It is not intended to be used as a substitute for professional advice. If you are unsure, please consult a professional. © 2017 iFixit. All rights reserved.</div></div>	<div><div>Xbox Controller Upgrade Instructions for Compatibility</div><div>Detailed instructions and download link for upgrading third-party controllers to ensure compatibility with the latest Xbox system updates. Includes video tutorial.</div></div>



[Guide to Upgrading Xbox Controller Firmware with DemoSDK](#)

Step-by-step instructions for downloading and using the DemoSDK application to upgrade your wireless Xbox controller firmware. Includes connection steps and troubleshooting tips.



[Xbox One and Kinect Sensor Product Guide: Safety, Warranty, and Usage](#)

Comprehensive guide for the Xbox One console and Kinect sensor, covering essential product safety information, limited warranty terms, usage guidelines, and regulatory compliance.



[Xbox One Accessory Regulatory and Warranty Guide](#)

Comprehensive guide covering safety, warranty, software license, and regulatory information for Xbox One accessories from Microsoft.

Regulatory and Warranty Guide
Guide réglementaire et de garantie
Guia regulamentar și garanție
Guia de normas e garantia
Guide de réglementation et de garantie
Sicherheit- und Garantiehinweise
Guida alla normativa e la garanzia
Informacje o wymogach prawnych i gwarancji
Guia de Regulamentações e Garantias
מדריך תקנות וזמנים