

Joiedomi L150C/3F-C6

Joiedomi C6 LED Christmas String Lights Instruction Manual

Model: L150C/3F-C6

1. SAFETY INFORMATION

Please read and understand all safety instructions before installation and use. Retain this manual for future reference.

- **UL Certified:** These lights are UL certified for safety.
- **Voltage:** Designed for 120V electrical systems.
- **Waterproof Rating:** The lights and wire have an IP44 rating, suitable for outdoor conditions including rain and snow.
- **Adapter:** The adapter is not waterproof and must be stored indoors or protected from water.
- **Cool Operation:** LED bulbs remain cool to the touch even after hours of operation, reducing burn risk.
- **Shatterproof Design:** C6 bulbs are made from durable material, designed to be impact-resistant.



RAINPROOF



SNOWPROOF



WINDPROOF



SUNPROOF

IP44
WATERPROOF

1. Avoid prolonged extreme weather or outdoor storage to protect product's service life.
2. The plug should be kept away from water

Image: Joiedomi C6 LED Christmas String Lights operating safely in snowy conditions, highlighting their IP44 waterproof rating.

SAFETY TO TOUCH

Surface Of Light Remains Cool



Image: Children interacting with the lights on a Christmas tree, illustrating the 'Safety to Touch' feature due to low heat emission.

2. WHAT'S INCLUDED

Your package contains the following items:

- 1 x 50.6 FT C6 LED Plug-in String Light (150 bulbs)
- 2 x Spare Bulbs
- 1 x Replacement Fuse



Image: The complete package contents, showing two bundles of 150 C6 LED string lights, along with an extra fuse, two extra bulbs, and the male and female plugs.

3. SETUP INSTRUCTIONS

3.1 Connecting Multiple Sets

These LED string lights are designed with safe male and female end-to-end connectors, allowing for easy extension. You can connect up to 30 sets of these lights, achieving a total lighted length of approximately 1518 feet (with about 4,500 LEDs).

1. Ensure both sets of lights are unplugged from the power source.
2. Align the male connector of one string with the female connector of another string.
3. Push firmly until the connectors are securely joined.
4. Plug the combined string into a 120V power outlet.

3.2 Placement and Installation

These lights are suitable for both indoor and outdoor use. The green wire blends well with natural foliage.

- **Outdoor Use:** Ideal for highlighting Christmas trees, lining porches, wrapping railings, or accenting gardens and patios. Use light clips for secure attachment to gutters or eaves.
- **Indoor Use:** Perfect for decorating Christmas trees, mantels, stair railings, and hallways.



**STEADY LIGHTS
(NO TWINKLE)**



**BULB LIFESPAN UP
TO 20000 HOURS**



**CONNECT UP
TO 30 SETS**



**HIGHLY
EFFICIENT**



**UV
RESISTANT**

Image: C6 LED string lights attached to a house gutter using light clips, demonstrating outdoor installation.



Image: Examples of indoor decoration with the string lights, showcasing their versatility on stair railings, mantels, and Christmas trees.

4. OPERATING INSTRUCTIONS

These lights provide a steady-on glow when plugged into a standard 120V electrical outlet.

1. Ensure all connections are secure.
2. Plug the male end of the string light into a compatible 120V power outlet.
3. The lights will illuminate with a steady, multicolor glow.

Your browser does not support the video tag.

Video: A demonstration of the Joiedomi C6 LED Strawberry Christmas Lights with green wire, showcasing their appearance and functionality.

5. MAINTENANCE

5.1 Replacing Bulbs

The C6 LED bulbs are removable and replaceable. If one bulb goes out, the others will continue to function normally.

1. **Unplug:** Always unplug the string lights from the power outlet before attempting any bulb replacement.
2. **Remove Old Bulb:** Gently pull the faulty bulb straight out from its socket.
3. **Insert New Bulb:** Take a spare bulb (2 included) and carefully insert it into the empty socket. Ensure it is fully seated.
4. **Test:** Plug the string lights back into the outlet to confirm the new bulb is working.



Image: A visual guide demonstrating the four simple steps to replace a bulb: unplug, remove old bulb, insert new bulb, and plug back in.

5.2 Replacing Fuses

A replacement fuse is included with your set to ensure continued operation. Refer to the plug for fuse compartment access and replacement instructions, typically located on the plug itself.

6. TROUBLESHOOTING

- **Lights Not Turning On:**

- Ensure the plug is fully inserted into a working 120V outlet.
- Check the fuse in the plug and replace if blown (refer to section 5.2).
- Verify all male and female connectors between multiple strings are securely connected.

- **Individual Bulbs Out:**

- As these lights feature removable and replaceable bulbs, an individual bulb failure will not affect the rest of the string. Replace the faulty bulb following the instructions in section 5.1.

- **Flickering Lights:**


- Check all bulb connections to ensure they are seated properly.
- Inspect the wire for any damage or kinks.

7. PRODUCT SPECIFICATIONS



150 C6 LED MULTICOLOR STRAWBERRY BULB

Voltage: 120V | Wattage: 7.2W
Green Wire Length per Strand: 50.6 ft
Lighted Length per Strand: 48.8 ft



The information is for ONE strand.
For multipack, please multiply the pack quantity.

Image: Detailed diagram illustrating the dimensions of the C6 LED bulbs and the spacing between them on the string.

Feature	Detail
Model Number	L150C/3F-C6
Bulb Type	C6 LED Strawberry Bulbs
Number of Bulbs	150
Light Color	Multicolor
Wire Color	Green
Total Length	50.6 FT
Lighted Length	48.8 FT
Bulb Spacing	3.93 inches

Feature	Detail
Power Source	Corded Electric
Working Voltage	120V
Wattage	6 watts (7.2W per set)
Indoor/Outdoor Usage	Indoor, Outdoor
Special Feature	Waterproof (IP44 rated lights/wire)
Connectable	Up to 30 sets

8. WARRANTY AND CUSTOMER SUPPORT

Each set of Joiedomi C6 LED Christmas String Lights undergoes rigorous testing to ensure quality and performance. We are committed to providing attentive and professional care.

Should you have any questions, require assistance, or encounter any issues with your string lights, please do not hesitate to reach out to our customer support team. Contact information can typically be found on the product packaging or the retailer's website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

