

[Manuals.plus](#) /

> [Tangkula](#) /

> Tangkula 3-Piece Patio Furniture Set Instruction Manual (Model AM3461HM)

Tangkula AM3461HM

Tangkula 3-Piece Patio Furniture Set Instruction Manual

Model: AM3461HM

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Tangkula 3-Piece Patio Furniture Set. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product.

SAFETY INFORMATION

Important Safety Precautions:

- Do not exceed the weight capacity of 360 lbs for each sofa chair to prevent tipping or damage.
- Do not exceed the weight capacity of 70 lbs for the coffee table to prevent tipping or damage.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Keep children away from the assembly area. Small parts may pose a choking hazard.
- Avoid placing hot items directly on the tempered glass tabletop without protection.
- Do not expose the rattan furniture set directly to heavy rain for extended periods. It is recommended to use a cover or store it in a dry place during inclement weather.

INCLUDED COMPONENTS

Verify that all components are present before beginning assembly:

- 2 x Sofa Chairs
- 1 x Coffee Table
- 2 x Seat Cushions
- 2 x Back Cushions

- 1 x User's Manual (this document)
- Assembly Hardware (screws, wrench, etc.)

SETUP AND ASSEMBLY

Assembly is required for this patio furniture set. Follow the instructions carefully. It is recommended to have two people for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.
2. **Identify Parts:** Refer to the parts list in the included user's manual to identify each component and piece of hardware.
3. **Assemble Chairs:**
 - Attach the backrest to the seat frame using the provided screws. Do not fully tighten screws at this stage.
 - Attach the armrests to the seat and backrest. Ensure all holes align.
 - Once all parts are loosely connected, place the chair on a flat surface and gradually tighten all screws to 100%. This helps ensure proper alignment.
4. **Assemble Coffee Table:**
 - Connect the side panels of the table.
 - Secure the top frame.
 - Place the tempered glass tabletop onto the table frame. The glass is fixed with suckers to prevent movement.
 - Tighten all screws securely.
5. **Add Cushions:** Place the seat and back cushions onto the assembled chairs.

Your browser does not support the video tag.

Video: Assembly guide for a 3-piece wicker set. This video demonstrates the general assembly process for similar patio furniture, including connecting frame components and securing screws. (Source: harmony-furniture)

Your browser does not support the video tag.

Video: Overview of the 3-piece patio furniture wicker chairs set. This video provides a visual demonstration of the assembled product and its features. (Source: Tangkula)

OPERATING INSTRUCTIONS

Your Tangkula 3-Piece Patio Furniture Set is designed for comfortable outdoor and indoor use.

- **Placement:** Position the furniture set on a flat, stable surface. Ensure there is adequate space around the furniture for safe movement.
- **Cushion Use:** The included seat and back cushions provide enhanced comfort. Arrange them as desired.
- **Tabletop Use:** The tempered glass tabletop is suitable for placing drinks, snacks, and small decorative items.




Image: The patio furniture set arranged outdoors by a pool, demonstrating typical use.



Image: The patio furniture set positioned indoors, highlighting its versatility for various environments.

MAINTENANCE

Proper maintenance will extend the life and appearance of your patio furniture set.

- **Cleaning the Frame:** Wipe the rattan and steel frame with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly.
- **Cushion Care:** The seat cushion covers are removable for easy cleaning. Hand wash or machine wash on a gentle cycle with cold water. Air dry only. Do not bleach or iron.
- **Glass Tabletop:** Clean the tempered glass tabletop with a damp cloth and a standard glass cleaner.
- **Weather Protection:** While the PE rattan is weather-resistant, prolonged exposure to harsh weather conditions (heavy rain, direct sunlight, snow) can affect its longevity. It is recommended to use a furniture cover or store the set indoors during extreme weather.
- **Hardware Check:** Periodically inspect all screws and bolts to ensure they remain tight. Re-tighten as needed to maintain structural integrity.



Please do not expose the rattan furniture set in the rain directly.
It's better to have a cover on it or take it in dry place in rainy days.




Image: Visual guidance on protecting the furniture from rain, suggesting the use of a cover or placement in a sheltered area.



Image: Detail of the thick, high-resilience cushion and its removable, washable cover, illustrating ease of maintenance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Parts do not align during assembly.	Screws were tightened prematurely.	Loosen all screws, align the parts, and then gradually tighten all screws evenly.
Furniture feels wobbly after assembly.	Screws are not fully tightened or unevenly tightened.	Ensure all screws are fully and evenly tightened. Place the furniture on a flat surface and apply gentle pressure to settle the frame before final tightening.
Glass tabletop slides or moves.	Suckers are not properly attached or are dirty.	Ensure the suckers are clean and firmly pressed onto the glass and table frame.

Problem	Possible Cause	Solution
Cushions appear flattened over time.	Normal wear and compression from use.	Fluff cushions regularly. Consider rotating them if possible to distribute wear.

SPECIFICATIONS

Feature	Detail
Model Number	AM3461HM
Brand	Tangkula
Color	Turquoise (as per current product variant)
Material	PE Rattan, Steel, Polyester Fabric, Sponge, Tempered Glass
Sofa Dimensions (L x W x H)	26.5" x 26.5" x 30" (67.3 cm x 67.3 cm x 76.2 cm)
Coffee Table Dimensions (L x W x H)	19.5" x 19.5" x 19.5" (49.5 cm x 49.5 cm x 49.5 cm)
Seat Height	14" (35.6 cm)
Armrest Height	23" (58.4 cm)
Sofa Weight Capacity	360 lbs (163 kg)
Table Weight Capacity	70 lbs (31.7 kg)
Assembly Required	Yes
Product Care	Wipe with Damp Cloth (frame), Washable (cushion covers)

◀ *Size*



Image: Detailed dimensions of the sofa chair and coffee table for reference.

Details about Wicker Sofa



Image: Close-up view of the wicker sofa details, including the curved backrest, raised feet, wide armrest, and anti-rust screws.

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included with your purchase or contact Tangkula customer service directly. Contact details may be available on the manufacturer's website or through your retailer.

Manufacturer Contact Information: Romeoville, IL 60446, US