

BELIFE RC1208

BELIFE RC1208 Replacement Remote Control Instruction Manual

For Medion TV Models

INTRODUCTION

This manual provides instructions for the BELIFE RC1208 replacement remote control, designed for specific Medion TV models. This remote control is pre-programmed and requires no complex setup for compatible devices. Please ensure your Medion TV model is listed as compatible before use.

SETUP

The BELIFE RC1208 remote control is designed for immediate use with compatible Medion TV models. Follow these simple steps to begin operation:

1. **Unpack the Remote Control:** Carefully remove the remote control from its packaging.
2. **Insert Batteries:** Open the battery compartment cover on the back of the remote control. Insert two AAA batteries (not included), ensuring the correct polarity (+ and -) as indicated inside the compartment. Close the battery cover securely.
3. **Ready for Use:** The remote control is now ready to operate your compatible Medion TV. No additional programming or pairing is required.

Important: This remote control is specifically designed for the indicated Medion TV models. It may not function correctly with other TV brands or Medion models not explicitly supported.

OPERATING INSTRUCTIONS

Familiarize yourself with the functions of each button on your BELIFE RC1208 remote control. Refer to the image below for button layout.







Image: Front view of the BELIFE RC1208 remote control, displaying all buttons and their labels.

Button Functions:

- **Power ()**: Turns the TV on or off.
- **Mute ()**: Mutes or unmutes the TV audio.
- **DISPLAY (1)**: Displays on-screen information such as current channel, time, and program details.
- **Star 2 (2)**: Functionality may vary depending on the TV model, often used for favorite channels or quick access.
- **EXIT**: Exits the current menu or on-screen display.
- **MEDIA**: Accesses the TV's media player or external media sources.
- **Rewind ()**: Rewinds media playback.
- **Play (▶)**: Starts or resumes media playback.
- **Fast Forward ()**: Fast forwards media playback.
- **Pause ()**: Pauses media playback.
- **Stop ()**: Stops media playback.
- **Record (●)**: Initiates recording (if supported by TV and connected device).
- **ZOOM (Red Button)**: Adjusts the screen zoom level.
- **REPEAT (Green Button)**: Repeats current media playback (e.g., track, chapter).
- **ROOT (Yellow Button)**: Accesses the root menu or specific functions.
- **TITLE (Blue Button)**: Displays the title menu of a DVD/Blu-ray or similar content.
- **MENU ()**: Opens the TV's main menu.
- **Rectangle Icon**: Often used for aspect ratio or picture mode selection.
- **LANG**: Changes the audio language or subtitle language during playback.
- **SIZE**: Adjusts the picture size or aspect ratio.
- **RETURN**: Returns to the previous screen or menu.
- **Directional Pad (Up, Down, Left, Right)**: Navigates through menus and options.
- **OK**: Confirms a selection or enters a menu item.
- **SOURCE**: Selects the input source (e.g., HDMI 1, AV, TV).
- **EPG**: Opens the Electronic Program Guide.
- **P+ / P- (Channel Up/Down)**: Changes the TV channel up or down.
- **INFO**: Displays information about the current program or selected item.
- **FAV**: Accesses favorite channels list.
- **Volume + / -**: Increases or decreases the TV volume.
- **Number Pad (0-9)**: Directly enters channel numbers or numerical values.
- **Text Buttons (abc, def, etc.)**: Used for text input in certain TV functions or smart features.
- **SLEEP**: Sets the TV's sleep timer.
- **Recycle/Loop Icon**: Often used for repeating a section or playlist.
- **PRESET**: Accesses preset settings or functions.

MAINTENANCE

To ensure the longevity and optimal performance of your BELIFE RC1208 remote control, follow these maintenance guidelines:

- **Battery Replacement:** Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Cleaning:** Use a soft, dry cloth to clean the remote control's surface. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the remote control in a dry place, away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote control from physical impact, as drops can damage internal components.

TROUBLESHOOTING

If you encounter issues with your BELIFE RC1208 remote control, try the following troubleshooting steps:

- **Remote Not Responding:**
 - Check the batteries. Ensure they are inserted correctly with the correct polarity.
 - Replace old batteries with new ones.
 - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
 - Make sure you are within the operating range (up to 10 meters) and pointing the remote directly at the TV.
- **Specific Buttons Not Working:**
 - Clean the remote control, especially around the problematic buttons, to remove any dirt or debris that might be preventing proper contact.
 - If only certain buttons are unresponsive after cleaning and battery replacement, the remote control may be faulty.
- **Remote Works with Some Functions but Not Others:**
 - Verify that your TV model is fully compatible with the RC1208 remote. Some advanced functions might not be supported by all TV models.
 - Consult your TV's original manual for specific function compatibility.

SPECIFICATIONS

Brand	BELIFE
Model Number	RC1208
Color	Black
Connectivity Technology	Infrared
Compatible Devices	Television (Specific Medion models)
Special Feature	Pre-programmed

Number of Buttons	35
Maximum Range	10 Meters
Battery Type	AAA (not rechargeable)




WARRANTY AND SUPPORT



The BELIFE RC1208 remote control comes with a **2-year warranty** from the manufacturer, BELIFE. This warranty covers defects in materials and workmanship under normal use. For warranty claims or customer service inquiries, please contact BELIFE customer support through your point of purchase or the official BELIFE website.

BELIFE is committed to providing excellent customer service and support for its products.

© 2023 BELIFE. All rights reserved. Information in this manual is subject to change without notice.

Related Documents - RC1208

	<p>BELIFE S11 Stick Vacuum Cleaner User Manual - Operation, Safety, and Troubleshooting</p> <p>Comprehensive user manual for the BELIFE S11 stick vacuum cleaner. Learn about product specifications, safety guidelines, assembly, operation, cleaning, and troubleshooting common issues. Get the most out of your BELIFE S11.</p>
	<p>BELIFE TV Wall Mount Installation Guide</p> <p>Step-by-step instructions for installing a BELIFE TV wall mount, including parts list and mounting procedures.</p>
	<p>Belife Cordless Vacuum Cleaner User Manual and Troubleshooting Guide</p> <p>Comprehensive guide for the Belife cordless vacuum cleaner, covering assembly, operation, troubleshooting, and maintenance for optimal performance. Learn how to clean filters, brush, and cyclone unit.</p>

	<p>Belife Cordless Vacuum Cleaner User Guide and Troubleshooting</p> <p>Comprehensive user guide for the Belife Cordless Vacuum Cleaner, covering assembly, operation, troubleshooting, and maintenance of filters and brush head. Features include 22Kpa suction, 45mins runtime, and LED touch screen.</p>
	<p>Belife BVC11 Cordless Vacuum Cleaner User Guide and Maintenance</p> <p>Comprehensive user guide for the Belife BVC11 Cordless Vacuum Cleaner, covering assembly, operation, troubleshooting, and detailed cleaning instructions for filters, dust cup, brush, and bearing. Learn how to maintain your vacuum for optimal performance.</p>
	<p>Belife BVC-V11/V12 Cordless Vacuum Cleaner User Manual</p> <p>User manual for the Belife BVC-V11/V12 Cordless Vacuum Cleaner, covering safety instructions, product parts, preparation, usage, cleaning, maintenance, technical specifications, troubleshooting, and warranty information.</p>