

Transformers F0691

Transformers War for Cybertron Kingdom WFC-K8 Optimus Primal Action Figure User Manual

Model: F0691

INTRODUCTION

This manual provides comprehensive instructions for the Transformers War for Cybertron Kingdom WFC-K8 Optimus Primal action figure. This collectible figure features a detailed design and converts between robot and gorilla modes. Please read these instructions carefully to ensure proper handling and enjoyment of your figure.

SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

This product is recommended for ages 8 and up. Adult supervision is advised for younger users. Keep small parts away from young children to prevent choking. Do not attempt to force parts during transformation, as this may cause damage.

SETUP

Upon receiving your Transformers Optimus Primal figure, follow these steps for initial setup:

1. **Unboxing:** Carefully remove the figure and its accessories from the packaging. Retain the packaging for future reference or storage.
2. **Initial Inspection:** Examine the figure for any visible defects or loose parts. Ensure all accessories, including the two Cyber Blades, are present.



Figure in its retail packaging, displaying both robot and beast modes on the box art.



The Optimus Primal figure in robot mode, displayed alongside its packaging.

OPERATING INSTRUCTIONS

The Optimus Primal figure converts between robot mode and Beast Wars-inspired gorilla mode in 22 steps. Refer to the detailed instructions on the back of the packaging for specific transformation sequences.

Robot Mode Features:

- **Cyber Blades:** The figure includes two Cyber Blade accessories. These can be held in the figure's hands or attached to its back for storage.
- **Forearm Cannons:** Hidden cannons are integrated into the forearms. These can be deployed for battle poses.
- **Mega Blasters:** Additional blasters are included, which can be used in conjunction with the forearm cannons.



Optimus Primal in robot mode, ready for action with his Cyber Blades.



Robot mode with forearm cannons extended, showcasing the figure's weaponry.

Gorilla Mode Features:

- **Detailed Fur Texture:** The gorilla mode features intricate molded fur texture for a realistic appearance.
- **Hip Articulation:** The figure's hip articulation allows for posing in an upright or crouching gorilla stance.
- **Weapon Storage:** The Cyber Blades can be attached to the figure's back in gorilla mode.



Optimus Primal in gorilla mode, posed in a crouching position.



Detailed view of Optimus Primal's gorilla mode head sculpt.



The back of the product packaging illustrates the 22-step transformation process between robot and gorilla modes.

Transformation Demonstration Video:

Your browser does not support the video tag.

Official video demonstrating the transformation of the Transformers War for Cybertron Optimus Primal figure. This video provides a visual guide to converting the figure between its two modes.

MAINTENANCE

To ensure the longevity and appearance of your Optimus Primal figure, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to gently wipe away dust and debris. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the figure in a cool, dry place away from direct sunlight and extreme temperatures. Prolonged exposure to sunlight can cause discoloration.
- **Handling:** Handle the figure by its main body parts. Avoid excessive force on joints or thin plastic components during play or transformation.

TROUBLESHOOTING

If you encounter any issues with your Optimus Primal figure, consider the following:

- **Tight Joints:** Some joints may be stiff initially. Gently work the joint back and forth to loosen it. Do not apply excessive force.
- **Transformation Difficulties:** If the figure is difficult to transform, refer to the step-by-step instructions on the packaging or the official video demonstration. Ensure all parts are aligned correctly before attempting to move them.
- **Loose Parts:** If a part becomes loose, gently try to reattach it. If it consistently detaches or appears broken, contact

customer support.

SPECIFICATIONS

Brand Name	Transformers
Model Name	GEN WFC K VOYAGER OPTIMUS PRIMAL
Model Number	F0691
Toy Figure Type	Action Figure
Character	Optimus Primal
Manufacturer	Hasbro
Age Range Description	Ages 8 and up
Size	7 Inch
Scale	Voyager
Material Type	Plastic
Item Weight	157 g
Item Dimensions (L x W x H)	9.49"L x 3.19"W x 6.73"H
Included Components	Figure

WARRANTY

Specific warranty information for this product is not provided in the available details. Please refer to the manufacturer's official website or contact their customer service for warranty terms and conditions.

SUPPORT

For further assistance, product inquiries, or to explore other Transformers products, please visit the official Transformers store or contact Hasbro customer support.

- **Transformers Store:** [Visit the Transformers Store on Amazon](#)
- **Manufacturer:** Hasbro

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question