

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [SEIKO](#) /
- › [SEIKO Presage Cocktail Time Automatic Watch SRPE45 User Manual](#)

## SEIKO SRPE45

# SEIKO Presage Cocktail Time Automatic Watch SRPE45 User Manual

Model: SRPE45

---

## 1. INTRODUCTION

---

Welcome to the world of SEIKO Presage. This manual provides essential information for the proper use and care of your new SEIKO Presage Cocktail Time Automatic Watch, model SRPE45. This timepiece combines traditional Japanese mechanical watchmaking with elegant design, featuring an automatic movement, date calendar, and 50-meter water resistance.



*Image: Front view of the SEIKO Presage Cocktail Time Automatic Watch SRPE45, showcasing its green patterned dial, golden numerals, and brown leather strap.*

## 2. SETUP

### 2.1 Unboxing and Initial Inspection

Upon receiving your watch, carefully remove it from its packaging. Inspect the watch for any visible damage. Protective films may be present on the crystal, case back, and strap buckle; gently peel these off before use.

### 2.2 Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (located at the 3 o'clock position) to the second click position.
2. **Set the time:** Rotate the crown to move the hands clockwise until the desired time is displayed. Ensure the AM/PM is correctly set by observing the date change around midnight.
3. **Set the date:** Push the crown back to the first click position. Rotate the crown counter-clockwise to adjust the date. Avoid setting the date between 9 PM and 4 AM, as this can damage the movement.

4. **Push in the crown:** Once the time and date are set, push the crown back into its normal position against the case to start the watch and ensure water resistance.

## STAINLESS STEEL CASE & BRACELET



*Image: A detailed diagram highlighting the watch's features, including the push-pull crown and date calendar.*

### 3. OPERATING YOUR WATCH

#### 3.1 Automatic Winding

Your SEIKO Presage SRPE45 is an automatic mechanical watch, meaning it is powered by the natural motion of your wrist. When worn regularly, the watch will self-wind and maintain its power reserve. It features a power reserve of approximately 41 hours.

#### 3.2 Manual Winding

If the watch has stopped or its power reserve is low, you can manually wind it. With the crown in its normal position (not pulled out), rotate it clockwise approximately 20-30 times. This will provide sufficient power to start the watch and build up the power reserve.



PRESAGE

## FEATURING AUTOMATIC MOVEMENT

Self-winding for accurate  
timekeeping, with 41 hours  
of reserve power

*Image: The SEIKO Presage watch from the front and back, illustrating its automatic movement visible through the transparent case back.*

### 3.3 Water Resistance

This watch is water-resistant up to 50 meters (5 bar). This means it is suitable for short periods of recreational swimming, showering, and general daily use. It is **not** suitable for diving, snorkeling, or high-impact water sports. Always ensure the crown is fully pushed in before any contact with water.

## VINTAGE LOOK

➤ Inspired by a Cocktail, the Mojito

The dial pattern is delicately embossed and perfectly harmonious with the gradation evoking a beautiful cocktail enjoyed with a vintage glass at the bar. The Arabic numerals are in the image of a vintage bottle's label and projects on the dial.



Image: The SEIKO Presage watch partially submerged in water, highlighting its 50-meter water resistance.

## 4. MAINTENANCE

### 4.1 Cleaning

To maintain the appearance of your watch, wipe the case and crystal with a soft, dry cloth regularly. For the leather strap, avoid prolonged exposure to water, direct sunlight, and harsh chemicals. If the strap gets wet, dry it thoroughly with a soft cloth and allow it to air dry completely before wearing.

### 4.2 Periodic Inspection

It is recommended to have your watch inspected by an authorized SEIKO service center every 2-3 years to ensure optimal performance and maintain water resistance. Gaskets and seals can degrade over time, affecting water resistance.

### 4.3 Storage

When not wearing your watch for extended periods, store it in a cool, dry place away from direct sunlight and strong magnetic fields. If the watch stops, simply wind it manually or wear it to restart the movement.

## 5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch has stopped or runs intermittently.	Insufficient power reserve.	Wear the watch regularly (8+ hours a day) or manually wind the crown 20-30 times.
Time is inaccurate.	Exposure to strong magnetic fields, or requires servicing.	Keep the watch away from magnets. If problem persists, consult an authorized service center.
Date does not change at midnight.	AM/PM setting is incorrect.	Advance the time by 12 hours.
Condensation inside the crystal.	Loss of water resistance.	Immediately take the watch to an authorized service center.

## 6. SPECIFICATIONS

- **Model Number:** SRPE45 (203540)
- **Movement:** Automatic (Caliber 4R35), Manual Winding Capability
- **Power Reserve:** Approximately 41 hours
- **Case Material:** Stainless Steel
- **Case Diameter:** 38 Millimeters
- **Case Thickness:** 11 Millimeters
- **Crystal:** Hardlex
- **Dial Color:** Green (Patterned with Golden Numerals)
- **Band Material:** Leather (Brown)
- **Band Width:** 20 Millimeters
- **Clasp Type:** Tri-fold push button release
- **Water Resistance:** 50 Meters (5 bar)
- **Functions:** Hour, Minute, Second, Date Calendar

## 7. WARRANTY AND SUPPORT

Your SEIKO Presage watch comes with a limited warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For service, repairs, or further assistance, please contact an authorized SEIKO service center or visit the official SEIKO website:

[Official SEIKO Website](#)

## 8. PRODUCT VIDEOS

### 8.1 Seiko Watch Style SRPE45

Your browser does not support the video tag.

*Video: A brief overview showcasing the style and aesthetic of the SEIKO Presage SRPE45 watch.*

### 8.2 Make a statement of refined taste with the Seiko Presage

Your browser does not support the video tag.

*Video: This video highlights the craftsmanship, heritage, and timeless style of the SEIKO Presage collection, emphasizing its refined aesthetic.*