MERITLINE Twin Over Full Bunk Bed with Trundle and Stairway

MERITLINE Twin Over Full Bunk Bed with Trundle and Stairway (Espresso)

Instruction Manual

Model: Twin Over Full Bunk Bed with Trundle and Stairway

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your MERITLINE Twin Over Full Bunk Bed with Trundle and Stairway. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Figure 1: Overall view of the MERITLINE Twin Over Full Bunk Bed with Trundle and Stairway in Espresso finish.

2. Safety Information

WARNING: Failure to follow these warnings could result in serious injury.

- Always follow the assembly instructions carefully.
- Ensure the bed frame's weight capacity is not exceeded. The upper bunk has a weight capacity of 200 lbs, the bottom bunk 250 lbs, and the trundle bed 200 lbs.
- The top bunk is not suitable for children under 6 years of age.
- Use only mattresses that are 6 inches thick or less for the top bunk to ensure adequate guardrail height. No box spring is needed.
- Periodically check and ensure that all connections are tight and secure.
- Do not allow horseplay on or under the bed.
- Always use the provided staircase for access to the upper bunk.

- Keep children away from the assembly area during construction.

IMPORTANT: This item comes in multiple boxes and may not be delivered at the same time. Please wait patiently for all boxes to arrive before beginning assembly.

3. Package Contents

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact MERITLINE customer service.

- Upper Bunk Frame Components
- Lower Bunk Frame Components
- Trundle Bed Frame Components
- Staircase with Storage Compartments
- Guardrails
- Slats for all beds
- Assembly Hardware (screws, bolts, dowels, etc.)
- Assembly Tools (e.g., screwdriver)

4. Assembly Instructions

Assembly is required for this bunk bed. Clear instructions and tools are provided with the product. It is recommended to have at least two adults for assembly. Do not overtighten screws during initial assembly; tighten fully once all components are in place.

UNIT:INCH




Figure 2: Product dimensions for planning your space.



Figure 3: The bunk bed can be separated into three individual beds for versatile room arrangement.

5. Operating Instructions

5.1 Trundle Bed Operation

The twin-size trundle bed is designed for easy access and storage. To use, gently pull the trundle frame out from under the bottom bunk. To store, push the trundle frame back into its position under the bottom bunk until it is fully concealed.

5.2 Staircase and Storage

The integrated staircase provides safe and convenient access to the upper bunk. Each step of the staircase features a hidden compartment for storage. Lift the lid of each step to access the storage space. These compartments are ideal for storing bedding, books, or toys.



Figure 4: The staircase features built-in storage compartments.

5.3 Safety Guardrails

The upper bunk is equipped with a full-length guardrail to prevent falls. Ensure the mattress on the upper bunk does not exceed 6 inches in thickness to maintain the effectiveness of the guardrail.



Figure 5: Upper bunk guardrail for enhanced safety.

6. Maintenance

- Regularly inspect all bolts, screws, and connections to ensure they remain tight. Tighten as necessary.
- Clean the wooden surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- Dust the bed frame regularly to prevent buildup.
- Avoid exposing the bed to excessive moisture or direct sunlight, which can cause warping or fading.

7. Troubleshooting

7.1 Bed Wobbles After Assembly

Ensure all bolts and screws are fully tightened. Check that all components are correctly aligned according to the assembly instructions. Disassemble and reassemble any sections that appear misaligned.

7.2 Trundle Bed Does Not Slide Smoothly

Check for any obstructions under the trundle bed. Ensure the wheels are clean and free of debris. Verify that the trundle frame is properly assembled and aligned.

7.3 Missing Parts

If any parts are missing upon delivery, please contact MERITLINE customer service immediately with your purchase details. Do not attempt to substitute parts.

8. Specifications

Feature	Detail
Brand	MERITLINE
Model	Twin Over Full Bunk Bed with Trundle and Stairway
Color	Espresso
Product Dimensions	91.73"L x 54.33"W x 61.4"H
Material	Solid Pine Wood and High-Quality MDF
Upper Bunk Mattress Size	Twin (Max 6" thickness)
Lower Bunk Mattress Size	Full
Trundle Bed Mattress Size	Twin
Upper Bunk Weight Capacity	200 lbs
Lower Bunk Weight Capacity	250 lbs
Trundle Bed Weight Capacity	200 lbs
Assembly Required	Yes
Included Components	Guardrails, Slats



Figure 6: Weight capacities for each bed section.

9. Product Overview Video

For a visual overview of the MERITLINE Twin Over Full Bunk Bed with Trundle and Stairway, please watch the following video:

Your browser does not support the video tag.

Video 1: Product overview demonstrating the features of the twin over full bunk bed with stairs and trundle.

10. Warranty and Support

For warranty information or customer support, please refer to the documentation included with your purchase or visit the official MERITLINE website. Our experienced customer service team aims to respond within 24 hours for any inquiries regarding missing parts or product issues.
You can also visit the MERITLINE Store on Amazon for more product information and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question