

[manuals.plus](#) /› [Senso](#) /› [Senso Wireless Earbuds - Model Wings TW10 User Manual](#)

Senso Wings TW10

Senso Wireless Earbuds

MODEL: WINGS TW10 USER MANUAL

This manual provides essential information for the safe and efficient use of your Senso Wireless Earbuds.

1. Introduction

Thank you for choosing Senso Wireless Earbuds. These True Wireless Stereo (TWS) earphones are designed for an active lifestyle, featuring a secure fit, high-quality audio, and sweatproof construction. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

2. What's in the Box

- Senso Wireless Earbuds (Left and Right)
- Portable Charging Case
- USB Charging Cable
- User Guide
- Multiple Sizes of Ear Tips



Image: The Senso Wireless Earbuds packaging, displaying the earbuds, charging case, user guide, USB charging cable, and various ear tip sizes.

3. Product Overview

The Senso Wings TW10 earbuds are designed for comfort and performance, featuring advanced audio technology and a durable build.

PREMIUM SOUND QUALITY

Latest apt-X Low-Latency Technology
Delivers a True Audiophile Experience To You



Massive 13mm Driver
Produces Intense Bass Levels
Dynamic Range, & Deep Sensitivity

Image: An exploded view of the earbud, illustrating the 13mm dynamic driver responsible for delivering premium sound quality with intense bass and dynamic range.



TRUE WIRELESS BLUETOOTH 5.0

**Latest Bluetooth 5.0 Chipset
with CVC 8.0 Noise Cancellation Technology**

Image: A detailed view of the earbud's internal circuitry, emphasizing the Bluetooth 5.0 chipset and CVC 8.0 Noise Cancellation Technology for stable connection and clear audio.

MONO OR DUAL

Pick up Either Earbud and Use Independently



BINAURAL CALLS

Microphone in Each Earphone for Crisp Clear Calls

Image: Two scenarios demonstrating the earbuds' versatility: one earbud in use for mono mode (e.g., driving) and both earbuds for dual mode (e.g., binaural calls).



IPX6 Waterproof
Resists Sweat, Water and Rain



Image: The earbuds are shown resisting water splashes, indicating their IPX6 waterproof rating, suitable for sweat, water, and rain.

4. Setup

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB charging cable to the case and a power source. The indicator lights on the case will show the charging status.

4.2 Initial Pairing

1. Ensure your earbuds are charged.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for available Bluetooth devices and select "SENSO Wings TW10" from the list.
5. Once connected, you will hear an audio prompt, and the earbud indicator lights will change.

Super Simple & Fast Pairing

*Auto Power On & Connect by Simply
Taking Out of the Charging Case*



Image: The earbuds are shown connecting to a smartphone, demonstrating the simple and fast pairing process upon removal from the charging case.

Your browser does not support the video tag.

Video: An official product video demonstrating the features and setup of the Senso WINGS Ultra Durable Premium Audio Wireless Earbuds.

5. Operating Instructions

5.1 Wearing the Earbuds

Place the earbuds in your ears and adjust the ear hooks for a secure and comfortable fit. The 60-degree twist lock system ensures they stay in place during physical activity.

Twist Lock Super Snug Fitting

60 Degree Twist Lock System

Creates a Comfortable and Snug Fit for All Ear Sizes



Image: A user demonstrating the secure fit of the earbuds with the 60-degree twist lock system, ideal for sports and exercise.

5.2 Basic Controls

The earbuds feature touch-sensitive controls for media playback and call management. Refer to the detailed user guide included in the box for specific touch commands for functions such as play/pause, skip track, answer/end call, and voice assistant activation.

5.3 Mono or Dual Mode

You can use either earbud independently (mono mode) or both together (dual mode) for a stereo audio experience. This flexibility allows for awareness of your surroundings when needed.

5.4 Call Functions

Each earbud is equipped with a microphone, enabling binaural calls for clear communication. Use the touch controls to answer, end, or reject calls.

6. Maintenance

6.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Avoid using abrasive cleaners or solvents.

6.2 Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Keep the device in a cool, dry place, away from extreme temperatures and direct sunlight.

7. Troubleshooting

7.1 Pairing Issues

- Ensure both earbuds are fully charged.
- Turn off Bluetooth on your device, then turn it back on.
- Forget the device from your Bluetooth list and attempt to pair again.
- If only one earbud connects, try resetting the earbuds (refer to the full user guide for specific reset instructions).

7.2 No Sound or Low Volume

- Check the volume levels on both your device and the earbuds.
- Ensure the earbuds are properly seated in your ears.
- Clean any debris from the earbud speakers and ear tips.

7.3 Charging Problems

- Verify the charging cable is securely connected to both the case and the power source.
- Ensure the charging contacts on the earbuds and inside the case are clean and free of obstruction.
- Try a different charging cable or power adapter.

8. Specifications

| Feature | Detail |
|-----------------------------------|---------------------------|
| Model Name | Wings TW10 |
| Connectivity Technology | Bluetooth 5.0, Wireless |
| Wireless Communication Technology | Bluetooth |
| Noise Control | Active Noise Cancellation |
| Water Resistance Level | Waterproof (IPX6) |
| Battery Life (Earbuds) | 8 Hours |
| Total Playtime (with Case) | Up to 30 Hours |
| Audio Driver Size | 10 Millimeters |
| Impedance | 32 Ohms |
| Control Type | Media Control |

| | |
|----------------|----------|
| Control Method | Remote |
| Ear Placement | In Ear |
| Form Factor | In Ear |
| Material | Silicone |
| Item Weight | 7 ounces |



Image: The earbuds and charging case illustrating the extended playtime: 6 hours for the earbuds and up to 30 hours total with the portable charging case.

9. Warranty and Support

Senso offers a standard warranty for its products. Additionally, you may be eligible for an extended warranty.

9.1 Extended Warranty

To convert to a two-year extended warranty, visit www.sensoshop.com/warranty. This must be claimed within 7 days of receiving your product.

9.2 Customer Support

For any product-related issues or inquiries, please contact Senso customer support. Details can be found on the warranty card included in your product packaging or on the official Senso website.

© 2026 Senso. All rights reserved.