

Estink Estinky9iwfze05p

Estink Portable Mini Travel Bluetooth Speaker User Manual

Model: BM3D

1. INTRODUCTION

Thank you for choosing the Estink Portable Mini Travel Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it thoroughly before use to ensure optimal performance and longevity of your device.

2. WHAT'S IN THE BOX

Your package should contain the following items:

- Bluetooth Speaker
- Hanging Rope
- Charging Cable
- Manual (this document)



Image: The Estink Bluetooth Speaker shown alongside its hanging rope and charging cable.



Image: A closer view of the hanging rope and the USB charging cable.

3. PRODUCT OVERVIEW

The Estink Bluetooth Speaker (Model BM3D) is a compact and portable audio device designed for clear sound and easy connectivity. Its luxury aluminum design provides a premium feel, and its small size makes it ideal for travel or everyday use.



Image: Front and rear view of the Estink Bluetooth Speaker, highlighting the speaker grille and the control panel with power button and charging port.



Image: The speaker with its compact dimensions labeled: 50mm (1.97in) width, 50mm (1.97in) depth, and 31mm (1.22in) height.

Compact body, clear sound

Can carry it around or hanging on your bag as fashionable accessory.



Image: The speaker depicted as lightweight and portable, suitable for carrying anywhere.

3W drive

Provides Hi-Fi stereo even at maximum volume.



Image: A visual representation of the speaker's 3W drive providing Hi-Fi stereo sound.

Video: An official product video demonstrating the Estink Bluetooth Speaker's features and usage.

4. SETUP

4.1 Initial Charging

Before first use, fully charge your speaker. Connect the provided charging cable to the speaker's charging port and the other end to a USB power source (e.g., computer USB port, wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged. A full charge takes approximately 2 hours.

4.2 Powering On/Off

- **To Power On:** Press and hold the power button (located on the bottom of the speaker) for a few seconds until you hear an audible prompt or see an indicator light.
- **To Power Off:** Press and hold the power button again for a few seconds until you hear an audible prompt or the indicator light turns off.

5. OPERATING INSTRUCTIONS

5.1 Bluetooth Pairing

To connect your speaker to a Bluetooth-enabled device:

1. Ensure the speaker is powered on and in pairing mode (usually indicated by a blinking blue light).
2. On your device (smartphone, tablet, laptop), go to the Bluetooth settings.
3. Search for available devices. The speaker will appear as "**BM3D**" or a similar name.
4. Select the speaker from the list to pair. Once connected, you will hear a confirmation tone, and the indicator light will become solid blue.
5. The speaker has an excellent connection range of up to 10 meters (33 feet).

5.2 TWS (True Wireless Stereo) Pairing

You can pair two Estink BM3D speakers together to create a true wireless stereo sound experience:

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. Press and hold the power button on **one** of the speakers for approximately one second. This speaker will become the primary speaker.
3. The two speakers will automatically search for and pair with each other. You will hear a confirmation tone once TWS pairing is successful.
4. Once TWS paired, connect your device to the primary speaker via Bluetooth as described in Section 5.1.

TWS loudspeaker

Activate true wireless stereo by pairing 2 speakers.
Pressing one of the button for a second connects two loudspeakers.



Image: Two speakers shown with a smartphone, illustrating the True Wireless Stereo (TWS) pairing capability.

5.3 Hands-free Calling

The speaker features a noise reduction microphone for hands-free calling when connected to your smartphone:

- When a call comes in, the speaker will ring.
- Press the power button once to answer the call.
- Press the power button once again to end the call.
- To reject an incoming call, press and hold the power button for a few seconds.

Noise reduction microphone

Luxury aluminum designed gives you excellent touching feel.
Noise reduction microphone for hands-free calling.



Image: The speaker in a car setting, demonstrating its use for hands-free calling with its noise reduction microphone.

6. CHARGING

The speaker is equipped with a 400mAh polymer lithium battery, providing approximately 2-3 hours of continuous playback on a full charge. When the battery is low, you may hear an audible alert or see a blinking indicator light.

- Connect the small end of the charging cable to the speaker's micro USB port.
- Connect the standard USB end to a 5V USB power source.
- Charging time is approximately 2 hours.

7. MAINTENANCE

- Keep the speaker dry. Do not expose it to water or excessive moisture.
- Clean the speaker with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid dropping or subjecting the speaker to strong impacts.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker is not in pairing mode or already connected to another device. Device's Bluetooth is off.	Ensure speaker is in pairing mode (blinking light). Disconnect from other devices. Turn on Bluetooth on your device. Move speaker closer to device.
No sound or low volume.	Volume on speaker or device is too low. Speaker not properly connected.	Increase volume on both speaker and connected device. Re-pair the speaker.
TWS pairing fails.	Speakers are too far apart or already connected to other devices.	Ensure both speakers are disconnected from other devices. Place them close together and try TWS pairing again.

9. SPECIFICATIONS

Feature	Detail
Model Name	BM3D
Brand	Estink
Speaker Type	Portable Speaker
Loudspeaker Output	3W
Bluetooth Version	4.2
Bluetooth Range	Up to 10 meters (33 feet)
Battery Type	Polymer Lithium Battery
Battery Capacity	400mAh
Playback Time	2-3 Hours
Charging Time	2 Hours
Frequency Response	20HZ-20KHZ
Signal-to-Noise Ratio	>= 80DB
Product Dimensions (LxWxH)	50x50x31mm (1.97x1.97x1.22 inches)
Item Weight	68.4g (2.41 oz)
Material	Aluminum
Control Method	Touch (Power Button)
Waterproof	No

10. WARRANTY & SUPPORT

This product comes with a Limited Warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support or customer service inquiries, please contact your retailer or the manufacturer directly. Keep your purchase receipt as proof of purchase for warranty claims.