

LEMEGA M5

LEMEGA M5P Hi-Fi Compact Stereo System User Manual

Model: M5 | Brand: LEMEGA

1. INTRODUCTION

The LEMEGA M5P is a versatile Hi-Fi compact stereo system designed to provide a comprehensive audio experience. It integrates multiple playback options including a CD player, DAB/DAB+ and FM digital radio, Internet radio with Spotify Connect, Bluetooth connectivity, and USB playback. This manual provides detailed instructions for setting up, operating, and maintaining your M5P system.

2. SAFETY INFORMATION

Please read all safety instructions before using the device. Keep this manual for future reference.

- **Power Source:** Use only the specified power adapter. Ensure the voltage matches your local power supply.
- **Ventilation:** Do not block any ventilation openings. Maintain adequate space around the unit for proper airflow.
- **Water and Moisture:** Do not expose the unit to rain, moisture, or dripping/splashing liquids. Do not place objects filled with liquids, such as vases, on the unit.
- **Heat:** Keep the unit away from heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
- **Cleaning:** Unplug the unit from the power outlet before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- LEMEGA M5P Hi-Fi Compact Stereo System
- Remote Control
- Power Adapter
- User Manual (this document)

4. PRODUCT FEATURES OVERVIEW

The LEMEGA M5P offers a range of features for diverse audio playback:

- **CD Player:** Integrated slot-in CD player compatible with CD, CD-R, and CD-RW discs.
- **Internet Radio:** Access to over 30,000 radio stations worldwide via Wi-Fi.
- **Spotify Connect:** Stream millions of music tracks directly from Spotify.
- **DAB/DAB+ & FM Radio:** Digital and analog radio tuning with superior sound quality and 40 station presets.
- **Bluetooth Connectivity:** Wireless audio streaming from smartphones, tablets, and other Bluetooth-enabled devices.
- **USB Playback:** Play MP3 files from a USB drive.
- **Dual Alarm Clock:** Two independent alarms with customizable sound sources (radio or music).
- **Remote Control:** Full-function remote for convenient operation.
- **Audio Output:** Stereo sound with 35 Watts maximum speaker output power.

5. SETUP

Follow these steps to set up your LEMEGA M5P system:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Placement:** Place the unit on a stable, flat surface. Ensure adequate ventilation around the unit.
3. **Connect Power:** Connect the power adapter to the DC IN port on the back of the unit, then plug it into a wall outlet.
4. **Initial Power On:** Press the Power button on the unit or remote control to turn it on.
5. **Language Selection:** Follow the on-screen prompts to select your preferred language.
6. **Network Setup (Wi-Fi):** The system will guide you through connecting to your Wi-Fi network. You may need to enter your Wi-Fi password manually if WPS (Wi-Fi Protected Setup) does not work.

6. OPERATING INSTRUCTIONS

6.1 CD Player Operation



Image: LEMEGA M5P system showing the slot-in CD player and remote control.

The M5P features an integrated slot-in CD player. Use the remote control for convenient playback.

1. **Insert CD:** Gently insert a CD (CD, CD-R, or CD-RW) into the slot. The system will automatically detect and begin playback.
2. **Playback Controls:** Use the Play/Pause, Skip Forward, and Skip Backward buttons on the unit or remote control to manage playback.
3. **Volume Adjustment:** Adjust the volume using the rotary knob on the unit or the Volume +/- buttons on the remote.
4. **Audio Settings:** Access the menu to adjust bass, treble, and equalizer settings for personalized audio.

6.2 DAB/DAB+ and FM Radio



DAB/DAB+AND FM RADIO

Enjoy all of your favourite DAB / DAB+ and FM stations with superior quality sound. Easy set-up and quick Auto-Scan to access your favorite stations quickly.

Image: LEMEGA M5P system displaying DAB radio station information.

Enjoy digital and analog radio broadcasts with clear sound.

1. **Select Mode:** Press the 'Mode' button to select DAB or FM radio.
2. **Auto Scan:** For first-time use or to find new stations, perform an auto scan. The system will automatically search and store available stations.
3. **Tune Stations:** Use the navigation buttons to browse through available stations.
4. **Presets:** Save your favorite stations by pressing and holding a preset number button (1-40). Recall saved stations by pressing the corresponding preset number button.

6.3 Internet Radio and Spotify Connect



SMART STREAMS

Stream and enjoy over 30,000 radios from local or worldwide by wifi streaming. The built-in Spotify connect, you can enjoy over 20 millions music tracks from Spotify connect freely.

Image: LEMEGA M5P system displaying Internet Radio options on its screen.

Access a vast selection of online radio stations and Spotify content.

1. **Select Mode:** Press the 'Mode' button to select Internet Radio.
2. **Browse Stations:** Navigate through categories, locations, or search for specific stations.
3. **Spotify Connect:** Ensure your M5P is connected to Wi-Fi. Open the Spotify app on your smartphone or tablet, play a song, and select the M5P as the playback device from the 'Devices Available' menu.

6.4 Bluetooth & USB Features



BLUETOOTH & USB FEATURES

With Wireless Bluetooth listen to your own music from your smartphone or tablet. With USB ports allowing both playback of MP3 files.

Image: LEMEGA M5P system wirelessly connected to a smartphone via Bluetooth.

Stream music wirelessly or play files from a USB drive.

1. Bluetooth Pairing:

- Select 'Bluetooth' mode on the M5P.
- Enable Bluetooth on your smartphone or tablet and search for 'LEMEGA M5P'.
- Select the M5P to pair. Once connected, you can stream audio from your device.

2. USB Playback:

- Insert a USB drive containing MP3 files into the USB port.
- Select 'USB' mode. The system will automatically detect and display the files.
- Use the navigation buttons to select and play tracks.

6.5 Dual Alarms Clock / Sleep / Snooze



DUAL ALARMS CLOCK/SLEEP/SNOOZE

Dual independent alarms to schedule your alarms/snooze/sleep timer, take your favorite radio stations or music as the alarm ringtone to wake you up.

Image: LEMEGA M5P system with its alarm clock function active, shown next to a sleeping person.
Set up to two independent alarms and utilize sleep/snooze functions.

1. Setting Alarms:

- Access the 'Alarm' menu through the system settings.
- Configure Alarm 1 and Alarm 2 independently, setting time, source (radio or buzzer), and volume.

2. **Snooze Function:** When an alarm sounds, press the 'Snooze' button to temporarily silence it for a short period.

3. **Sleep Timer:** Set a sleep timer to automatically turn off the system after a specified duration.

7. MAINTENANCE

Proper care ensures the longevity of your LEMEGA M5P system.

- **Cleaning:** Wipe the unit with a soft, dry, lint-free cloth. Do not use abrasive cleaners, waxes, or solvents.
- **CD Care:** Handle CDs by their edges. Clean dirty CDs with a soft, lint-free cloth, wiping from the center outwards.

- **Storage:** If storing the unit for an extended period, unplug it from the power outlet and store it in a cool, dry place.

8. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet faulty	Ensure power cable is securely connected; Try a different power outlet.
No sound	Volume too low; Mute activated; Incorrect source selected	Increase volume; Deactivate mute; Select the correct input source.
Cannot connect to Wi-Fi	Incorrect password; Router issue; Signal too weak	Verify Wi-Fi password; Restart your router; Move the unit closer to the router or use a Wi-Fi extender. If WPS fails, try manual password entry.
CD not playing	CD inserted incorrectly; CD is dirty or scratched; Disc format not supported	Re-insert CD correctly; Clean or replace CD; Ensure it's a compatible CD (CD, CD-R, CD-RW).
Bluetooth pairing fails	Device not in pairing mode; M5P not in Bluetooth mode; Device too far	Ensure both devices are in pairing mode; Select Bluetooth mode on M5P; Move devices closer.

9. SPECIFICATIONS

Detailed technical specifications for the LEMEGA M5P system.

- **Brand:** LEMEGA
- **Model Number:** M5
- **ASIN:** B08HMWMB3T
- **GTIN/UPC:** 779584903648
- **Connectivity Technology:** USB, Bluetooth, Wi-Fi
- **Power Source:** Cable Electric
- **Voltage:** 220 Volts
- **Maximum Speaker Output Power:** 35 Watts
- **Audio Output Mode:** Stereo
- **Compatible Devices:** Smartphone, Tablet, MP3 Player
- **Item Weight:** 4.55 Kilograms
- **Spare Parts Availability:** Information not available
- **Software Updates Guaranteed Until:** Information not available

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the

official LEMEGA website. Keep your proof of purchase for any warranty claims.

© 2023 LEMEGA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question