

vidaXL 145380

vidaXL Double Stainless Steel Bin Storage Shed Instruction Manual

Model: 145380

1. INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your vidaXL Double Stainless Steel Bin Storage Shed. This practical storage solution is designed to conceal two 240-liter or smaller waste bins, enhancing the aesthetic appeal of your outdoor space. Constructed from durable stainless steel, it offers weather resistance and features ventilation holes to prevent odor buildup, along with a secure locking system.

2. SAFETY INFORMATION

- Do not exceed the maximum recommended load capacity to prevent structural damage.
- Wear protective gloves during assembly, as some metal components may have sharp edges.
- Ensure all fasteners are securely tightened during assembly and periodically check for tightness.
- Place the shed on a stable and level surface to ensure proper door and lid function.

3. PACKAGE CONTENTS

The package includes all necessary components and hardware for assembling the vidaXL Double Stainless Steel Bin Storage Shed. Please verify all parts are present before beginning assembly. If any parts are missing or damaged, contact your retailer for assistance.

4. SETUP AND ASSEMBLY

Assembly of this bin storage shed is required. It is recommended that two people perform the assembly to ensure stability and ease of construction. Follow the included assembly instructions carefully.

1. **Preparation:** Choose a flat, level surface for installation. An uneven surface can cause doors to jam or the structure to be unstable.
2. **Tools:** Basic hand tools (e.g., screwdriver, wrench) are typically sufficient. However, some users have reported needing additional tools for minor adjustments or alignment.

3. **Component Identification:** Familiarize yourself with all parts before starting. Refer to the assembly diagram.
4. **Assembly Steps:** Connect panels, doors, and lids according to the provided diagrams. Ensure all screws and bolts are tightened securely.



Image 1: Assembled bin storage shed with one door open, showing a waste bin.




Image 2: Dimensional view of the bin storage shed.

5. OPERATING INSTRUCTIONS

The bin storage shed is designed for straightforward use to manage your waste bins.

- **Accessing Bins:** Open the front doors to easily roll waste bins in and out of the shed.
- **Depositing Waste:** The top lids can be opened to deposit waste into the bins without needing to open the main doors.
- **Securing the Shed:** Utilize the integrated locking system on the doors to secure the contents and prevent unauthorized access or animal interference.



Image 3: Detail of a lid handle for easy opening.



Image 4: Detail of the door locking mechanism.

6. MAINTENANCE

Proper maintenance will extend the lifespan and preserve the appearance of your bin storage shed.

- **Cleaning:** The stainless steel surface is easy to clean. Use a soft cloth with mild soap and water, or a specialized stainless steel cleaner. Avoid abrasive cleaners or scouring pads that can scratch the surface.
- **Fasteners:** Periodically inspect all screws and bolts for tightness. While the shed is made of stainless steel, some fasteners may be of a different material and could be susceptible to rust. Replace any rusted fasteners with stainless steel alternatives if necessary.
- **Lid Mechanisms:** Check the lid support mechanisms (e.g., gas struts) for proper function. If a lid does not stay open, the support may need adjustment or replacement.



Image 5: Detail of the lid support mechanism.

7. TROUBLESHOOTING

- **Doors Jamming:** If doors do not open or close smoothly, ensure the shed is placed on a completely level surface. Adjust the shed's position or add shims under the base if necessary.
- **Lids Not Staying Open:** Inspect the lid support mechanisms (e.g., gas struts) for damage or wear. These may need to be replaced if they no longer hold the lid open.
- **Rust Spots:** Although the main structure is stainless steel, some minor components or fasteners might show rust. Clean rust spots with a stainless steel cleaner and consider replacing affected fasteners with higher-grade stainless steel hardware.

8. SPECIFICATIONS

| | |
|---------------------|--------|
| Brand | vidaXL |
| Model Number | 145380 |
| Color | Silver |

| | |
|---------------------------------------|------------------------|
| Material | Stainless Steel |
| Product Dimensions (D x W x H) | 115P x 77.5l x 115H cm |
| Item Weight | 42.25 Kilograms |
| Door Width | 77.5 Centimeters |
| Door Height | 115 Centimeters |
| Chamber Depth | 115 Centimeters |
| Style | Modern |
| Water Resistance Level | Water Resistant |
| UV Protection | No |
| Assembly Required | Yes |
| Country of Origin | China |

9. WARRANTY INFORMATION

No specific warranty information is provided within the product details. For details regarding warranty coverage, terms, and conditions, please refer to your purchase documentation or contact the retailer from whom you purchased the product.

10. SUPPORT

For further assistance, technical support, or inquiries not covered in this manual, please contact your retailer or the manufacturer, vidaXL, through their official customer service channels. Please have your model number (145380) and purchase details available when contacting support.