

[manuals.plus](#) /

› [Peerless](#) /

› [Peerless Elmhurst P2665LF-OB Two-Handle Bath Faucet Instruction Manual](#)

## Peerless P2665LF-OB

# Peerless Elmhurst Two-Handle Centerset Bath Faucet

Model: P2665LF-OB (Oil-Rubbed Bronze)

## INTRODUCTION

This manual provides instructions for the installation, operation, and maintenance of your Peerless Elmhurst Two-Handle Centerset Bath Faucet. Please read all instructions carefully before beginning installation and keep this manual for future reference.



Image: Peerless Elmhurst Two-Handle Centerset Bath Faucet in Oil-Rubbed Bronze, shown installed on a bathroom vanity with a mirror and plant.

## SAFETY INFORMATION

---

- Always turn off the water supply to the faucet before beginning any work.
- Wear safety glasses during installation.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Ensure all connections are secure to prevent leaks.

## WHAT'S IN THE BOX

---

Verify that all components are present before beginning installation:

- Faucet Assembly
- Handles (2)
- Push Pop-Up Drain Assembly
- Mounting Hardware

## SPECIFICATIONS



Image: Diagram illustrating key dimensions and features of the Peerless Elmhurst Two-Handle Centerset Lavatory Faucet, including 3-hole installation, ceramic disc valve, 7.6 inch height, 5 inch spout reach, 9.3 inch width, and 2.5 inch minimum clearance to backsplash.

Feature	Detail
Model Number	P2665LF-OB
Finish	Oil-Rubbed Bronze
Mounting Type	Deck Mount
Hole Count	3-hole, 4-inch installations
Number of Handles	2
Material	Zinc
Valve Type	Ceramic Disc Valve
Spout Swivel	360 degrees

Drain Type	Push Pop-Up Drain (included)
WaterSense Certified	Yes (uses at least 20% less water)
ADA Compliant	Yes

## SETUP AND INSTALLATION

This faucet is designed for 3-hole, 4-inch centerset installations. Refer to the included installation guide for detailed step-by-step instructions and diagrams.

- 1. Prepare the Installation Area:** Turn off the water supply at the main shut-off valves. Clear the area under the sink.
- 2. Remove Old Faucet (if applicable):** Disconnect water lines and mounting nuts from the old faucet. Clean the sink surface.
- 3. Install Faucet Body:** Place the faucet body onto the sink holes. Secure it from underneath with the provided mounting hardware.
- 4. Connect Water Supply Lines:** Attach the hot and cold water supply lines to the corresponding inlets on the faucet body. Hand-tighten, then use a wrench for a quarter turn. Do not overtighten.
- 5. Install Pop-Up Drain:** Follow the instructions for installing the push pop-up drain assembly into the sink drain hole. Ensure a watertight seal.
- 6. Test for Leaks:** Turn on the water supply slowly and check all connections for leaks. Operate the faucet to ensure proper function.

## OPERATING INSTRUCTIONS

The Peerless Elmhurst faucet features two handles for precise control of water temperature and flow.



Image: The Peerless Elmhurst Two-Handle Centerset Bath Faucet in Oil-Rubbed Bronze with water flowing from its high-arc spout into a white sink.

- **Cold Water:** Turn the right handle counter-clockwise a quarter turn to activate cold water.
- **Hot Water:** Turn the left handle counter-clockwise a quarter turn to activate hot water.
- **Temperature Control:** Adjust the mix of hot and cold water by rotating both handles simultaneously.
- **Flow Control:** The handles feature 1/4 turn stops for easy on/off and flow adjustment.
- **Spout Swivel:** The high-arc spout can swivel 360 degrees for increased flexibility.
- **Pop-Up Drain:** Press the top of the drain stopper to open or close the drain.

## MAINTENANCE

---

Proper care will ensure the longevity and appearance of your faucet.

- **Cleaning:** Clean the faucet regularly with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or polishes that could damage the finish.
- **Mineral Deposits:** For hard water spots, use a solution of equal parts white vinegar and water. Apply with a soft cloth, let sit briefly, then rinse thoroughly and dry.
- **Aerator Maintenance:** If water flow decreases, the aerator may be clogged. Unscrew the aerator from the spout, clean any debris, and reattach.

## TROUBLESHOOTING

---

Refer to the following common issues and solutions:

- **Low Water Flow:** Check if the aerator is clogged. Ensure water supply valves are fully open.
- **Leaks from Faucet Base:** Ensure mounting nuts are tightened securely. Check for proper seating of gaskets.
- **Leaks from Handles:** This may indicate a worn O-ring or cartridge. Consult the full installation guide or contact customer support for replacement parts.
- **Water Temperature Issues:** Verify that both hot and cold water supply lines are connected correctly and that the water heater is functioning.

## WARRANTY INFORMATION

---

Peerless products are manufactured to high-quality standards and are backed by a limited warranty. For specific warranty details and terms, please refer to the warranty card included with your product or visit the official Peerless website.

## SUPPORT

---

For further assistance, technical support, or to order replacement parts, please contact Peerless customer service or visit their official website:

- **Website:** [Visit the Peerless Store on Amazon](#) (for product information) or search for the official Peerless Faucet website.
- **Customer Service:** Refer to the contact information provided in your product packaging or on the

official Peerless website.

---

© 2026 Peerless Faucet Company. All rights reserved.