



Manuals.plus /

› LyxJam /

› LyxJam 7-Piece Electronic Drum Kit User Manual

## LyxJam EDS750

# LyxJam 7-Piece Electronic Drum Kit User Manual

Model: EDS750 | Brand: LyxJam

## INTRODUCTION

---

This manual provides detailed instructions for the setup, operation, and maintenance of your LyxJam 7-Piece Electronic Drum Kit. Designed for both beginners and advanced players, this kit offers a realistic drumming experience with its mesh fabric pads and versatile sound module. Please read this manual thoroughly before using your drum kit to ensure proper function and longevity.



Figure 1: Complete LyxJam 7-Piece Electronic Drum Kit setup.

## WHAT'S INCLUDED

---

Your LyxJam 7-Piece Electronic Drum Kit package includes the following components:

- 7 Pc Drum Kit (including 3x 8" Mesh Tom Pads, 1x 8" Mesh Snare Pad, 1x 8" Crash Cymbal, 1x 8" Ride Cymbal, 1x 8" Hi-Hat Cymbal with Controller)
- Sound Module
- Kick Pedal
- Drum Sticks
- Drum Key
- All necessary connection cables, rods, fasteners, and adapters for assembly.



**GET YOUR FEET  
INVOLVED IN  
THE RHYTHM**  
**INCLUDED  
HI-HAT AND  
KICK PEDALS**

Figure 2: Key components of the LyxJam Electronic Drum Kit.

## SETUP GUIDE

---

Follow these steps to assemble your electronic drum kit:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the "What's Included" list.
2. **Assemble the Rack:** Connect the main frame components using the provided fasteners and drum key. Ensure all connections are secure.
3. **Attach Drum Pads:** Mount the mesh tom pads and snare pad to the rack. Adjust their positions for comfortable playing.
4. **Install Cymbals:** Attach the crash, ride, and hi-hat cymbals to their respective stands on the rack.
5. **Connect Pedals:** Place the kick pedal and hi-hat controller pedal on the floor. Connect them to the sound module using the appropriate cables.
6. **Mount Sound Module:** Secure the sound module to the central part of the rack.
7. **Cable Connections:** Connect each drum pad and cymbal to the sound module's trigger inputs using the provided cables. Ensure each cable is connected to its corresponding input (e.g., Snare to Snare input, Tom 1 to Tom 1 input).

8. **Power On:** Connect the power adapter to the sound module and a power outlet. Turn on the power switch.



Figure 3: Detailed view of the sound module connections.

## OPERATING INSTRUCTIONS

Your LyxJam Electronic Drum Kit features an advanced sound module with various functions:

- **Sound Module Overview:** The module includes an easy-read LED display, Master Volume knob, and buttons for Click, Tempo, Kit, Pattern, Voice, Volume, Drum Off, Stop, Play, Record, and Save.
- **Preloaded Sounds & Songs:** Access 209 preloaded sounds and 50 play-along songs to enhance your practice and performance.
- **Recording Capability:** The module supports 1-song recording capacity, allowing you to capture your drumming sessions.
- **Metronome:** Utilize the built-in metronome for precise timing practice.
- **Connectivity:**
  - **Headphone Output:** Connect headphones for private practice.

- **Line In/Out:** Connect to external speakers or audio interfaces.
- **USB B-Type:** Connect to a computer for MIDI functionality or software integration.
- **Mesh Fabric Pads:** The 100% mesh fabric drum heads provide a responsive and realistic feel, mimicking acoustic drums.
- **Rubber Cymbals:** The 8" Ride and 8" Crash cymbals offer multi-zone capability for nuanced percussion techniques.

# GO FROM BEGINNER TO PRO WITH THE BUILT-IN LEARNING SYSTEM



**209**  
PRE-LOADED  
SOUNDS

**50**  
PRE-LOADED  
SONGS

**1**  
SONG RECORDING  
CAPACITY



**209**  
PRE-LOADED  
SOUNDS



**50**  
PRE-LOADED  
SONGS



**1**  
SONG RECORDING  
CAPACITY

**Lux JAM**

Figure 4: Close-up view of the sound module controls and display.

# NATURAL-FEELING MESH DRUM HEAD WITH THE BOUNCE BACK OF A REAL DRUM



Figure 5: The natural-feeling mesh drum head.

## MAINTENANCE

---

To ensure the longevity and optimal performance of your LyxJam Electronic Drum Kit, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the drum pads, cymbals, and sound module. Avoid using abrasive cleaners or solvents.
- **Cable Management:** Keep cables neatly organized and avoid sharp bends or kinks to prevent damage.
- **Pad Tension:** Periodically check the tension of the mesh drum heads. Adjust with the drum key if they become too loose or too tight, ensuring a consistent rebound.
- **Storage:** When not in use for extended periods, store the drum kit in a dry, temperature-controlled environment away from direct sunlight or extreme humidity.
- **Connection Check:** Regularly inspect all cable connections to ensure they are secure and free from corrosion.

## TROUBLESHOOTING

---

---

If you encounter issues with your drum kit, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from a specific pad/cymbal.	Loose or incorrect cable connection; faulty pad/cymbal.	Ensure the cable from the pad/cymbal is securely connected to the correct input on the sound module. Try swapping the cable with a known working one. If the issue persists, the pad/cymbal or cable may be faulty.
No sound from the entire kit.	Power issue; master volume too low; headphones/speakers not connected or faulty.	Check power adapter connection and ensure the unit is powered on. Increase the Master Volume knob on the sound module. Verify headphones or external speakers are properly connected and functioning.
Pads not responding consistently (e.g., kick pedal, hi-hat pedal).	Pedal placement; sensor issue; cable issue.	Ensure pedals are placed on a stable surface, preferably a mat or carpet to prevent sliding. Check cable connections for the pedals. If a specific pad/pedal consistently fails, it may require replacement.

For further assistance, please refer to the support section or contact LyxJam customer service.

## SPECIFICATIONS

---

Feature	Detail
Model Number	EDS750
Brand	LyxJam
Kit Configuration	7-Piece (3x 8" Mesh Tom Pads, 1x 8" Mesh Snare Pad, 1x 8" Crash Cymbal, 1x 8" Ride Cymbal, 1x 8" Hi-Hat Cymbal with Controller, Kick Pedal)
Drum Head Material	100% Mesh Fabric
Sound Module Sounds	209 Preloaded Sounds
Sound Module Songs	50 Play-Along Songs
Recording Capacity	1 Song
Connectivity	Headphone Output, Line In/Out, USB B-Type
Included Components	7 Pc Drum, drum sticks, drum key
Body Material	Metal
Product Dimensions	25.7 x 10.1 x 32.1 inches
Item Weight	7.33 pounds (3.33 Kilograms)
Color	Black
UPC	843812142946

## WARRANTY AND SUPPORT

---

For warranty information or technical support, please contact LyxJam customer service. Details can typically be found on the product packaging or the official LyxJam website. Keep your purchase receipt as proof of purchase for warranty claims. You can visit the LyxJam Store for more information: [LyxJam Store](#)

